



Original instructions

YAMAHA 4-AXIS/2-AXIS ROBOT CONTROLLER

RCX 3 Series

Programming Manual

RCX340/RCX320

Ver. 2.11

EGR9232211
E135

Introduction

Safety precautions

Chapter 1 Writing Programs

1	The YAMAHA Robot Language	1-1
2	Characters	1-1
3	Program Basics	1-1
4	Program Names	1-2
5	Identifiers	1-4
6	LABEL Statement	1-4
7	Comment	1-5
8	Command Statement Format	1-5

Chapter 2 Constants

1	Outline	2-1
2	Numeric constants	2-1
2.1	Integer constants	2-1
2.2	Real constants	2-1
3	Character constants	2-2

Chapter 3 Variables

1	Outline	3-1
2	User Variables & System Variables	3-2
2.1	User Variables	3-2
2.2	System Variables	3-2
3	Variable Names	3-3
3.1	Dynamic Variable Names	3-3
3.2	Static Variable Names	3-3

4 Variable Types	3-4
4.1 Numeric variables	3-4
4.2 Character variables	3-4

5 Array variables	3-5
--------------------------	------------

6 Value Assignments	3-5
----------------------------	------------

7 Type Conversions	3-6
---------------------------	------------

8 Value Pass-Along & Reference Pass-Along	3-6
--	------------

9 System Variables	3-7
9.1 Point variable	3-7
9.2 Shift variable	3-8
9.3 Parallel input variable	3-8
9.4 Parallel output variable	3-9
9.5 Internal output variable	3-10
9.6 Arm lock output variable	3-11
9.7 Timer output variable	3-12
9.8 Serial input variable	3-13
9.9 Serial output variable	3-14
9.10 Serial word input	3-15
9.11 Serial double word input	3-15
9.12 Serial word output	3-16
9.13 Serial double word output	3-16

10 Bit Settings	3-17
------------------------	-------------

11 Valid range of variables	3-18
11.1 Valid range of dynamic (array) variables	3-18
11.2 Valid range of static variables	3-18

12 Clearing variables	3-19
12.1 Clearing dynamic variables	3-19
12.2 Clearing static variables	3-19

Chapter 4 Expressions and Operations

1 Arithmetic operations	4-1
1.1 Arithmetic operators	4-1
1.2 Relational operators	4-1
1.3 Logic operations	4-2

1.4	Priority of arithmetic operation	4-3
1.5	Data format conversion	4-3
2	Character string operations	4-4
2.1	Character string connection	4-4
2.2	Character string comparison	4-4
3	Point data format	4-5
4	DI/DO conditional expressions	4-6
Chapter 5 Multiple Robot Control		
1	Overview	5-1
2	Command list with a robot setting	5-2
Chapter 6 Multi-tasking		
1	Outline	6-1
2	Task definition method	6-1
3	Task status and transition	6-2
3.1	Starting tasks	6-2
3.2	Task scheduling	6-3
3.3	Condition wait in task	6-4
3.4	Suspending tasks (SUSPEND)	6-5
3.5	Restarting tasks (RESTART)	6-5
3.6	Deleting tasks	6-6
3.7	Stopping tasks	6-7
4	Multi-task program example	6-8
5	Sharing the data	6-9
6	Cautionary Items	6-9
Chapter 7 Sequence function		
1	Sequence function	7-1
2	Sequence program specifications	7-1

3	Creating a sequence program	7-2
3.1	Programming method	7-2
3.2	Compiling	7-4
4	Executing a sequence program	7-5
4.1	Sequence program STEP execution	7-5
5	Programming a sequence program	7-6
5.1	Assignment statements	7-6
5.2	Input/output variables	7-6
5.3	Timer definition statement	7-8
5.4	Logical operators	7-9
5.5	Priority of logic operations	7-9

Chapter 8 Robot Language

Robot language list		8-1
1	ABS	Acquires absolute values 8-7
2	ABSRPOS	Acquires the machine reference value (axes: mark method) 8-8
3	ACCEL	Specifies/acquires the acceleration coefficient parameter 8-9
4	ARCHP1 / ARCHP2	Specifies/acquires the arch distance parameter 8-10
5	ARMCND	Acquires the current arm status 8-12
6	ARMSEL	Sets/acquires the current hand system selection 8-13
7	ARMTYP	Sets/acquires the hand system selection during program reset 8-14
8	ASPEED	Sets/acquires the AUTO movement speed of robot 8-15
9	ATN / ATN2	Acquires the arctangent of the specified value 8-16
10	AXWGHT	Sets/acquires the axis tip weight 8-17
11	CALL	Calls a sub-procedure 8-18
12	CHANGE	Switches the hand data 8-19
13	CHGPRI	Changes the priority ranking of task 8-20
14	CHGWRK	Switches the work data 8-21
15	CHR\$	Acquires a character with the specified character code 8-22
16	CLOSE	Closes the specified General Ethernet Port 8-23
17	CONTPLS	Specifies/acquires CONT pulse parameter of specified robot. 8-24
18	CORRECTXY	Acquires the target position corrected for workpiece gripping position misalignment. 8-25
19	COS	Acquires the cosine value of a specified value 8-26
20	CREWRK	Creates the work data from the offset; difference between 2 point data 8-27

21	CURTQST	Acquires the ratio of the current torque (current) value of axis against the rated torque (current) value	8-28
22	CURTRQ	Acquires the ratio of the current torque (current) value of axis against the maximum torque (current) value	8-29
23	CUT	Terminates another task which is currently being executed	8-30
24	DATE\$	Acquires the date	8-31
25	DECEL	Specifies/acquires the deceleration ratio parameter	8-32
26	DEF FN	Defines functions which can be used by the user	8-33
27	DEGRAD	Angle conversion (degree → radian)	8-34
28	DELAY	Program execution waits for a specified period of time	8-35
29	DI	Acquires the input status from the parallel port	8-36
30	DIM	Declares array variable	8-37
31	DIST	Acquires the distance between 2 specified points	8-38
32	DO	Outputs to parallel port or acquires the output status	8-39
33	DRIVE	Executes absolute movement of specified axes	8-41
34	DRIVEI	Moves the specified robot axes in a relative manner	8-45
35	END SELECT	Ends the SELECT CASE statement	8-50
36	END SUB	Ends the sub-procedure definition	8-51
37	ERR / ERL	Acquires the error code / error line number	8-52
38	ETHSTS	Acquires the Ethernet port status	8-53
39	EXIT FOR	Terminates the FOR to NEXT statement loop	8-54
40	EXIT SUB	Terminates the sub-procedure defined by the SUB to END SUB statement	8-55
41	EXIT TASK	Terminates its own task which is in progress	8-56
42	FOR to NEXT	Performs loop processing until the variable exceeds the specified value	8-57
43	GEPSTS	Acquires the General Ethernet Port status	8-58
44	GOSUB to RETURN	Jumps to a subroutine	8-59
45	GOTO	Executes an unconditional jump to the specified line	8-60
46	HALT	Stops the program and performs a reset	8-61
47	HALTALL	Stops all programs and performs reset	8-62
48	HAND	Defines the hand	8-63
48.1	For SCARA Robots		8-64
48.1.1	<4th parameter> "R" is not specified.		8-64
48.1.2	<4th parameter> "R" is specified.		8-65
48.2	For Cartesian Robots		8-66
48.2.1	<4th parameter> "R" is not specified.		8-66
48.2.2	<4th parameter> "R" is specified.		8-67

49	HOLD	Temporarily stops the program	8-68
50	HOLDALL	Temporality stops all programs	8-69
51	IF	Evaluates a conditional expression value, and executes the command in accordance with the conditions	8-70
51.1	Simple IF statement		8-70
51.2	Block IF statement		8-71
52	INPUT	Assigns a value to a variable specified from the programming box	8-72
53	INROFST	Specifies/acquires R axis inertia offset for SCARA parameter.	8-74
54	INT	Truncates decimal fractions	8-75
55	JTOXY	Performs axis unit system conversions (pulse → mm)	8-76
56	LEFT\$	Extracts character strings from the left end	8-77
57	LEFTY	Sets the SCARA robot hand system as a left-handed system	8-78
58	LEN	Acquires a character string length	8-79
59	LET	Assigns values to variables	8-80
59.1	Arithmetic assignment statement		8-80
59.2	Character string assignment statement		8-81
59.3	Point assignment statement		8-81
59.4	Shift assignment statement		8-82
60	LO	Arm lock output or acquires the output status	8-83
61	LOCx	Specifies/acquires point data for a specified axis or shift coordinate data/work data for a specified element	8-85
62	LSHIFT	Left-shifts a bit	8-87
63	MCHREF	Acquires the machine reference value (axes: sensor method / stroke-end method)	8-88
64	MID\$	Acquires a character string from a specified position	8-89
65	MO	Outputs a specified value to the MO port or acquires the output status	8-90
66	MOTOR	Controls the motor power status	8-92
67	MOVE	Moves robot to the absolute position	8-93
68	MOVEI	Moves robot to the relative position	8-110
69	MOVET	Performs relative movement of all robot axes in tool coordinates	8-111
70	MTRDUTY	Acquires the motor load factor of the specified axis	8-112
71	OFFLINE	Sets a specified communication port to the "offline" mode	8-113
72	ON ERROR GOTO	Jumps to a specified label when an error occurs	8-114
73	ON to GOSUB	Executes the subroutine specified by the <expression> value	8-115
74	ON to GOTO	Jumps to the label specified by the <expression> value	8-116
75	ONLINE	Sets the specified communication port to the "online" mode	8-117

76	OPEN	Opens the specified General Ethernet Port	8-118
77	ORD	Acquires a character code	8-119
78	ORGORD	Specifies/acquires the robot's return-to-origin sequence	8-120
79	ORIGIN	Performs return-to-origin	8-121
80	OUT	Turns ON the specified port output	8-122
81	OUTPOS	Specifies/acquires the OUT enable position parameter of the robot	8-123
82	PATH	Specifies the motion path	8-125
83	PATH END	Ends the path setting	8-129
84	PATH SET	Starts the path setting	8-130
85	PATH START	Starts the PATH motion	8-133
86	PDEF	Defines the pallet	8-135
87	PGMTSK	Acquires the task number in which a specified program is registered	8-136
88	PGN	Acquires the program number from a specified program name	8-137
89	PMOVE	Executes a pallet movement command for the robot	8-138
90	Pn	Defines points within a program	8-143
91	PPNT	Creates pallet point data	8-145
92	PRINT	Displays the specified expression value at the programming box	8-146
93	PSHFRC	Specifies/acquires the pushing force parameter	8-147
94	PSHJGSP	Specifies/acquires the push judge speed parameter	8-148
95	PSHMTD	Specifies/acquires a pushing type parameter	8-149
96	PSHRSLT	Acquires the status when PUSH statement ends	8-150
97	PSHSPD	Specifies/acquires the push speed parameter	8-151
98	PSHTIME	Specifies/acquires the push time parameter	8-152
99	PUSH	Executes a pushing operation for specified axes	8-153
100	RADDEG	Performs a unit conversion (radians → degrees)	8-158
101	REFTSK	Acquires the task state	8-159
102	REM	Inserts a comment	8-160
103	RESET	Turns OFF the bits of specified ports, or clears variables	8-161
104	RESTART	Restarts another task during a temporary stop	8-162
105	RESUME	Resumes program execution after error recovery processing	8-163
106	RETURN	Processing which was branched by GOSUB, is returned to the next line after GOSUB	8-164
107	RIGHT\$	Extracts a character string from the right end of another character string	8-165
108	RIGHTY	Sets the SCARA robot hand system as a right-handed system	8-166

109 RSHIFT	Shifts a bit value to the right	8-167
110 SCRINR	Specifies/acquires R axis inertia for SCARA parameter.	8-168
111 SELECT CASE to END SELECT	Executes the specified command block in accordance with the <expression> value	8-169
112 SEND	Sends readout file data to the write file	8-170
113 SERVO	Controls the servo status	8-172
114 SET	Turns the bit at the specified output port ON	8-173
115 SETGEP	Sets the General Ethernet Port	8-174
116 SGI	Assigns /acquires the value to a specified integer type static variable	8-175
117 SGR	Assigns /acquires the value to a specified real type static variable	8-176
118 SHARED	Enables sub-procedure referencing without passing on the variable	8-177
119 SHIFT	Sets the shift coordinates	8-178
120 SI	Acquires specified SI status	8-179
121 SID	Acquires a specified serial input's double-word information	8-180
122 SIN	Acquires the sine value for a specified value	8-181
123 SIW	Acquires a specified serial input's word information	8-182
124 Sn	Defines the shift coordinates in the program	8-183
125 SO	Outputs a specified value to serial port or acquires the output status	8-184
126 SOD	Outputs a specified serial output's double-word information or acquires the output status	8-186
127 SOW	Outputs a specified serial output's word information or acquires the output status	8-187
128 SPEED	Changes the program movement speed	8-188
129 SQR	Acquires the square root of a specified value	8-189
130 START	Starts a new task	8-190
131 STR\$	Converts a numeric value to a character string	8-191
132 SUB to END SUB	Defines a sub-procedure	8-192
133 SUSPEND	Temporarily stops another task which is being executed	8-194
134 SWI	Switches the program being executed	8-195
135 TAN	Acquires the tangent value for a specified value	8-196
136 TCOUNTER	Timer & counter	8-197
137 TIME\$	Acquires the current time	8-198
138 TIMER	Acquires the current time	8-199
139 TO	Outputs a specified value to the TO port or acquires the output status	8-200
140 TOLE	Specifies/acquires the tolerance parameter	8-201

141 TORQUE	Specifies/acquires the maximum torque command value	8-202
142 TSKPGM	Acquires the program number which is registered in a specified task number	8-204
143 VAL	Converts character strings to numeric values	8-205
144 WAIT	Waits until the conditional expression is met	8-206
145 WAIT ARM	Waits until the robot axis operation is completed	8-207
146 WEIGHT	Specifies/acquires the tip weight (kg) parameter	8-208
147 WEIGHTG	Specifies/acquires the tip weight (g) parameter	8-209
148 WEND	Ends the WHILE statement's command block	8-210
149 WHERE	Acquires the arm's current position (pulse coordinates)	8-211
150 WHILE to WEND	Repeats an operation for as long as a condition is met	8-212
151 WHRXY	Acquires the arm's current position in Cartesian coordinates	8-213
152 WRKDEF	Defines the work data (creates the work data of the specified number)	8-214
153 XYTOJ	Converts the Cartesian coordinate data ("mm") to joint coordinate data ("pulse")	8-216

Chapter 9 PATH Statements

1 Overview	9-1
2 Features	9-1
3 How to use	9-1
4 Cautions when using this function	9-2

Chapter 10 Data file description

1 Overview	10-1
2 Program file	10-3
3 Point file	10-5
4 Point comment file	10-8
5 Point name file	10-10
6 Parameter file	10-12
7 Shift coordinate definition file	10-16

8 Hand definition file	10-18
9 Work definition file	10-20
10 Pallet definition file	10-22
11 General Ethernet port file	10-26
12 Input/output name file	10-28
13 Area check output file	10-32
14 Real time output file	10-34
15 All file	10-38
16 Program directory file	10-40
17 Parameter directory file	10-42
18 Machine reference file	10-43
19 Accumulated data file	10-45
20 System configuration information file	10-46
21 Version information file	10-47
22 Option board file	10-48
23 Self check file	10-49
24 Alarm history file	10-50
25 Remaining memory size file	10-52
26 Variable file	10-53
27 Constant file	10-59
28 Array variable file	10-60
29 DI file	10-62
30 DO file	10-64

31 MO file	10-66
32 LO file	10-68
33 TO file	10-70
34 SI file	10-72
35 SO file	10-74
36 SIW file	10-76
37 SOW file	10-78
38 EOF file	10-80
39 Serial port communication file	10-81
40 Ethernet port communication file	10-82

Chapter 11 User program examples

1 Basic operation	11-1
1.1 Directly writing point data in program	11-1
1.2 Using point numbers	11-2
1.3 Using shift coordinates	11-3
1.4 Palletizing	11-4
1.4.1 Calculating point coordinates	11-4
1.4.2 Utilizing pallet movement	11-6
1.5 DI/DO (digital input and output) operation	11-7
2 Application	11-8
2.1 Pick and place between 2 points	11-8
2.2 Palletizing	11-10
2.3 Pick and place of stacked parts	11-12
2.4 Parts inspection (Multi-tasking example)	11-14
2.5 Sealing	11-17
2.6 Connection to an external device through RS-232C (example 1)	11-18
2.7 Connection to an external device through RS-232C (example 2)	11-19

Chapter 12 Online commands

1 Online Command List	12-1
------------------------------	-------------

2	Operation and setting commands	12-5
3	Reference commands	12-21
4	Operation commands	12-37
5	Data file operation commands	12-41
6	Utility commands	12-51
7	Individual execution of robot language	12-53
8	Control codes	12-55

Chapter 13 Appendix

1	Reserved word list	13-1
	Variable name usage examples	13-2
2	Changes from conventional models	13-3
1	Program name	13-3
2	Multiple Robot Control	13-3
3	Multi-tasking	13-4
4	Robot Language	13-4
5	Online commands	13-4
6	Data file	13-4

Introduction

Our sincere thanks for your purchase of this YAMAHA RCX 3 series robot controller.

This manual describes robot program commands and related information for using YAMAHA RCX 3 series robot controllers. Be sure to read this manual carefully as well as related manuals and comply with their instructions for using the YAMAHA robot controllers safely and correctly.

For details on how to operate YAMAHA robot controllers, refer to the separate controller user's manual that comes with the YAMAHA robot controller.

Applicable controllers: RCX340, RCX320

Safety precautions

Be sure to read before using

Before using the YAMAHA robot controller, be sure to read this manual and related manuals, and follow their instructions to use the robot controller safely and correctly.

Warning and caution items listed in this manual relate to YAMAHA robot controllers.

When this robot controller is used in a robot controller system, please take appropriate safety measures as required by the user's individual system.

This manual classifies safety caution items and operating points into the following levels, along with symbols for signal words "CAUTION" and "NOTE".



CAUTION

"CAUTION" indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury or damage to the equipment or software.



NOTE

Primarily explains function differences, etc., between software versions.



MEMO

Explains robot operation procedures in a simple and clear manner.

Note that the items classified into "CAUTION" might result in serious injury depending on the situation or environmental conditions.

Keep this manual carefully so that the operator can refer to it when needed. Also make sure that this manual reaches the end user.

Chapter 1

Writing Programs

1	The YAMAHA Robot Language.....	1-1
2	Characters	1-1
3	Program Basics	1-1
4	Program Names.....	1-2
5	Identifiers.....	1-4
6	LABEL Statement	1-4
7	Comment	1-5
8	Command Statement Format	1-5

The YAMAHA robot language was developed by Yamaha Motor Co., Ltd. Robotics Company for simple and efficient programming to control YAMAHA industrial robots. The YAMAHA robot language is similar to BASIC (Beginner's All-purpose Symbolic Instruction Code) and makes even complex robot movements easy to program. This manual explains how to write robot control programs with the YAMAHA robot language, including actual examples on how its commands are used.

The characters and symbols used in the YAMAHA robot language are shown below.

Only 1-byte characters can be used.

- **Alphabetic characters**

A to Z, a to z

- **Numbers**

0 to 9

- **Symbols**

() [] + - * / ^ = < > & | ~ _ % ! # \$; , . " ' { } @ ?

- **katakana (Japanese phonetic characters)**



- Katakana (Japanese phonetic characters) cannot be entered from a programming box. Katakana can be used when communicating with a host computer (if it handles katakana).
- Spaces are also counted as characters (1 space = 1 character).

Programs are written in a "1 line = 1 command" format, and every line must contain a command. Blank lines (lines with no command) will cause an error when the program is executed. A line-feed on the program's final line creates a blank line, so be careful not to do so.

To increase the program's efficiency, processes which are repeated within the program should be written as subroutines or sub-procedures which can be called from the main routine. Moreover, same processing items which occurs in multiple programs should be written as common routines within a program named [COMMON], allowing those processing items to be called from multiple programs.

User functions can be defined for specific calculations. Defined user functions are easily called, allowing even complex calculations to be easily performed.

Multi-task programs can also be used to execute multiple command statements simultaneously in a parallel processing manner.

Using the above functions allows easy creation of programs which perform complex processing.

Reference

- For details regarding sub-procedure, refer to "11 CALL" and "127 SUB to END SUB" in Chapter 8.
- For details regarding user defined functions, refer to "24 DEF FN" in Chapter 8.

Each program to be created in the robot controller must have its own name.

Programs can be named as desired provided that the following conditions are satisfied:

- Program names may contain no more than 32 characters, comprising a combination of alphanumeric characters and underscores (_).
- Each program must have a unique name (no duplications).

The 2 program names shown below are reserved for system operations, and programs with these names have a special meaning.

- A) SEQUENCE
- B) COMMON

The functions of these programs are explained below.

A) SEQUENCE

Functions Unlike standard robot programs, the RCX340/RCX320 Controller allow the execution of high-speed processing programs (sequence programs) in response to robot inputs and outputs (DI, DO, MO, LO, TO, SI, SO). Specify a program name of "SEQUENCE" to use this function, thus creating a pseudo PLC within the controller.

When the controller is in the AUTO or MANUAL mode, a SEQUENCE program can be executed in fixed cycles (regardless of the program execution status) in response to dedicated DI10 (sequence control input) input signals, with the cycle being determined by the program capacity. For details, refer to "4.6 Sequence program specifications" in Chapter 7.

This allows sensors, push-button switches, and solenoid valves, etc., to be monitored and operated by input/output signals.

Moreover, because the sequence programs are written in robot language, they can easily be created without having to use a new and unfamiliar language.

Sample

```
DO (20) = ~DI (20)
DO (25) = DI (21) AND DI (22)
MO (26) = DO (26) OR DO (25)
:
```

Reference For details, refer to "4.6 Sequence program specifications" in Chapter 7.

B) COMMON

Functions A separate "COMMON" program can be created to perform the same processing in multiple robot programs. The common processing routine which has been written in the COMMON program can be called and executed as required from multiple programs. This enables efficient use of the programming space.

The sample COMMON program shown below contains two processing items (obtaining the distance between 2 points (SUB *DISTANCE), and obtaining the area (*AREA)) which are written as common routines, and these are called from separate programs (SAMPLE 1 and SAMPLE 2).

When SAMPLE1 or SAMPLE2 is executed, the SUB *DISTANCE (A!,B!,C!) and the *AREA routine are executed.

Sample	Description
<pre>X!=2.5 Y!=1.2 CALL *DISTANCE(X!,Y!,REF C!) GOSUB *AREA PRINT C!,Z! HALT</pre>	Program Name: SAMPLE1
<pre>X!=5.5 Y!=0.2 CALL *DISTANCE(X!,Y!,REF C!) GOSUB *AREA PRINT C!,Z! HALT</pre>	Program Name: SAMPLE2
<pre>SUB *DISTANCE(A!,B!,C!) C!=SQR(A!^2+B!^2) END SUB *AREA: Z!=X!*Y! RETURN</pre>	Program Name: COMMON Common Routine

Reference For details, refer to the command explanations given in this manual.

5

Identifiers

"Identifiers" are a combination of characters and numerals used for label names, variable names, and procedure names. Identifiers can be named as desired provided that the following conditions are satisfied:

- Identifiers must consist only of alphanumeric characters and underscores (_). Special symbols cannot be used, and the identifier must not begin with an underscore (_).
- The identifier length must not exceed 32 characters (all characters beyond the 32th character are ignored).
- The maximum number of usable identifiers varies depending on the length of the identifiers. When all identifier length is 32 characters, the number is at the maximum. Local variables can be used up to 128 (in one program task) and global variables can be used up to 512.
- Variable names must not be the same as a reserved word, or the same as a name defined as a system variable. Moreover, variable name character strings must begin with an alphabetic character. For label names, however, the "*" mark may be immediately followed by a numeric character.

Sample

```
LOOP, SUBROUTINE, GET_DATA
```

Reference

- Regarding reserved words, refer to Chapter 13 "1. Reserved word list",
- Regarding system variables, refer to Chapter 3 "9 System Variables".

6

LABEL Statement

Defines a *label* on a program line.

Format

```
*label:
```

A *label* must always begin with an asterisk (*), and it must be located at the beginning of the line.

Although a colon (:) is required at the end of the *label* when defining it, this mark is not required when writing a jump destination in a program.

- A *label* must begin with an alphabetic or numeric character.
- Alphanumeric and underscore (_) can be used as the remaining *label* characters. Special symbols cannot be used.
- The *label* must not exceed 32 characters (all characters beyond the 32th character are ignored).

Sample

Explanation

```
*ST:           ..... Defines*ST.
MOVE P,P0
DO(20) = 1
MOVE P,P1
DO(20) = 0
GOTO *ST      ..... Jumps to *ST.
HALT
```

Characters which follow REM or an apostrophe (!) are processed as a comment. Comment statements are not executed. Moreover, comments may begin at any point in the line.

Sample	Description
<pre>REM *** MAIN PROGRAM *** (Main Program) '*** SUBROUTINE *** (Subroutine) HALT 'HALT COMMAND</pre>	<pre>..... Comments may begin at any point in the line.</pre>

Format

label: *statement* *operand*

One robot language command must be written on a single line and arranged in the format shown below:

- The shaded section can be omitted.
- *The italic items* should be written in the specific format.
- Items surrounded by | | are selectable.
- The label can be omitted. When using a label, it must always be preceded by an asterisk (*), and it must end with a colon (:). (the colon is unnecessary when a label is written as a branching destination).

For details regarding labels, refer to "6 LABEL Statement" in this Chapter.

- Operands may be unnecessary for some commands.
 - Programs are executed in order from top to bottom unless a branching instruction is given.
- 1 line may contain no more than 255 characters.

Chapter 2

Constants

1	Outline	2-1
2	Numeric constants	2-1
3	Character constants	2-2

Constants can be divided into two main categories: "numeric types" and "character types". These categories are further divided as shown below.

Category	Type	Details/Range
Numeric type	Integer type	Decimal constants -2,147,483,648 to 2,147,483,647
		Binary constants &B0 to &B11111111
		Hexadecimal constants &H80000000 to &H7FFFFFFF
	Real type	Single-precision real numbers -999,999.9 to +999,999.9
		Exponential format single-precision real numbers -1.0×10^{38} to $+1.0 \times 10^{38}$
Character type	Character string	Alphabetic, numeric, special character, or katakana (Japanese) character string of 255 bytes or less.

2.1 Integer constants

- **Decimal constants**

Integers from -2,147,483,648 to 2,147,483,647 may be used.

- **Binary constants**

Unsigned binary numbers of 8 bits or less may be used. The prefix "&B" is attached to the number to define it as a binary number.

Range: &B0 (decimal: 0) to &B11111111 (decimal: 255)

- **Hexadecimal constants**

Signed hexadecimal numbers of 32 bits or less may be used. The prefix "&H" is attached to the number to define it as a hexadecimal number.

Range: &H80000000 (decimal: -2,147,483,648) to &H7FFFFFFF (decimal: 2,147,483,647)

2.2 Real constants

- **Single-precision real numbers**

Real numbers from -999999.9 to +999999.9 may be used.

7 digits including integers and decimals. (For example, ".0000001" may be used.)

- **Single-precision real numbers in exponent form**

Numbers from -1.0×10^{38} to $+1.0 \times 10^{38}$ may be used.

Mantissas should be 7 digits or less, including integers and decimals.

Sample

```
-1. 23456E-12
3. 14E0
1. E5
```

MEMO

An integer constant range of -1,073,741,824 to 1,073,741,823 is expressed in signed hexadecimal number as &H80000000 to &H7FFFFFFF.

Character type constants are character string data enclosed in double quotation marks ("). The character string must not exceed 255 bytes in length, and it may contain upper-case alphabetic characters, numerals, special characters, or katakana (Japanese) characters.

To include a double quotation mark (") in a string, enter two double quotation marks in succession.

Sample	Description
<pre>"YAMAHA ROBOT"</pre>	
<pre>"EXAMPLE OF" "A" " "</pre>	Represents EXAMPLE OF "A".
<pre>PRINT "COMPLETED"</pre>	
<pre>"YAMAHA ROBOT"</pre>	

Chapter 3

Variables


1	Outline	3-1
2	User Variables & System Variables.....	3-2
3	Variable Names.....	3-3
4	Variable Types	3-4
5	Array variables	3-5
6	Value Assignments	3-5
7	Type Conversions	3-6
8	Value Pass-Along & Reference Pass-Along....	3-6
9	System Variables	3-7
10	Bit Settings	3-17
11	Valid range of variables	3-18
12	Clearing variables.....	3-19

There are "user variables" which can be freely defined, and "system variables" which have pre-defined names and functions.

User variables consist of "dynamic variables" and "static variables". "Dynamic variables" are cleared at program editing, program resets, and program switching. "Static variables" are not cleared unless the memory is cleared. The names of dynamic variables can be freely defined, and array variables can also be used.

Variables can be used simply by specifying the variable name and type in the program. A declaration is not necessarily required. However, array variables must be pre-defined by a DIM statement.

User variables & system variables



33301-R9-00

Reference For details regarding array variables, refer to "5 Array variables" in this Chapter.

2.1 User Variables

Numeric type variables consist of an "integer type" and a "real type", and these two types have different usable numeric value ranges. Moreover, each of these types has different usable variables (character string variables, array variables, etc.), and different data ranges, as shown below.

Category	Variable Type	Details/Range
Dynamic variables	Numeric type	Integer type variables -2,147,483,648 to 2,147,483,647 (Signed hexadecimal constants: &H80000000 to &H7FFFFFFF)
		Real variables (single-precision) -1.0×10^{38} to $+1.0 \times 10^{38}$
	Character type	Character string variables Alphabetic, numeric, special character, or katakana (Japanese) character string of 255 bytes or less.
Static variables	Numeric type	Integer type variables -2,147,483,648 to 2,147,483,647
		Real variables (single-precision) -1.0×10^{38} to $+1.0 \times 10^{38}$
Array variables	Numeric type	Integer array variables -2,147,483,648 to 2,147,483,647
		Real array variables (single-precision) -1.0×10^{38} to $+1.0 \times 10^{38}$
	Character type	Character string array variables Alphabetic, numeric, special character, or katakana (Japanese) character string of 255 bytes or less.



NOTE

Array variables are dynamic variables.

2.2 System Variables

As shown below, system variables have pre-defined names which cannot be changed.

Category	Type	Details	Specific Examples
Input/output variables	Input variables	External signal / status inputs	DI, SI, SIW, SID
	Output variables	External signal / status outputs	DO, SO, SOW, SOD
Point variables		Handles point data	Pnnnn
Shift variables		Specifies the shift coordinate No. as a numeric constant or expression	Sn

Reference

For details, refer to "9 System Variables" in this Chapter.

3.1 Dynamic Variable Names

Dynamic variables can be named as desired, provided that the following conditions are satisfied:

- The name must consist only of alphanumeric characters and underscores (_). Special symbols cannot be used.
- The name must not exceed 32 characters (all characters beyond the 32th character are ignored).
- The name must begin with an alphabetic character.

Sample	Description
COUNT	✓ Use is permitted
COUNT123	✓ Use is permitted
2COUNT	- Use is NOT permitted

- Variable names must not be the same as a reserved word.
- Variable names must not begin with characters used for system variable names (pre-defined variables) and user-defined function. These characters include the following:
FN, DIn, DOn, MOn, LOn, TOn, SIn, SOn, Pn, Sn, Hn ("n" denotes a numeric value)

Sample	Description
COUNT	✓ Use is permitted
ABS	- Use is NOT permitted (Reserved word)
FNAME	- Use is NOT permitted (FN: user-defined function)
S91	- Use is NOT permitted (Sn: pre-defined variable)

Reference For details regarding reserved words, refer to Chapter 13 "1 Reserved word list".

3.2 Static Variable Names

Static variable names are determined as shown below, and these names cannot be changed.

Variable Type	Variable Name
Integer variable	SGIn (n: 0 to 31)
Real variable	SGRn (n: 0 to 31)

Static variables are cleared only when initializing is executed by online command.

Reference For details regarding clearing of static variables, refer to "12 Clearing variables" in this Chapter.

The type of variable is specified by the type declaration character attached at the end of the variable name. However, because the names of static variables are determined based on their type, no type declaration statement is required.

Type Declaration Character	Variable Type	Specific Examples
\$	Character variables	STR1\$
%	Integer variables	CONT0%, ACT%(1)
!	Real variables	CNT1!, CNT1

MEMO

- If no type declaration character is attached, the variable is viewed as a real type.
- Variables using the same identifier are recognized to be different from each other by the type of each variable.
 - ASP_DEF% Integer variable
 - ASP_DEF Real variable
 - ASP_DEF! Real variable
 - ASP_DEF Real variable
 → ASP_DEF% and ASP_DEF are different variables.
 → ASP_DEF! and ASP_DEF are the same variables.

4.1 Numeric variables

Integer variables

Integer variables and integer array elements can handle an integer from -2,147,483,648 to 2,147,483,647 (in signed hexadecimal, this range is expressed as &H80000000 to &H7FFFFFFF).

Sample

```
R1% = 10
R2%(2) = R1% + 10000
```



NOTE

When a real number is assigned to an integer type variable, the decimal value is rounded off to the nearest whole number. For details, refer to Chapter 4 "1.5 Data format conversion".

Real variables

Real variables and real array elements can handle a real number from -1.0×10^{38} to 1.0×10^{38} .

Sample

```
R1! = 10.31
R2!(2) = R1% + 1.98E3
```



NOTE

The "!" used in real variables may be omitted.

4.2 Character variables

Character variables and character array elements can handle a character string of up to 255 characters. Character strings may include alphabetic characters, numbers, symbols and katakana (Japanese phonetic characters).

Sample	Description
R1\$ = "YAMAHA" R2\$(2) = R1\$ + "MOTOR"	Returns "YAMAHA MOTOR"

Both numeric and character type arrays can be used at dynamic variables.

Using an array allows multiple same-type continuous data to be handled together.

Each of the array elements is referenced in accordance with the parenthesized subscript which appears after each variable name. Subscripts may include integers or *expressions* in up to 3 dimensions.

In order to use an array, Array variables must be declared by DIM statement in advance, and the maximum number of elements which can be used is the declared subscripts + 1 (0 ~ number of declared subscripts).

MEMO

- All array variables are dynamic variables. (For details regarding dynamic variables, refer to "11 Valid range of variables" in this Chapter.)
- The length of an array variable that can be declared with the DIM statement depends on the program size.

Format		
<i>variable name</i>	% ! \$	(<i>expression, expression, expression</i>)
Sample	Description	
A%(1)	Integer array variable	
DATA!(1,10,3)	Single-precision real array variable (3-dimension array)	
STRING\$(10)	Character array variable	

An assignment statement (LET) can also be used to assign a value to a variable.

MEMO

"LET" directly specifies an assignment statement, and it can always be omitted.

Format
LET <i>variable</i> = <i>expression</i>

Write the value assignment target variable on the left side, and write the assignment value or the *expression* on the right side. The *expression* may be a constant, a variable, or an arithmetic expression, etc.

Reference For details, refer to Chapter 8 "54 LET (Assignment Statement)"

When different-type values are assigned to variables, the data type is converted as described below.

- When a real number is assigned to an integer type:
The decimal value is rounded off to the nearest whole number.
- When an integer is assigned to a real type:
The integer is assigned as it is, and is handled as a real number.
- When a numeric value is assigned to a character string type:
The numeric value is automatically converted to a character string.
- When a character string is assigned to numeric type:
This assignment is not possible, and an error will occur at the program is execution. Use the "VAL" command to convert the character string to a numeric value, and that value is then assigned.

A variable can be passed along when a sub-procedure is called by a CALL statement. This pass-along can occur in either of two ways: as a value pass-along, or as a reference pass-along.

Value pass-along

With this method, the variable's value is passed along to the sub-procedure. Even if this value is changed within the sub-procedure, **the content of the call source variable is not changed.**

A value pass-along occurs when the CALL statement's actual argument specifies a constant, an expression, a variable, or an array element (array name followed by (*subscript*)).

Reference pass-along

With this method, the variable's reference (address in memory) is passed along to the sub-procedure. If this value is changed within the sub-procedure, **the content of the call source variable is also changed.**

A reference pass-along occurs when the CALL statement's actual argument specifies an entire array (an array named followed by parenthetical content), or when the actual argument is preceded by "REF".

Value pass-along & reference pass-along

Value pass-along

```
X%=5
CALL *TEST( X% )
PRINT X%
HALT
' SUB ROUTINE
SUB *TEST( A% )
  A%=A%*10
END SUB
```

Execution result: The X% value remains as "5".

Reference pass-along

```
X%=5
CALL *TEST( REF X% )
PRINT X%
HALT
' SUB ROUTINE
SUB *TEST( A% )
  A%=A%*10
END SUB
```

Execution result: The X% value becomes "50".

The following system variables are pre-defined, and other variable names must not begin with the characters used for these system variable names.

Variable Type	Format	Meaning
Point variable	Pnnn / P [<i>expression</i>]	Specifies a point number
Shift variable	Sn / S [<i>expression</i>]	Specifies the shift number as a constant or as an expression
Parallel input variable	DI(mb), DI(m)b	Parallel input signal status
Parallel output variable	DO(mb), DO(m)b	Parallel output signal setting and status
Internal output variable	MO(mb), MO(m)b	Controller's internal output signal setting and status
Arm lock output variable	LO(mb), LO(m)b	Axis-specific movement prohibit
Timer output variable	TO(mb), TO(m)b	For sequence program's timer function
Serial input variable	SI(mb), SI(m)b	Serial input signal status
Serial output variable	SO(mb), SO(m)b	Serial output signal setting and status
Serial word input	SIW(m)	Serial input's word information status
Serial double-word input	SID(m)	Serial input's double-word information status
Serial word output	SOW(m)	Serial output's word information status
Serial double-word output	SOD(m)	Serial output's double-word information status

9.1 Point variable

This variable specifies a point data number with a numeric constant or expression.

Format

Pnnnnn or P [*expression*]

Notation

Value

Range

n

Point number

0 to 9

Functions A point data number is expressed with a "P" followed by a number of 5 digits or less, or an *expression* surrounded by brackets ([*expression*])

Point numbers from 0 to 29999 can be specified with point variables.

Sample

```
P0
P110
P [A]
P [START_POINT]
P [A(10)]
```

9.2 Shift variable

This variable specifies a shift coordinate number with a numeric constant or expression.

Format

`Snn` or `S[expression]`

Notation	Value	Range
<code>n</code>	Shift number	0 to 9

Functions A shift number is expressed with an "S" followed by a 2-digit number or an *expression* surrounded by brackets (*expression*). As a shift number, 0 to 39 can be specified.

Sample

```
S1
S[A]
S[BASE]
S[A(10)]
```

MEMO

The "shift coordinate range" for each shift number can be changed from the programming box.

9.3 Parallel input variable

This variable is used to indicate the status of parallel input signals.

Format 1

`DIm(b, ..., b)`

Format 2

`DI(mb, ..., mb)`

Notation	Value	Range
<code>m</code>	port number	0 to 7, 10 to 17, 20 to 27
<code>b</code>	bit definition	0 to 7

If the bit definition is omitted in Format 1, bits 0 to 7 are all selected.

Sample	Description
<code>A%=DI1()</code>	Input status of ports DI(17) to DI(10) is assigned to variable A%. 0 to 255 integer can be assigned to A%.
<code>A%=DI5(7,4,0)</code>	Input status of DI(57), DI(54) and DI(50) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
<code>A%=DI(27,15,10)</code>	Input status of DI(27), DI(15) and DI(10) is assigned to variable A%. (If all above signals except DI(10) are 1(ON), then A%=6.)
<code>WAIT DI(21)=1</code>	Waits for DI(21) to change to 1(ON).

MEMO

- When specifying multiple bits, specify them from left to right in descending order (high to low).
- A "0" is input if an input port does not actually exist.

9.4 Parallel output variable

Specifies the parallel output signal or indicates the output status.

Format 1

DOm(b, . . . , b)

Format 2

DO(mb, . . . , mb)

Notation	Value	Range
m	port number	0 to 7, 10 to 17, 20 to 27
b	bit definition	0 to 7

If the bit definition is omitted in Format 1, bits 0 to 7 are all selected.

Sample	Description
A%=DO2()	Output status of DO(27) to DO(20) is assigned to variable A%.
A%=DO5(7,4,0)	Output status of DO(57), DO(54) and DO(50) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
A%=DO(37,25,20)	Output status of DO(37), DO(25) and DO(20) is assigned to variable A%. (If all above signals except DO(20) are 1 (ON), then A%=6.)
DO3()=B%	Changes to a status in which the DO(37) to DO(30) output can be indicated by B%. Example) B% is "123": "123" is represented as "01111011" in binary number, DO(37) and DO(32) is "0", and the other bits is "1".
DO4(5,4,0)=&B101	DO(45) and DO(40) become "1", and DO(44) becomes "0".

MEMO

- When specifying multiple bits, specify them from left to right in descending order (high to low).
- If an output port does not actually exist, the data is not output externally.

9.5 Internal output variable

Specifies the controller's internal output signals and indicates the signal status.

Format 1

MOm (b, . . . , b)

Format 2

MO (mb, . . . , mb)

Notation	Value	Range	Notation	Value	Range
m	port number	0 to 7, 10 to 17, 20 to 27, 30 to 37	b	bit definition	0 to 7

If the bit definition is omitted in Format 1, bits 0 to 7 are all selected.

Functions

Internal output variables which are used only in the controller, can set the status and refer.

These variables are used for signal communications, etc., with the sequence program.

Ports 30 to 37 are for dedicated internal output variables which can only be referenced (they cannot be changed).

1. Port 30 indicates the status of origin sensors for axes 1 to 8 (in order from bit 0). Port 31 indicates the status of origin sensors for axes 9 to 16 (in order from bit 0).

Each bit sets to "1" when the origin sensor turns ON, and to "0" when OFF.

2. Port 34 indicates the HOLD status of axes 1 to 8 (in order from bit 0). Port 35 indicates the HOLD status of axes 9 to 16 (in order from bit 0).

Each bit sets to "1" when the axis is in HOLD status, and to "0" when not.

Bit	7	6	5	4	3	2	1	0
Port 30	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1
Port 31	Axis 16	Axis 15	Axis 14	Axis 13	Axis 12	Axis 11	Axis 10	Axis 9
Origin sensor status 0: OFF / 1: ON (Axis 1 is not connected)								
Port 34	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1
Port 35	Axis 16	Axis 15	Axis 14	Axis 13	Axis 12	Axis 11	Axis 10	Axis 9
Hold status 0: RELEASE / 1: HOLD (Axis 1 is not connected)								

MEMO

- Axes where no origin sensor is connected are always ON.
- Being in HOLD status means that the axis movement is stopped and positioned within the target point tolerance while the servo is still turned ON.
- When the servo turns OFF, the HOLD status is released.
- Axes not being used are set to "1" (HOLD).
- The status of each axis in order from the smallest axis number used by robot 1 is maintained.
Example) In the case of a configuration where robot 1 has 5 axes and robot 2 has 4 axes, bits 0 to 4 of port 30 indicate the status of axes 1 to 5 of robot 1, bits 5 to 7 of port 30 indicate the status of axes 1 to 3 of robot 2, and bit 0 of port 31 indicates the status of axis 4 of robot 2.

Sample	Description
A%=MO2 ()	Internal output status of MO(27) to MO(20) is assigned to variable A%.
A%=MO5 (7,4,0)	Internal output status of MO(57), MO(54) and MO(50) is assigned to variable A%. (If all above signals are 1 (ON), then A%=7.)
A%=MO (37,25,20)	Internal output status of MO(37), MO(25) and MO(20) is assigned to variable A%. (If all above signals except MO(25) are 1 (ON), then A%=5.)

MEMO

When specifying multiple bits, specify them from left to right in descending order (high to low).

9.6 Arm lock output variable

Specifies axis-specific movement prohibit settings.

Format 1

LOm(b, ..., b)

Format 2

LO(mb, ..., mb)

Notation	Value	Range
m	port number	0, 1
b	bit definition	0 to 7

If the bit definition is omitted in Format 1, bits 0 to 7 are all selected.

Functions

The contents of this variable can be set the status and referred to as needed.

Of Port 0, bits 0 to 7 respectively correspond to axes 1 to 8, and of port 1, bits 0 to respectively correspond to axes 9 to 16.

When this bit is ON, movement on the corresponding axis is prohibited.

Sample	Description
A%=LO0()	Arm lock status of LO(07) to LO(00) is assigned to variable A%.
A%=LO0(7,4,0)	Arm lock status of LO(07), LO(04) and LO(00) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
A%=LO(06,04,01)	Arm lock status of LO(06), LO(04) and LO(01) is assigned to variable A%. (If all above signals except LO(01) are 1(ON), then A%=6.)
LO1()=&B0010	LO(11) is set to 1(ON), then movement of axis 10 is prohibited.
LO1(2,0)=3	LO(12) and LO(10) are set to 1(ON), then movements of axes 11 and 9 are prohibited.

MEMO

- When specifying multiple bits, specify them from left to right in descending order (high to low).
- Servo OFF to ON switching is disabled if an arm lock is in effect at even 1 axis.
- When performing JOG movement in the MANUAL mode, axis movement is possible at axes where an arm lock status is not in effect, even if an arm lock status is in effect at another axis.
- When executing movement commands from the program, etc., the "12.401 Arm locked" error will occur if an arm lock status is in effect at the axis in question.
- Arm locks sequentially correspond to axes in order from the axis with the smallest axis number used by robot 1.

Example) In the case of a configuration where robot 1 has 5 axes and robot 2 has 4 axes, the status of axes 1 to 5 of robot 1 is set by bits 0 to 4 of port 0, the status of axes 1 to 3 of robot 2 is set by bits 5 to 7 of port 0, and the prohibition of motion of axis 4 of robot 2 is set by bit 0 of port 1.

9.7 Timer output variable

This variable is used in the timer function of a sequence program.

Format 1

TOm (b, . . . , b)

Format 2

TO (mb, . . . , mb)

Notation	Value	Range
m	port number	0, 1
b	bit definition	0 to 7

If the bit definition is omitted in Format 1, bits 0 to 7 are all selected.

Functions The contents of this variable can be changed and referred to as needed.
Timer function can be used only in the sequence program.
If this variable is output in a normal program, it is an internal output.

Reference For details regarding sequence program usage examples, refer to the timer usage examples given in "4.2 Input/output variables" in Chapter 7.

Sample	Description
A%=TO0 ()	Status of TO(07) to TO(00) is assigned to variable A%.
A%=TO0 (7,4,0)	Status of TO(07), TO(04) and TO(00) is assigned to variable A%. (If all above signals are 1 (ON), then A%=7.)
A%=TO (06,04,01)	Status of TO(06), TO(04) and TO(01) is assigned to variable A%. (If all above signals except TO(01) are 1 (ON), then A%=6.)

MEMO

When specifying multiple bits, specify them from left to right in descending order (high to low).

9.8 Serial input variable

This variable is used to indicate the status of serial input signals.

Format 1

`SIm(b, ..., b)`

Format 2

`SI(mb, ..., mb)`

Notation	Value	Range
m	port number	0 to 7, 10 to 17, 20 to 27
b	bit definition	0 to 7

If the bit definition is omitted in Format 1, bits 0 to 7 are all selected.

Sample	Description
<code>A%=SI1()</code>	Input status of ports SI(17) to SI(10) is assigned to variable A%.
<code>A%=SI5(7,4,0)</code>	Input status of SI(57), SI(54) and SI(50) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
<code>A%=SI(27,15,10)</code>	Input status of SI(27), SI(15) and SI(10) is assigned to variable A%. (If all above signals except SI(10) are 1 (ON), then A%=6.)
<code>WAIT SI(21)=1</code>	Waits until SI(21) sets to 1 (ON).

MEMO

- When specifying multiple bits, specify them from left to right in descending order (high to low).
- A "0" is input if a serial port does not actually exist.

9.9 Serial output variable

This variable is used to define the serial output signals and indicate the output status.

Format 1

S0m (b, ..., b)

Format 2

SO (mb, ..., mb)

Notation	Value	Range
m	port number	0 to 7, 10 to 17, 20 to 27
b	bit definition	0 to 7

If the bit definition is omitted in Format 1, bits 0 to 7 are all selected.

Sample	Description
A%=S02 ()	Output status of SO(27) to SO(20) is assigned to variable A%.
A%=S05 (7,4,0)	Output status of SO(57), SO(54) and SO(50) is assigned to variable A%. (If all above signals turn 1(ON), then A%=7.)
A%=SO (37,25,20)	Output status of SO(37), SO(25) and SO(20) is assigned to variable A%. (If all above signals except SO(25) turn 1(ON), then A%=5.)
SO3 ()=B%	Changes the output status of SO(37) to SO(30) to one indicated by B%. (If B% is 123, 123 is expressed B01111011 as a binary number, that means SO(37) and SO(32) turn 0(OFF), the other bits turn 1(ON).)
SO4 (5,4,0) =&B101	DO(45) and DO(40) turn 1(ON), DO(44) turns 0(OFF).

MEMO

- When specifying multiple bits, specify them from left to right in descending order (high to low).
- If a serial port does not actually exist, the data is not output externally.

9.10 Serial word input

This variable indicates the status of the serial input word information.

Format		
SIW (m)		
Notation	Value	Range
m	port number	2 to 15*
The acquisition range is 0 (&H0000) to 65,535 (&HFFFF).		
*When SLOW extension is enabled, the range of port number is extended to 2 -15, 24 - 127. For details, refer to RCX3 user's manual "Option board related parameters".		
Sample	Description	
A%=SIW(2)	The input status from SIW (2) is assigned to variable A%.	
A%=SIW(15)	The input status from SIW (15) is assigned to variable A%.	

MEMO

- The information is handled as unsigned word data.
- "0" is input if a serial port does not actually exist.

9.11 Serial double word input

This variable indicates the state of the serial input word information as a double word.

Format		
SID (m)		
Notation	Value	Range
m	port number	2, 4, 6, 8, 10, 12, 14*
The acquisition range is -2,147,483,648(&H80000000) to 2,147,483,647(&H7FFFFFFF).		
*When SLOW extension is enabled, the range of port number is extended to 2, 4, 6 -14, 24, 26, 28 -126. For details, refer to RCX3 user's manual "Option board related parameters".		
Sample	Description	
A%=SID(2)	The input status from SIW (2) , SIW (3) is assigned to variable A%.	
A%=SID(14)	The input status from SIW (14), SIW (15) is assigned to variable A%.	

MEMO

- The information is handled as signed double word data.
- "0" is input if a serial port does not actually exist.
- The lower port number data is placed at the lower address.
For example, if SIW(2) =&H2345, SIW(3) =&H0001, then SID(2) =&H00012345.

9.12 Serial word output

Outputs to the serial output word information or indicates the output status.

Format		
SOW (m)		
Notation	Value	Range
m	port number	2 to 15*

The output range is 0 (&H0000) to 65,535 (&HFFFF).

Note that if a negative value is output, the low-order word information will be output after being converted to hexadecimal.

*When SLOW extension is enabled, the range of port number is extended to 2 -15, 24 - 127. For details, refer to RCX3 user's manual "Option board related parameters".

Sample	Description
A%=SOW(2)	The output status of SOW (2) is assigned to variable A%.
SOW(15)=A%	The contents of variable A% are assigned in SOW (15). If the variable A% value exceeds the output range, the low-order word information will be assigned.
SOW(15)=-255	The contents of -255 (&HFFFFFF01) are assigned to SOW (15). -255 is a negative value, so the low-order word information (&HFF01) will be assigned.

MEMO

- The information is handled as unsigned word data.
- If a serial port does not actually exist, the data is not output externally.
- If a value exceeding the output range is assigned, the low-order 2-byte information is output.

9.13 Serial double word output

Output the status of serial output word information in a double word, or indicates the output status.

Format		
SOD (m)		
Notation	Value	Range
m	port number	2, 4, 6, 8, 10, 12, 14*

The output range is -2,147,483,648(&H80000000) to 2,147,483,647(&H7FFFFFFF).

*When SLOW extension is enabled, the range of port number is extended to 2, 4, 6 -14, 24, 26, 28 -126. For details, refer to RCX3 user's manual "Option board related parameters".

Sample	Description
A%=SOD(2)	The output status of SOD (2) is assigned to variable A%.
SOD(14)=A%	The contents of variable A% are assigned in SOD (14).

MEMO

- The information is handled as signed double word data.
- If a serial port does not actually exist, the data is not output externally.
- The lower port number data is placed at the lower address.
For example, if SOW(2) =&H2345, SOW(3) =&H0001, then SOD(2) =&H00012345.

Bits can be specified for input/output variables by any of the following methods.

1. Single bit

To specify only 1 of the bits, the target port number and bit number are specified in parentheses. The port number may also be specified outside the parentheses.

Programming example: DOm(b)DOm(b)

Sample	Description
DO (25)	Specifies bit 5 of port 2.
DO2 (5)	

2. Same-port multiple bits

To specify multiple bits at the same port, those bit numbers are specified in parentheses (separated by commas) following the port number.

The port number may also be specified in parentheses.

Programming example: DOm(b,b,...,b) DO(mb,mb,...,mb)

Sample	Description
DO2 (7, 5, 3)	Specifies DO(27), DO(25), DO(23)
DO (27, 25, 23)	

3. Different-port multiple bits

To specify multiple bits at different ports, 2-digit consisting of the port number and the bit number must be specified in parentheses and must be separated by commas. Up to 8 bits can be written.

Programming example: DO(mb,mb,...,mb)

Sample	Description
DO (37, 25, 20)	Specifies DO(37), DO(25), DO(20).

4. All bits of 1 port

To specify all bits of a single port, use parentheses after the port number. Methods 2 and 3 shown above can also be used.

Programming example: DOm()

Sample	Description
DO2 ()	Specifies all the DO(27) to DO(20) bits
DO (27, 26, 25, 24, 23, 22, 21, 20)	
DO2 (7, 6, 5, 4, 3, 2, 1, 0)	

11 Valid range of variables

11.1 Valid range of dynamic (array) variables

Dynamic (array) variables are divided into global variables and local variables, according to their declaration position in the program. Global and local variables have different valid ranges.

Variable Type	Explanation
Global variables	Variables are declared outside of sub-procedures (outside of program areas enclosed by a SUB statement and END SUB statement). These variables are valid throughout the entire program.
Local variables	Variables are declared within sub-procedures and are valid only in these sub-procedures.

MEMO

- For details regarding arrays, refer to Chapter 3 "5 Array variables".
- A variable declared at the program level can be referenced from a sub-procedure without being passed along as a dummy argument, by using the SHARED statement (for details, refer to Chapter 8 "111 SHARED").

11.2 Valid range of static variables

Static variable data is not cleared when a program reset occurs. Moreover, variable data can be changed and referenced from any program.

The variable names are determined as shown below (they cannot be named as desired).

Variable type	Variable name
Integer variable	SGIn (n: 0 to 31)
Real variable	SGRn (n: 0 to 31)

12.1 Clearing dynamic variables

In the cases below, numeric variables are cleared to zero, and character variables are cleared to a null string. The array is cleared in the same manner.

- When a program reset occurs.
- When dedicated input signal DI15 (program reset input) was turned on while the program was stopped in AUTO mode.
- When either of the following is initialized by an initialization operation.
 1. Program memory
 2. Entire memory
- When any of the following online commands was executed.
@RESET, @INIT PGM, @INIT MEM, @INIT ALL
- When the HALTALL statement was executed in the program (HALT statement does not clear dynamic variables).

12.2 Clearing static variables

In the cases below, integer variables and real variables are cleared to zero.

- When the following is initialized by an initialization operation.
Entire memory
- When any of the following online commands was executed.
@INIT MEM, @INIT ALL

Chapter 4

Expressions and Operations

1	Arithmetic operations	4-1
2	Character string operations	4-4
3	Point data format.....	4-5
4	DI/DO conditional expressions	4-6

1.1 Arithmetic operators

Operators	Usage Example	Meaning
+	A+B	Adds A to B
-	A-B	Subtracts B from A
*	A*B	Multiplies A by B
/	A/B	Divides A by B
^	A^B	Obtains the B exponent of A (exponent operation)
-	-A	Reverses the sign of A
MOD	A MOD B	Obtains the remainder A divided by B

When a "remainder" (MOD) operation involves real numbers, **the decimal value is rounded off to the nearest whole number which is then converted to an integer** before the calculation is executed. The result represents the remainder of an integer division operation.

Sample	Results
A=15 MOD 2	A=1 (15/2=7...1)
A=17.34 MOD 5.98	A=2 (17/5=3...2)

1.2 Relational operators

Relational operators are used to compare 2 values. If the result is "true", a "-1" is obtained. If it is "false", a "0" is obtained.

Operators	Usage Example	Meaning
=	A=B	"-1" if A and B are equal, "0" if not.
<>, ><	A<>B	"-1" if A and B are unequal, "0" if not.
<	A<B	"-1" if A is smaller than B, "0" if not.
>	A>B	"-1" if A is larger than B, "0" if not.
<=, =<	A<=B	"-1" if A is equal to or smaller than B, "0" if not.
>=, =>	A>=B	"-1" if A is equal to or larger than B, "0" if not.

Sample	Results
A=10>5	Since 10 > 5 is "true", A = -1.

MEMO

When using equivalence relational operators with real variables and real arrays, the desired result may not be obtained due to the round-off error.

Sample	Description
A=2 B=SQR(A!) IF A!=B!*B! THEN...	In this case, A! will be unequal to B!*B!.

1.3 Logic operations

Logic operators are used to manipulate 1 or 2 values bit by bit. For example, the status of an I/O port can be manipulated.

- Depending on the logic operation performed, the results generated are either 0 or 1.
- Logic operations with real numbers convert the values into integers before they are executed.

Operators	Functions	Meaning
NOT, ~	Logical NOT	Reverses the bits.
AND, &	Logical AND	Becomes "1" when both bits are "1".
OR,	Logical OR	Becomes "1" when either of the bits is "1".
XOR	Exclusive OR	Becomes "1" when both bits are different.
EQV	Logical equivalence operator	Becomes "1" when both bits are equal.
IMP	Logical implication operator	Becomes "0" when the first bit is "1" and the second bit is "0".

Examples: $A\% = \text{NOT } 13.05 \rightarrow \text{"-14"}$ is assigned to A% (reversed after being rounded off to 13).

Bit	7	6	5	4	3	2	1	0
13	0	0	0	0	1	1	0	1
NOT 13=-14	1	1	1	1	0	0	1	0

Examples: $A\% = 3 \text{ AND } 10 \rightarrow \text{"2"}$ is assigned to A%

Bit	7	6	5	4	3	2	1	0
3	0	0	0	0	0	0	1	1
10	0	0	0	0	1	0	1	0
3 AND 10 = 2	0	0	0	0	0	0	1	0

Examples: $A\% = 3 \text{ OR } 10 \rightarrow \text{"11"}$ is assigned to A%

Bit	7	6	5	4	3	2	1	0
3	0	0	0	0	0	0	1	1
10	0	0	0	0	1	0	1	0
3 OR 10 = 11	0	0	0	0	1	0	1	1

Examples: $A\% = 3 \text{ XOR } 10 \rightarrow \text{"9"}$ is assigned to A%

Bit	7	6	5	4	3	2	1	0
3	0	0	0	0	0	0	1	1
10	0	0	0	0	1	0	1	0
3 XOR 10 = 9	0	0	0	0	1	0	0	1

1.4 Priority of arithmetic operation

Operations are performed in the following order of priority. When two operations of equal priority appear in the same statement, the operations are executed in order from left to right.

Priority Rank	Arithmetic Operation
1	Expressions included in parentheses
2	Functions, variables
3	^ (exponents)
4	Independent "+" and "-" signs (Monomial operators)
5	* (Multiplication), / (Division)
6	MOD
7	+ (Addition), - (Subtraction)
8	Relational operators
9	NOT, ~ (Logical NOT)
10	AND, & (Logical AND)
11	OR, , XOR (Logical OR, exclusive OR)
12	EQV (Logical equivalence)
13	IMP (Logical implication)

1.5 Data format conversion

Data format is converted in cases where two values of different formats are involved in the same operation.

When a real number is assigned to an integer, decimal places are rounded off.

Sample	Results
A%=125.67	A%=126

When integers and real numbers are involved in the same operation, the result becomes a real number.

Sample	Results
A(0)=125 * 0.25	A(0)=31.25

When an integer is divided by an integer, the result is an integer with the remainder discarded.

Sample	Results
A(0)=100/3	A(0)=33

2.1 Character string connection

Character strings may be combined by using the "+" sign.

Sample	Results
A\$="YAMAHA"	
B\$="ROBOT"	
C\$="LANGUAGE"	
D\$="MOUNTER"	YAMAHA ROBOT LANGUAGE
E\$=A\$+" "+B\$+" "+C\$	YAMAHA MOUNTER
F\$=A\$+" "+D\$	
PRINT E\$	
PRINT F\$	

2.2 Character string comparison

Characters can be compared with the same relational operators as used for numeric values. Character string comparison can be used to find out the contents of character strings, or to sort character strings into alphabetical order.

- In the case of character strings, the comparison is performed from the beginning of each string, character by character.
- If all characters match in both strings, they are considered to be equal.
- Even if only one character in the string differs from its corresponding character in the other string, then the string with the larger (higher) character code is treated as the larger string.
- When the character string lengths differ, the longer of the character strings is judged to be the greater value string.

Sample	Results
"AA"<"AB"	
"X&">"X#"	All examples are "true".
"DESK"<"DESKS"	

3 Point data format

There are two types of point data formats: joint coordinate format and Cartesian coordinate format. Point numbers are in the range of 0 to 29999.

Coordinate Format	Data Format	Explanation
Joint coordinate format	± nnnnnnn	This is a decimal integer constant of 8 digits or less with a plus or minus sign, and can be specified from -99999999 to 99999999. Unit: [pulses]
Cartesian coordinate format	± nnn.nn to ± nnnnnnn	This is a decimal fraction of a total of 7 digits including 3 or less decimal places. Unit: [mm] or [degrees]



NOTE

- The data format is common for axes 1 to 6 for both the joint coordinate format and the Cartesian coordinate format.
- Plus (+) signs can be omitted.
- The first arm and the second arm rotation information is not available on any robot model except the YK-TW series.

When setting an extended hand system flag for SCARA robots, set either "1" or "2" at the end of the data. If a value other than "1" or "2" is set, or if no value is designated, "0" will be set to indicate that no hand system flag is set.

Hand System	Data Value
RIGHTY (right-handed system)	1
LEFTY (left-handed system)	2

On the YK-TW series robot, the first arm and the second arm movement range is extended beyond 360 degrees (The working envelope for both the first arm and second arm is -225° to +225°).

Therefore, attempts to convert Cartesian coordinate data ("mm" units) to joint coordinate data ("pulse" units) will result in multiple solutions, making the position impossible to determine.

In order to obtain the correct robot position and arm posture when converting to joint coordinates, the first arm and the second arm rotation information is added after the "mm" units point data's extended hand system flag.

The Cartesian coordinate data ("mm" units) is then converted to joint coordinate data ("pulse" units) according to the specified the first arm and the second arm rotation information.

To set extended the first arm and the second arm rotation information at the YK-TW series robot, a "-1", "0", or "1" value must be specified after the hand system flag. Any other value, or no value, will be processed as "0".

Arm rotation information	Data Value
"mm" → pulse converted angle data x (*1) range: -180° < x <= 180°	0
"mm" → pulse converted angle data x (*1) range: 180° < x <= 540°	1
"mm" → pulse converted angle data x (*1) range: -540° < x <= -180°	-1

*1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.

DI/DO conditional expressions may be used to set conditions for WAIT statements and STOPON options in MOVE statements.

Numeric constants, variables and arithmetic operators that may be used with DI/DO conditional expressions are shown below.

- Constant
Decimal integer constant, binary integer constant, hexadecimal integer constant
- Variables
Global integer type, global real type, input/output type
- Operators
Relational operators, logic operators
- Operation priority
 1. Relational operators
 2. NOT, ~
 3. AND, &
 4. OR, |, XOR

Sample	Description
WAIT DI(31)=1 OR DI(34)=1	The program waits until either DI31 or DI34 turns ON.

Chapter 5

Multiple Robot Control

1	Overview	5-1
2	Command list with a robot setting.....	5-2

RCX340/RCX320 can be used to control multiple robots (up to 4).

The multi-task function also enables multiple robots to move asynchronously.

To use this function, settings for multiple robots or settings for auxiliary axes must be made in the system prior to shipment.

The following settings are possible to the axes of robots.


- Robot 1 (4 axes)
- Robot 1 (1 axis) + robot 2 (1 axis) + robot 3 (1 axis) + robot 4 (1 axis)
- Robot 1 (6 axes) + robot 2 (2 axes) (when using the YC-LINK/E option)
- Robot 1 (4 axes) + robot 2 (4 axes) (when using the YC-LINK/E option)
- Robot 1 (2 axes) + robot 2 (2 axes)
- Robot 1 (4 axes) + robot 2 (4 axes) + robot 3 (4 axes) + robot 4 (4 axes)
(when a master controller is RCX340 and the YC-LINK/E option is used.)
- Robot 1 (2 axes) + robot 2 (4 axes) + robot 3 (4 axes) + robot 4 (4 axes)
(when a master controller is RCX320 and the YC-LINK/E option is used.)

Each robot consists of normal axes and auxiliary axes.


When using one robot without auxiliary axes, the setting is made only to normal axes.

Axes configuration


1. For robot 1




2. For robot 1 and robot 2



3. For 1 robot with no auxiliary axes used



4. When no auxiliary axes are set to two robots



The special commands and functions for robot movements and coordinate control are common for all robots. A robot can be specified with an option of a command. Main commands are shown below.

Operator	Command name	
Robot movement	DRIVE MOVE MOVET PMOVE WAIT ARM	DRIVEI MOVEI PATH SERVO
Coordinate control	CHANGE HAND PATH SHIFT	CHGWRK LEFTY RIGHTY WRKDEF
Status change	ACCEL ARCHP2 ARMTYP AXWGHT DECEL MSPEED OUTPOS SPEED WEIGHT	ARCHP1 ARMSEL ASPEED CONTPLS INROFST ORGORD SCRINR TOLE WEIGHTG
Point operation	CORRECTXY WHERE XYTOJ	JTOXY WHRXY
Parameter reference	ACCEL ARCHP2 AXWGHT DECEL ORGORD SCRINR WEIGHT	ARCHP1 ARMTYP CONTPLS INROFST OUTPOS TOLE WEIGHTG
Status reference	ABSRPOS ARMSEL CORRECTXY CURTRQ WHERE	ARMCND ARMTYP CURTQST MCHREF WHRXY
Torque control	CURTRQ TRQSTS	TORQUE TRQTIME

- An axis specified as an auxiliary axis cannot be moved with the MOVE, MOVEI, MOVET and PMOVE commands. Use the DRIVE or DRIVEI command to move it.

Chapter 6

Multi-tasking

1	Outline	6-1
2	Task definition method.....	6-1
3	Task status and transition	6-2
4	Multi-task program example	6-8
5	Sharing the data	6-9
6	Cautionary Items	6-9

The multi-task function performs multiple processing simultaneously in a parallel manner, and can be used to create programs of higher complexity. Before using the multi-task function, read this section thoroughly and make sure that you fully understand its contents.

Multi-tasking allows executing two or more tasks in parallel. However, this does not mean that multiple tasks are executed simultaneously because the controller has only one CPU to execute the tasks. In multi-tasking, the CPU time is shared among multiple tasks by assigning a priority to each task so that they can be executed efficiently.

- A maximum of 16 tasks (task 1 to task 16) can be executed in one program.
- Tasks can be prioritized and executed in their priority order (higher priority tasks are executed first).
- The priority level can be set to any level between 1 and 64.
- Smaller values have higher priority, and larger values have lower priority (High priority: 1 ↔ 64: low priority).

A task is a set of instructions which are executed as a single sequence. As explained below, a task is defined by assigning a label to it.


- Create one program that describes a command which is to be defined as a task.
- In the START statement of the program that will be a main task, specify the program created at Step 1 above. Task numbers are then assigned, and the program starts.

Sample	Description
<pre>' MAIN TASK(TASK1) START <SUB_PGM>,T2..... *ST1: MOVE P,P1,P0 IF DO(20)= 1 THEN HALTALL ENDIF GOTO *ST HALTALL</pre>	<p><SUB_PGM> is started as Task 2</p>
<pre>' SUB TASK(TASK2) *IOTASK:..... IF DI(21)=1 THEN DO(30)=1 ELSE DO(30)=0 ENDIF GOTO *IOTASK EXIT TASK</pre>	<p>Program name:SUB_TSK2</p> <p>Task 2 begins here</p> <p>Task 2 processing ends here</p>

There are 6 types of task status.

- **STOP status** A task is present but the task processing is stopped.
- **RUN status** A task is present and the task processing is being executed by the CPU.
- **READY status** A task is present and ready to be allocated to the CPU for task processing.
- **WAIT status** A task is present and waiting for an event to begin the task processing.
- **SUSPEND status** A task is present but suspended while waiting to begin the task processing.
- **NON EXISTENT status** No tasks exist in the program. (The START command is used to perform a call.)

Task state transition



MEMO

Use REFTSK function to acquire the current task status.

Reference

For details regarding REFTSK function, refer to Chapter 8 "101 REFTSK".

3.1 Starting tasks

When the START command is executed, a specified program is registered in the task and placed in RUN status. If the task number (1 to 16) is not specified by the START command, the task with the smallest number among the tasks yet to be started is automatically specified.

Reference

For details regarding the START command, refer to "123 START" in Chapter 8.

MEMO

- When the LOAD command is executed, a specified program is registered in the task and placed in a STOP status. For details of the LOAD command, refer to "1. Register task" of "2.1 Program operations" in Chapter 12.
- If another program is already registered in the task number specified by the START command or the LOAD command, the "6.215: Task running" error will occur.
- When programs are registered in all task numbers and the START command or the LOAD command is executed without specifying the task number, the "6.263: Too many Tasks" error will occur.
- When the HALTALL command is executed, all tasks terminate and the task enters the NON EXISTENT (no task registration) status. When the main program is specified, the HALTALL command registers the main program in the task 1 and stops at the beginning line. When the main program is not specified, the HALTALL command registers the program that has been executed last (current program) in the task 1 and stops at the beginning line.

Reference

For details regarding the main program, refer to "Setting the main program" of RCX3 user's manual.


3.2 Task scheduling

Task scheduling determines the priority to be used in allocating tasks in the READY (execution enabled) status to the CPU and executing them.

When there are two or more tasks which are put in the READY status, ready queues for CPU allocation are used to determine the priority for executing the tasks. One of these READY status tasks is then selected and executed (RUN status).

Only tasks with the same priority ranking are assigned to a given ready queue. Therefore, where several tasks with differing priority rankings exist, a corresponding number of ready queues are created. Tasks within a given ready queue are handled on a first come first serve (FCFS) basis. The task where a READY status is first established has priority. The smaller the number, the higher the task priority level.


Task scheduling



A RUN status task will be moved to the end of the ready queue if placed in a READY status by any of the following causes:

- A WAIT status command was executed.
- The CPU occupation time exceeds a specified time.
- A task with a higher priority level is put in READY status.

Ready queue



NOTE

When the prescribed CPU occupation time elapses, the active command is ended, and processing moves to the next task.

However, if there are no other tasks of the same or higher priority (same or higher ready queue), the same task will be executed again.

3.3 Condition wait in task

A task is put in the WAIT status (waiting for an event) when a command causing WAIT status is executed for that task. At this time, the transition to READY status does not take place until the wait condition is canceled.

When a command causing WAIT status is executed, the following transition happens.

- Task for which a command causing WAIT status is executed → WAIT status
- Task at the head of the ready queue with higher priority → RUN status

MEMO

For example, when a MOVE statement (a command that establishes WAIT status) is executed, the CPU sends a "MOVE" instruction to the driver, and then waits for a "MOVE COMPLETED" reply from the driver. This is "waiting for an event" status.

In this case, WAIT status is established at the task which executed the MOVE command, and that task is moved to the end of the ready queue. RUN status is then established at the next task.

When an event waited by the task in the WAIT status occurs, the following status transition takes place by task scheduling.

Task in the WAIT status for which the awaited event occurred → READY status

However, if the task put in the READY status was at the head of the ready queue with the highest priority, the following transition takes place.

- Task that is currently in RUN status → READY status
- Task at the head of the ready queue with higher priority → RUN status

MEMO

In the above MOVE statement example, the task is moved to the end of the ready queue.

Then, when a "MOVE COMPLETED" reply is received, this task is placed in READY status.



NOTE

If multiple tasks are in WAIT status awaiting the same condition event, or different condition events occur simultaneously, all tasks for which the waited events occur are put in READY status.

Tasks are put in WAIT status by the following commands.

Event		Command			
Wait for axis movement to complete	Axis movement command	MOVE DRIVEI SERVO	MOVEI PMOVE WAIT ARM	MOVET PATH	DRIVE MOTOR
	Parameter command	ACCEL AXWGHT ORGORD WEIGHT	ARCHP1 CONTPLS OUTPOS WEIGHTG	ARCHP2 DECEL SCRINR	ARMTYP INROFST TOLE
	Robot status change command	CHANGE MSPEED	SHIFT SPEED	LEFTY	ASPEED
Wait for time to elapse		DELAY, SET (Time should be specified.)			
Wait for condition to be met		WAIT			
Wait for data to send or to be received		SEND			
Wait for print buffer to become empty		PRINT			
Wait for key input		INPUT			

MEMO


The tasks are not put in WAIT status if the event has been established before the above commands are executed.

3.4 Suspending tasks (SUSPEND)

The SUSPEND command temporarily stops tasks other than task 1 and places them in SUSPEND status. When the SUSPEND command is executed, the status transition takes place as follows.

- Task that executed the SUSPEND command → RUN status
- Specified task → SUSPEND status

Suspending tasks (SUSPEND)




3.5 Restarting tasks (RESTART)

Tasks in the SUSPEND status can be restarted with the RESTART command. When the RESTART command is executed, the status transition takes place as follows.

- Task for which the RESTART command was executed → RUN status
- Specified task → READY status

Restarting tasks (RESTART)



3.6 Deleting tasks


Task self-delete (EXIT TASK)

Tasks can delete themselves and set to the NON EXISTENT (no task registration) status by using the EXIT TASK command.

When the EXIT TASK command is executed, the status transition takes place as follows.

- Task that executed the EXIT TASK command → NON EXISTENT status
- Task at the head of the ready queue with higher priority → RUN status

Task self-delete (EXIT TASK)




Other-task delete (CUT)

Tasks can also delete the other tasks and put in the NON EXISTENT (no task registration) status by using the CUT command.

When the CUT command is executed, the status transition takes place as follows.

- Task that executed the CUT command → RUN
- Specified task → NON EXISTENT

Other-task delete (CUT)



MEMO

If a SUSPEND command is executed for a WAIT-status task, the commands being executed by that task are ended.

3.7 Stopping tasks

All tasks stop if any of the following cases occurs.

HALTALL command is executed. (stop & reset)

All programs are reset and task is put in the NON EXISTENT status. When the main program is specified, the HALTALL command registers the main program in the task 1 and all tasks are put in the STOP status at the beginning line. When the main program is not specified, the HALTALL command registers the program that has been executed last (current program) in the task 1 and all tasks are put in the STOP status at the beginning line.

HOLDALL command is executed. (temporary stop)

All tasks are put in the STOP status. When the program is restarted, the tasks in the STOP status set to the READY or SUSPEND status.

STOP key on the programming box is pressed or the interlock signal is cut off.

Just as in the case where the HOLD command is executed, all tasks are put in the STOP status.

When the program is restarted, the tasks in the STOP status set to the READY status (or, the task is placed the SUSPEND status after being placed in the READY status).

When the emergency stop button on the programming box is pressed or the emergency stop signal is cut off.

All tasks are put in the STOP status. At this point, the power to the robot is shut off and the servo sets to the non-hold state.

After the canceling emergency stop, when the program is restarted, the tasks in the STOP status are set to the READY or SUSPEND status. However, a servo ON is required in order to restart the robot power supply.

MEMO

When the program is restarted without being reset after the tasks have been stopped by a cause other than 1., then each task is processed from the status in which the task stopped. This holds true when the power to the controller is turned off and then turned on.

1

2

3

4

5

6

Tasks are executed in their scheduled order. An example of a multi-task program is shown below.

Sample	Description
<pre>' TASK1 START <SUB_TSK2>,T2 START <SUB_TSK3>,T3 *ST1: DO (20) = 1 WAIT MO(20) = 1 MOVE P,P1,P2,Z=0 IF MO(21)=1 THEN *FIN GOTO *ST1 *FIN: CUT T2 HALTALL</pre>	<p>TASK1</p>
<pre>' TASK2 *ST2: IF DI(20) = 1 MO(20) = 1 DELAY 100 ELSE MO(20) = 0 ENDIF GOTO *ST2 EXIT TASK</pre>	<p>Program name:SUB_TSK2 Task 2 begins here.</p> <p>Ends here.</p>
<pre>' TASK3 *ST3: IF DI(21) = 0 THEN *ST3 IF DI(30) = 0 THEN *ST3 IF DI(33) = 0 THEN *ST3 MO(21) = 1 EXIT TASK</pre>	<p>Program name:SUB_TSK3 Task 3 begins here.</p> <p>Ends here.</p>

All global variables, static variables, input/output variables, point data, shift coordinate definition data, hand definition data, work definition data, and pallet definition data are shared between all tasks.

Execution of each task can be controlled while using the same variables and data shared with the other tasks.

MEMO

In this case, however, use sufficient caution when rewriting the variable and data because improper changes may cause trouble in the task processing. Take great care when sharing the same variables and data.

A freeze may occur if subtasks are continuously started (START command) and ended (EXIT TASK command) by a main task in an alternating manner.

This occurs for the following reason: if the main task and subtask priority levels are the same, a task transition to the main task occurs during subtask END processing, and an illegal task status then occurs when the main task attempts to start a subtask.

Therefore, in order to properly execute the program, the subtask priority level must be set higher than that of the main task. This prevents a task transition condition from occurring during execution of the EXIT TASK command.

In the sample program shown below, the priority level of task 1 (main task) is set as 32, and the priority level of task 2 is set as 31 (the lower the value, the higher the priority).

Sample	Description
<pre> FLAG1 = 0 *MAIN_TASK: IF FLAG1=0 THEN FLAG1 = 1 START <SUB_PGM>, T2, 31 ENDIF GOTO *MAIN_TASK HALTALL '===== ' TASK2 '===== *TASK2: DRIVE(1,P1) WAIT ARM(1) DRIVE(1,P2) WAIT ARM(1) FLAG1 = 0 EXIT TASK </pre>	<p>MAIN_TASK</p> <p><SUB_PGM> is started as task 2 with priority level 31.</p> <p>SUB TASK (Program name:SUB_PGM)</p>

Chapter 7

Sequence function

1	Sequence function.....	7-1
2	Sequence program specifications	7-1
3	Creating a sequence program.....	7-2
4	Executing a sequence program.....	7-5
5	Programming a sequence program.....	7-6

Besides normal robot programs, the RCX340/RCX320 controller can execute high-speed processing programs (sequence programs) in response to the robot input/output (DI, DO, MO, LO, TO, SI, SO) signals.

- This function allows to monitor the input/output signals of sensors, push button switches, solenoid valves, etc. and move them. The sequence program starts running simultaneously the controller is turned on.
- The sequence program can be written in the same robot language used for robot programs. (The ladder logic are not necessary).
- Naming the program "SEQUENCE" makes the controller recognize as sequence program.
- For details regarding conditions to execute a sequence program, refer to "3 Executing a sequence program" in this Chapter.
- General-purpose outputs are not reset by the program reset while the sequence function is running.



NOTE

- While the "DI10" *: sequence control input" is ON, a sequence program runs according to its own cycle, regardless of robot program starts and stops. * "SI10" instead of "DI10" when an SIO board is inserted.
- The output while a sequence program is running is as follows.
 - > When a dedicated PIO board is inserted: "DO12: Sequence program running" dedicated signal output
 - > When an SIO board is inserted: "SO12: Sequence program running" dedicated signal output



MEMO


In the manners shown below, the reset of general-purpose output will be allowed while the sequence program is operating.

- Set a sequence flag value of the controller parameter at "3".
- Select "Output Reset Enable" on the sequence execution flag dialogue in the support software.


Item	Specification
Commands	Logical NOT, AND, OR, XOR, EQV, IMP
I/O	Same as robot language
Program capacity	8,192 bytes (A maximum of 2,048 variables can be specified.)
Scan time	2 to 8 ms depending on the number of steps (this value changes automatically)

3.1 Programming method


Step 1 Select (Program Edit) from (Edit) menus on the "MENU" screen of the programming box.




Step 2 Press the F1 key (NEW) on the "PROGRAM SELECTION" screen.



Step 3 Enter "SEQUENCE" on the program name entry screen, and press the (OK) button.



Step 4 Use the cursor keys (▲ / ▼) to select "SEQUENCE" on the "PROGRAM SELECTION" screen, and then press the F2 key (EDIT).



Step 5 "3.220: Program step doesn't exist" message appears when creating a new program, and press (Close).





NOTE

When creating a new program, the alarm occurs since no program is written. This alarm does not occur when the robot language exists already in a program.

Step 6 Input a program on "PROGRAM SELECTION" screen.

Although usable commands are restricted, editing method is same as the standard robot program.


Commands which can be input are explained at "4 Programming a sequence program" in this Chapter.




3.2 Compiling

Compile and create an executable sequence program.

Step 1 Press the F3 key (SEQ CMP) on the "PROGRAM SELECTION" screen.




Step 2 The confirmation message will appear whether you execute sequence compile. Press (OK) to compile the program.



MEMO

If there is a syntax error in the program, an error message appears. When the compiling ends without any error, the display returns to the "PROGRAM SELECTION" screen and the letter "s" appears in "Flag". This means that the sequence program has been compiled successfully and is ready for use.



MEMO


The sequence execution program is erased and the Flag's letter "s" disappears in the following cases. In these cases the sequence function cannot be used.

1. When the sequence program was erased.
2. When the sequence program was edited.
3. When the program data was initialized.
4. When the "9.729: Sequence object destroyed." alarm occurred.

All the following conditions must be satisfied to execute a sequence program.

- The sequence program has been compiled.
- The sequence program execution flag is enabled.
(For details regarding the sequence program execution flag, refer to the RCX3 user's manual.)
- The external sequence control input "DI10"* contact is ON. * "SI10" when an SIO board is inserted.

Sequence program execution in progress



4.1 Sequence program STEP execution

The sequence program may be executed line by line while checking one command line at a time. This step execution can be executed in the same way as normal programs.

For details, refer to the RCX3 user's manual.

When the step is executed, satisfying the conditions described in the previous section is not required.

When programming a sequence program, you may use only assignment statements comprised of input/output variables and logical operators.

5.1 Assignment statements

Format

```
output variable = expression
```

Notation

Description

expression

Any one of the following can be used.

- Parallel input/output variables
- Internal output variables
- Arm lock output variables
- Timer output variables
- Serial input/output variable
- The logic operation expression shown above

5.2 Input/output variables

Each variable must be specified in a 1-bit format

Sample	Description
DO (35)	Correct examples
MO (24)	
DI (16)	
DO (37, 24)	Incorrect examples
DI3 (4)	
MO3 ()	

5.2.1 Input variables

Parallel input variables

Format

```
DI (mb)
```

Notation

Value

Range

m	port number	0 to 7, 10 to 17, 20 to 27
b	bit definition	0 to 7

These variables show the status of the parallel input signal.

Serial input variables

Format

```
SI (mb)
```

Notation

Value

Range

m	port number	0 to 7, 10 to 17, 20 to 27
b	bit definition	0 to 7

Indicates a serial input signal status. Only referencing can occur. No controls are possible.

5.2.2 Output variables

Parallel output variables

Format

DO (mb)

Notation	Value	Range
m	port number	0 to 7, 10 to 17, 20 to 27
b	bit definition	0 to 7

A parallel output is specified, or the output status is referenced.
Ports 0 and 1 are for referencing only, and no outputs can occur there.

Internal output variables

Format

MO (mb)

Notation	Value	Range
m	port number	0 to 7, 10 to 17, 20 to 27, 30 to 37
b	bit definition	0 to 7

These variables are used within the controller.
Ports 30 to 37 are for referencing only and ON/OFF cannot be controlled.

Arm lock output variables

Format

LO (mb)

Notation	Value	Range
m	port number	0, 1
b	bit definition	0 to 7

These variables are used to prohibit the arm (axis) movement. Movement is prohibited when ON.

- LO(00) to LO(07) corresponds to arm 1 to arm 8
- LO(10) to LO(17) corresponds to arm 9 to arm 16, respectively.

Timer output variables

Format

TO (mb)

Notation	Value	Range
m	port number	0, 1
b	bit definition	0 to 7

There are a total of 16 timer output variables: TO(00) to TO(17).
The timer of each variable is defined by the timer definition statement TIM00 to 17.

Serial output variables

Format

SO (mb)

Notation	Value	Range
m	port number	0 to 7, 10 to 17, 20 to 27
b	bit definition	0 to 7

Control or reference serial output signal status. Port 0 is for referencing only, and no controls are possible.

5.3 Timer definition statement

Format

`TIMmb=time`

Notation	Value	Range
<i>time</i>		100 to 2,147,483,647 ms (0 second to 24 days)
m	port number	0 to 7, 10 to 17, 20 to 27
b	bit definition	0 to 7

These variables show the status of the parallel input signal.

Meaning The timer definition statement sets the timer value of the timer output variable. This definition statement may be anywhere in the program. When the timer definition statement is omitted, the timer setting value of the variable is 0.

TIM00 to 17 correspond to the timer output variables TO(00) to (17).


Although this value can be set by 1 ms unit, it is effected by the scan cycle of sequence program (2 to 8 ms), the updated cycle of PIO board (2 to 4 ms), or the update cycle of SIO board (5 ms).

Timer usage example

Sample	Description
<code>TIM02=2500</code>Timer 02 is set to 2.5 seconds.
<code>TO(02)=DI(23)</code>Timer starts when DI(23) switches ON.

- When DI(23) is ON, after 2.5 seconds, TO(02) is set ON.
- When DI(23) is OFF, TO(02) is also OFF.
- When DI(23) isn't ON after 2.5 second or more, TO(02) does not change to ON.

Timer usage example: Timing chart



5.4 Logical operators

Operators	Functions	Meaning
NOT, ~	Logical NOT	Reverses the bits.
AND, &	Logical AND	Becomes "1" when both bits are "1".
OR,	Logical OR	Becomes "1" when either of the bits is "1".
XOR	Exclusive OR	Becomes "1" when both bits are different.
EQV	Logical equivalence operator	Becomes "1" when both bits are equal.
IMP	Logical implication operator	Becomes "0" when the first bit is "1" and the second bit is "0".

5.5 Priority of logic operations


Priority Ranking	Operation Content
1	Expressions in parentheses
2	NOT, ~ (Logical NOT)
3	AND, & (Logical AND)
4	OR, (Logical OR)
5	XOR (Exclusive OR)
6	EQV (Logical equivalence operator)
7	IMP (Logical implication operator)

Example with a ladder statement substitution

Sample

```
DO(23) = DI(16) & DO(35)
MO(34) = DO(25) | ~DI(24)
DO(31) = (DI(20) | DO(31)) & ~DI(21)
```

Ladder diagram



MEMO

- "NOT" cannot be used prior to the first parenthesis " (" or on the left of an expression. For example, the following commands cannot be used.
 - $DO(21) = \sim(DI(30) | DI(32))$
 - $\sim DO(30) = DI(22) \& DI(27)$
- Numeric values cannot be assigned on the right of an expression.
 - $MO(35) = 1$
 - $DO(26) = 0$
- There is no need to define a "HALT" or "HOLD" statement at the end of the program.
- The variables used in sequence programs are shared with robot programs, so be careful not to make improper changes when using the same variables between them.

Chapter 8

Robot Language

Robot language list.....	8-1
1 ABS	8-7
2 ABSRPOS	8-8
3 ACCEL	8-9
4 ARCHP1 / ARCHP2	8-10
5 ARMCND	8-12
6 ARMSEL.....	8-13
7 ARMTYP	8-14
8 ASPEED	8-15
9 ATN / ATN2	8-16
10 AXWGHT.....	8-17
11 CALL	8-18
12 CHANGE.....	8-19
13 CHGPRI.....	8-20
14 CHGWRK	8-21
15 CHR\$.....	8-22
16 CLOSE.....	8-23
17 CONTPLS.....	8-24
18 CORRECTXY	8-25
19 COS	8-26

20	CREWRK.....	8-27
21	CURTQST.....	8-28
22	CURTRQ	8-29
23	CUT	8-30
24	DATE\$.....	8-31
25	DECEL	8-32
26	DEF FN.....	8-33
27	DEGRAD	8-34
28	DELAY.....	8-35
29	DI	8-36
30	DIM	8-37
31	DIST	8-38
32	DO	8-39
33	DRIVE	8-41
34	DRIVEI.....	8-45
35	END SELECT.....	8-50
36	END SUB.....	8-51
37	ERR / ERL.....	8-52
38	ETHSTS.....	8-53
39	EXIT FOR	8-54
40	EXIT SUB	8-55
41	EXIT TASK	8-56
42	FOR to NEXT	8-57
43	GEPSTS.....	8-58
44	GOSUB to RETURN	8-59
45	GOTO	8-60
46	HALT.....	8-61
47	HALTALL	8-62
48	HAND.....	8-63
49	HOLD	8-68
50	HOLDALL.....	8-69
51	IF	8-70
52	INPUT.....	8-72
53	INROFST	8-74
54	INT.....	8-75

55	JTOXY	8-76
56	LEFT\$	8-77
57	LEFTY	8-78
58	LEN	8-79
59	LET	8-80
60	LO	8-83
61	LOCx.....	8-85
62	LSHIFT	8-87
63	MCHREF	8-88
64	MID\$	8-89
65	MO	8-90
66	MOTOR	8-92
67	MOVE	8-93
68	MOVEI	8-110
69	MOVET.....	8-111
70	MTRDUTY.....	8-112
71	OFFLINE	8-113
72	ON ERROR GOTO.....	8-114
73	ON to GOSUB.....	8-115
74	ON to GOTO	8-116
75	ONLINE	8-117
76	OPEN	8-118
77	ORD	8-119
78	ORGORD	8-120
79	ORIGIN	8-121
80	OUT	8-122
81	OUTPOS	8-123
82	PATH	8-125
83	PATH END	8-129
84	PATH SET.....	8-130
85	PATH START.....	8-133
86	PDEF	8-135
87	PGMTSK	8-136
88	PGN	8-137
89	PMOVE	8-138

90	Pn.....	8-143
91	PPNT.....	8-145
92	PRINT.....	8-146
93	PSHFRC.....	8-147
94	PSHJGSP.....	8-148
95	PSHMTD.....	8-149
96	PSHRSLT.....	8-150
97	PSHSPD.....	8-151
98	PSHTIME.....	8-152
99	PUSH.....	8-153
100	RADDEG.....	8-158
101	REFTSK.....	8-159
102	REM.....	8-160
103	RESET.....	8-161
104	RESTART.....	8-162
105	RESUME.....	8-163
106	RETURN.....	8-164
107	RIGHT\$.....	8-165
108	RIGHTY.....	8-166
109	RSHIFT.....	8-167
110	SCRINR.....	8-168
111	SELECT CASE to END SELECT.....	8-169
112	SEND.....	8-170
113	SERVO.....	8-172
114	SET.....	8-173
115	SETGEP.....	8-174
116	SGI.....	8-175
117	SGR.....	8-176
118	SHARED.....	8-177
119	SHIFT.....	8-178
120	SI.....	8-179
121	SID.....	8-180
122	SIN.....	8-181
123	SIW.....	8-182

124	Sn	8-183
125	SO	8-184
126	SOD	8-186
127	SOW	8-187
128	SPEED	8-188
129	SQR	8-189
130	START	8-190
131	STR\$	8-191
132	SUB to END SUB	8-192
133	SUSPEND	8-194
134	SWI	8-195
135	TAN	8-196
136	TCOUNTER	8-197
137	TIME\$	8-198
138	TIMER	8-199
139	TO	8-200
140	TOLE	8-201
141	TORQUE	8-202
142	TSKPGM	8-204
143	VAL	8-205
144	WAIT	8-206
145	WAIT ARM	8-207
146	WEIGHT	8-208
147	WEIGHTG	8-209
148	WEND	8-210
149	WHERE	8-211
150	WHILE to WEND	8-212
151	WHRXY	8-213
152	WRKDEF	8-214
153	XYTOJ	8-216

Robot language list

The key to reading the following robot language table is explained below.

(1) 	(2) 	(3) 	(4)
Name	Description	Online	Type
DIM	Declares array variable	-	Command

(1) Name

Indicates each robot language (command) name.

(2) Description

Explains the function of the robot language.

(3) Online

If "✓" is indicated at this item, online commands can be used.

If "-" is indicated at this item, commands containing operands that cannot partially be executed by online command.

(4) Type

Indicates the robot language type as "Command" or "Function".

When a command is used as both a "Command" and "Function", this is expressed as follows: Command/Function

Name	Description	Online	Type
A			
ABS	Acquires the absolute value of a specified value.	✓	Function
ABSRPOS	Acquires the machine reference value for specified robot axes. (Valid only for axes whose return-to-origin method is set as "mark".)	✓	Function
ACCEL	Specifies/acquires the acceleration coefficient parameter of a specified robot.	✓	Command / Function
ARCHP1	Specifies/acquires the arch distance 1 parameter of a specified robot.	✓	Command / Function
ARCHP2	Specifies/acquires the arch distance 2 parameter of a specified robot.	✓	Command / Function
ARMCND	Acquires the current arm status of a specified robot.	✓	Function
ARMSEL	Specifies/acquires the current "hand system" setting of a specified robot.	✓	Command / Function
ARMTYP	Specifies/acquires the "hand system" setting of a specified robot.	✓	Command / Function
ASPEED	Specifies/acquires the AUTO movement speed of a specified robot.	✓	Command / Function
ATN	Acquires the arctangent of the specified value.	✓	Function
ATN2	Acquires the arctangent of the specified X-Y coordinates.	✓	Function
AXWGHT	Specifies/acquires the axis tip weight parameter of a specified robot.	✓	Command / Function
C			
CALL	Calls a sub-procedure.	-	Command
CHANGE	Switches the hand data of a specified robot.	✓	Command
CHGPRI	Changes the priority ranking of a specified task.	✓	Command
CHGWRK	Switches the work data of a specified robot.	✓	Command
CHR\$	Acquires a character with the specified character code.	✓	Function

Name	Description	Online	Type
CLOSE	Close the specified General Ethernet Port.	✓	Command
CONTPLS	Specifies/acquires CONT pulse parameter of specified robot.	✓	Command / Function
CORRECTXY	Acquires the target position corrected for workpiece gripping position misalignment.	✓	Function
COS	Acquires the cosine value of a specified value.	✓	Function
CREWRK	Creates the work data from the offset; difference between 2 point data	✓	Function
CURTQST	Acquires the current torque value ratio of a specified axis to the rated torque.	✓	Function
CURTRQ	Acquires the current torque value of the specified axis of a specified robot.	✓	Function
CUT	Terminates another task currently being executed or temporarily stopped.	✓	Command
D			
DATE\$	Acquires the date as a "yy/mm/dd" format character string.	✓	Function
DECEL	Specifies/acquires the deceleration rate parameter of a specified robot.	✓	Command / Function
DEF FN	Defines the functions that can be used by the user.	–	Command
DEGRAD	Converts a specified value to radians (↔RADDEG).	✓	Function
DELAY	Waits for the specified period (units: ms).	–	Command
DI	Acquires the specified DI status.	✓	Function
DIM	Declares the array variable name and the number of elements.	–	Command
DIST	Acquires the distance between 2 specified points.	✓	Function
DO	Outputs a specified value to the DO port or acquires the DO status.	✓	Command / Function
DRIVE	Moves a specified axis of a specified robot to an absolute position.	✓	Command
DRIVEI	Moves a specified axis of a specified robot to a relative position.	✓	Command
E			
END SELECT	Terminates the SELECT CASE statement.	–	Command
END SUB	Terminates the sub-procedure definition.	–	Command
ERR / ERL	Acquires the error code number of an error which has occurred / the line number where an error occurred.	✓	Function
ETHSTS	Acquires the Ethernet port status.	✓	Function
EXIT FOR	Terminates the FOR to NEXT statement loop.	–	Command
EXIT SUB	Terminates the sub-procedure defined by the SUB to END statement.	–	Command
EXIT TASK	Terminates its own task which is in progress.	–	Command
F			
FOR to NEXT	Executes the FOR to NEXT statement repeatedly until a specified value is exceeded.	–	Command
G			
GEPSTS	Acquires the General Ethernet Port status.	✓	Function
GOSUB to RETURN	Jumps to a subroutine with the label specified by GOSUB statement, and executes that subroutine.	–	Command
GOTO	Unconditionally jumps to the line specified by a label.	–	Command
H			
HALT	Stops the program and performs a reset.	–	Command
HALTALL	Stops and resets all programs.	–	Command
HAND	Defines the hand of a specified robot.	✓	Command

Name	Description	Online	Type
HOLD	Temporarily stops the program.	-	Command
HOLDALL	Temporarily stops all programs.	-	Command
I			
IF	Allows control flow to branch according to conditions.	-	Command
INPUT	Assigns a value to a variable specified from the programming box.	✓	Command
INROFST	Specifies/acquires R axis inertia offset for SCARA parameter.	✓	Command / Function
INT	Acquires an integer for a specified value by truncating all decimal fractions.	✓	Function
J			
JTOXY	Converts joint coordinate data to Cartesian coordinate data of a specified robot. (↔XYTOJ)	✓	Function
L			
LEFT\$	Extracts a character string comprising a specified number of digits from the left end of a specified character string.	✓	Function
LEFTY	Sets the hand system of a specified robot to the left-handed system.	✓	Command
LEN	Acquires the length (byte count) of a specified character string.	✓	Function
LET	Executes a specified assignment statement.	✓	Command
LO	Outputs a specified value to the LO port to enable/disable axis movement or acquires the LO status.	✓	Command / Function
LOCx	Specifies/acquires point data for a specified axis or shift/work data for a specified element.	✓	Command / Function
LSHIFT	Shifts a value to the left by the specified bit count. (↔RSHIFT)	✓	Function
M			
MCHREF	Acquires the return-to-origin or absolute-search machine reference value for specified robot axes. (Valid only for axes whose return-to-origin method is set as "sensor" or "stroke-end".)	✓	Function
MID\$	Extracts a character string of a desired length from a specified character string.	✓	Function
MO	Outputs a specified value to the MO port or acquires the MO status.	✓	Command / Function
MOTOR	Controls the motor power status.	✓	Command
MOVE	Performs absolute movement of all axes of a specified robot.	✓	Command
MOVEI	Performs relative movement of all axes of a specified robot.	✓	Command
MOVET	Performs relative movement of all axes of a specified robot when the tool coordinate is selected.	✓	Command
MTRDUTY	Acquires the motor load factor of the specified axis.	✓	Function
O			
OFFLINE	Sets a specified communication port to the "offline" mode.	✓	Command
ON ERROR GOTO	This command allows the program to jump to the error processing routine specified by the label without stopping the program, or it stops the program and displays the error message.	-	Command
ON to GOSUB	Jumps to a subroutine with labels specified by a GOSUB statement in accordance with the conditions, and executes that subroutine.	-	Command
ON to GOTO	Jumps to label-specified lines in accordance with the conditions.	-	Command
ONLINE	Sets the specified communication port to the "online" mode.	✓	Command
OPEN	Opens the specified General Ethernet Port.	✓	Command

Name	Description	Online	Type
ORD	Acquires the character code of the first character in a specified character string.	✓	Function
ORGORD	Specifies/acquires the axis sequence parameter for performing return-to-origin and an absolute search operation in a specified robot.	✓	Command / Function
ORIGIN	Performs return-to-origin.	✓	Command
OUT	Turns ON the bits of the specified output ports and terminates the command statement.	-	Command
OUTPOS	Specifies/acquires the "OUT position" parameter of a specified robot.	✓	Command / Function
P			
PATH	Specifies the PATH motion path.	-	Command
PATH END	Ends the path setting for PATH motion.	-	Command
PATH SET	Starts the path setting for PATH motion.	-	Command
PATH START	Starts the PATH motion.	-	Command
PDEF	Defines the pallet used to execute pallet movement commands.	✓	Command
PGMTSK	Acquires the task number in which a specified program is registered.	✓	Function
PGN	Acquires the program number from a specified program name.	✓	Function
PMOVE	Executes the pallet movement command of a specified robot.	✓	Command
Pn	Defines points within a program.	✓	Command
PPNT	Creates point data specified by a pallet definition number and pallet position number.	✓	Function
PRINT	Displays a character string at the programming box screen.	-	Command
PSHFRC	Specifies/acquires the "Push force" parameter.	✓	Command / Function
PSHJGSP	Specifies/acquires the push judge speed threshold parameter.	✓	Command / Function
PSHMTD	Specifies/acquires the push method parameter.	✓	Command / Function
PSHRSLT	Acquires the status at the end of the PUSH statement.	✓	Function
PSHSPD	Specifies/acquires the push speed parameter.	✓	Command / Function
PSHTIME	Specifies/acquires the push time parameter.	✓	Command / Function
PUSH	Executes a pushing operation in the axis unit.	✓	Command
R			
RADDEG	Converts a specified value to degrees. (↔DEGRAD)	✓	Function
REFTSK	Acquires the status of the task.	✓	Function
REM	Expresses a comment statement.	-	Command
RESET	Turns the bit of a specified output port OFF.	✓	Command
RESTART	Restarts another task during a temporary stop.	✓	Command
RESUME	Resumes program execution after error recovery processing.	-	Command
RETURN	Returns the processing branching with GOSUB to the next line of GOSUB.	-	Command
RIGHT\$	Extracts a character string comprising a specified number of digits from the right end of a specified character string.	✓	Function
RIGHTY	Sets the hand system of a specified robot to the right-handed system.	✓	Command
RSHIFT	Shifts a value to the right by the specified bit count. (↔LSHIFT)	✓	Function

Name	Description	Online	Type
S			
SCRINR	Specifies/acquires R axis inertia for SCARA parameter.	✓	Command / Function
SELECT CASE to END SELECT	Allows control flow to branch according to conditions.	–	Command
SEND	Sends a file.	✓	Command
SERVO	Controls the servo ON/OFF of a specified axis or all axes of a specified robot.	✓	Command
SET	Turns the bit at the specified output port ON.	–	Command
SETGEP	Sets the General Ethernet Port.	✓	Command
SGL	Assigns the value to a specified integer type static variable / acquires the value of a specified integer type static variable.	✓	Command / Function
SGR	Assigns the value to a specified real type static variable / acquires the value of a specified real type static variable.	✓	Command / Function
SHARED	Enables reference with a sub-procedure without transferring a variable.	–	Command
SHIFT	Sets the shift coordinate for a specified robot by using the shift coordinate data specified by a shift variable.	✓	Command
SI	Acquires a specified SI status.	✓	Function
SID	Acquires a specified serial input's double-word information status.	✓	Function
SIN	Acquires the sine value for a specified value.	✓	Function
SIW	Acquires a specified serial input's word information status.	✓	Function
Sn	Defines the shift coordinates within the program.	✓	Command
SO	Outputs a specified value to the SO port or acquires the SO status.	✓	Command / Function
SOD	Outputs a specified serial output's double-word information or acquires the output status.	✓	Command / Function
SOW	Outputs a specified serial output's word information or acquires the output status.	✓	Command / Function
SPEED	Changes the program movement speed of a specified robot.	✓	Command
SQR	Acquires the square root of a specified value.	✓	Function
START	Specifies the task number and priority ranking of a specified program, and starts that program.	✓	Command
STR\$	Converts a specified value to a character string (↔VAL).	✓	Function
SUB to END SUB	Defines a sub-procedure.	–	Command
SUSPEND	Temporarily stops another task which is being executed.	–	Command
SWI	Switches the program being executed, then begins execution from the first line.	–	Command
T			
TAN	Acquires the tangent value for a specified value.	✓	Function
TCOUNTER	Outputs count-up values at 1ms intervals starting from the point when the TCOUNTER variable is reset.	✓	Function
TIME\$	Acquires the current time as an "hh:mm:ss" format character string.	✓	Function
TIMER	Acquires the current time in seconds, counting from midnight.	✓	Function
TO	Outputs a specified value to the TO port or acquires the TO status.	✓	Command / Function
TOLE	Specifies/acquires the tolerance parameter of a specified robot.	✓	Command / Function
TORQUE	Specifies/acquires the maximum torque command value which can be set for a specified axis of a specified robot.	✓	Command / Function
TSKPGM	Acquires the program number which is registered in a specified task.	✓	Function

Name	Description	Online	Type
V			
VAL	Converts the numeric value of a specified character string to an actual numeric value. (↔STR\$)	✓	Function
W			
WAIT	Waits until the conditions of the DI/DO conditional expression are met (with time-out).	–	Command
WAIT ARM	Waits until the axis operation of a specified robot is completed.	–	Command
WEIGHT	Specifies/acquires the tip weight (kg) parameter of a specified robot.	✓	Command / Function
WEIGHTG	Specifies/acquires the tip weight (g) parameter of a specified robot.	✓	Command / Function
WEND	Terminates the command block of the WHILE statement.	–	Command
WHERE	Reads out the current position of the arm of a specified robot in joint coordinates (pulse).	✓	Function
WHILE to WEND	Controls repeated operations.	–	Command
WHRXY	Reads out the current position of the arm of a specified robot as Cartesian coordinates (mm, degrees).	✓	Function
WRKDEF	Defines the work data (Creates the work data of the specified number)	✓	Command
X			
XYTOJ	Converts the point variable Cartesian coordinate data to the joint coordinate data of a specified robot. (↔JTOXY).	✓	Function

ABS

Acquires absolute values

FormatABS (*expression*)**Explanation** Returns a value specified by an *<expression>* as an absolute value.

Sample	Description
A=ABS(-362.54).....	The absolute value of -362.54 (=362.54) is assigned to variable A.

ABSRPOS

Acquires the machine reference value (axes: mark method)

FormatABSRPOS [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the machine reference value (units: %) of axes.

This function is valid only for axes whose return-to-origin method is set as "Mark", not for "Sensor" or "Stroke-end".

MEMO

At axes where return-to-origin method is set to "mark" method, absolute reset is possible when the machine reference value is in a 44 to 56% range.

Sample	Description
A=ABSRPOS(4)The machine reference value for axis 4 of robot 1 is assigned to variable A.

Format

1. ACCEL [*robot number*] *expression*
2. ACCEL [*robot number*] (*axis number*) = *expression*

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	1 to 100 (units: %)

- Explanation** Changes the acceleration coefficient parameter to the <expression> value.
 [Format 1] changes all axes of specified robot.
 [Format 2] changes the only axis specified by <axis number>.

Functions**Format**

ACCEL [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

- Explanation** Acquires the acceleration coefficient parameter value of axis.

Sample	Description
A=50	
ACCEL AThe acceleration coefficient of all axes of robot 1 becomes
ACCEL(3)=100	50%.
Only axis 3 of robot 1 becomes 100%.
'CYCLE WITH INCREASING ACCELERATION	
FOR A=10 TO 100 STEP 10The acceleration coefficient parameter is increased from 10%
	to 100% in 10% increments.
ACCEL A	
MOVE P,P0	
MOVE P,P1	
NEXT A	
A=ACCEL(3)The acceleration coefficient parameter of axis 3 of robot 1
HALT "END TEST"	is assigned to variable A.

ARCHP1 / ARCHP2

Specifies/acquires the arch distance parameter

Format

1. ARCHP1 [*robot number*] *expression*
2. ARCHP1 [*robot number*] (*axis number*) = *expression*

Format

1. ARCHP2 [*robot number*] *expression*
2. ARCHP2 [*robot number*] (*axis number*) = *expression*

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	0 to 99999999 (Unit: pulse)

Explanation ARCHP1 corresponds to the arch distance 1 parameter; ARCHP2 corresponds to the arch distance 2 parameter, respectively.

Changes the parameter's arch distance to the value indicated in the <*expression*>.

[Format 1] changes all axes of specified robot.

[Format 2] changes the only axis specified by <*axis number*> to the value indicated in the <*expression*>.

Functions**Format**

ARCHP1 [*robot number*] (*axis number*)

Format

ARCHP2 [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation ARCHP1 corresponds to the arch distance 1 parameter; ARCHP2 corresponds to the arch distance 2 parameter, respectively.

Acquires the arch distance parameter value of the axis specified at <*axis number*>.

Sample	Description
ARCHP1(3)=10The arch distance 1 parameter value of the 3rd axis of robot 1 changes to 10 pulses.
ARCHP2(3)=20The arch distance 2 parameter value of the 3rd axis of robot 1 changes to 20 pulses
.	
.	
.	
FOR B=1 TO 4	
SAV(B-1)=ARCHP1(B)	
NEXTThe arch distance parameters ARCHP1(1) to (4) are assigned to array variables SAV(0) to (3).

ARMCND

Acquires the current arm status

FormatARMCND [*robot number*]**Value***Robot Number***Range**

1 to 4 (If not input, robot 1 is specified.)

Explanation

This function acquires the current arm status of the SCARA robot.

The robot to acquire an arm status is specified by the *<robot number>*.

The arm status is "1" for a right-handed system and "2" for a left-handed system.

This function is enabled only when a SCARA robot is used.

Sample**Description**

A=ARMCNDThe current arm status of robot 1 is assigned to variable A.
IF A=1 THENRight-handed system status.
MOVE P, P100, Z=0	
ELSELeft-handed system status.
MOVE P, P200, Z=0	
ENDIF	

Format

```
ARMSEL [robot number] expression
```

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Expression</i>	1: right hand system, 2: left hand system

Explanation This function sets the current hand system selection of the SCARA robot. A robot to set a hand system is specified by the *<robot number>*.
This function is enabled only when a SCARA robot is used.

Sample**Description**

ARMSEL[2] 2Sets the left-handed system for the hand system selection of the robot 2.
-------------	--

Functions**Format**

```
ARMSEL [robot number]
```

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
---------------------	--

Explanation This function acquires the hand system currently selected for the SCARA robot. The robot to acquire a hand system is specified by the *<robot number>*.
The arm type is "1" for a right-handed system, and "2" for a left-handed system. This function is enabled only when a SCARA robot is used.

Sample**Description**

A=ARMSELThe current hand system selection of robot 1 is assigned to the variable A.
IF A=1 THENThe hand system selection is a right-handed system.
MOVE P,P100,Z=0	
ELSEThe hand system selection is a left-handed system.
MOVE P,P200,Z=0	
ENDIF	

ARMTYP

Sets/acquires the hand system selection during program reset

FormatARMTYP [*robot number*] *expression***Value****Range***Robot Number*

1 to 4 (If not input, robot 1 is specified.)

Expression

1: right hand system, 2: left hand system

Explanation

This function sets the hand system at program reset of the SCARA robot.

A robot to set a hand system selection is specified by the <*robot number*>.

This function is enabled only when a SCARA robot is used.

Sample**Description**

ARMTYP[2] 2Sets the left-handed system for the hand system of the robot 2.

Functions**Format**ARMTYP [*robot number*]**Value****Range***Robot Number*

1 to 4 (If not input, robot 1 is specified.)

Explanation

This function provides the hand system at program reset of the SCARA robot.

The robot to acquire a hand system is specified by the <*robot number*>.

The arm type is "1" for a right-handed system, and "2" for a left-handed system. This function is enabled only when a SCARA robot is used.

Sample**Description**

```

A=ARMTYP .....The arm type value of robot 1 is assigned to the variable A.
IF A=1 THEN .....The arm type is a right-handed system.
  MOVE P,P100,Z=0
ELSE .....The arm type is a left-handed system.
  MOVE P,P200,Z=0
ENDIF
HALTALL .....Program reset

```

Format

ASPEED [*robot number*] *expression*

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Expression</i>	1 to 100 (units: %)

Explanation Changes the automatic movement speed to the <expression> value.
This speed change applies to all axes.

The operation speed is determined by the product of the automatic movement speed (specified by programming box operation and by the ASPEED command), and the program movement speed (specified by SPEED command, etc.).

Operation speed = automatic movement speed x program movement speed.

Example:

Automatic movement speed: 80%

Program movement speed: 50%

Movement speed = 40% (80% × 50%)

**NOTE**

This command only defines the maximum speed, and does not guarantee the movement at the specified speed.

- Automatic movement speed: Specified by programming box operation or by the ASPEED command.
- Program movement speed: Specified by SPEED commands or MOVE, DRIVE speed settings.

Functions**Format**

ASPEED [*robot number*]

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
---------------------	--

Explanation Acquires the automatic movement speed value of robot.

Sample**Description**

SPEED 70	
ASPEED 100	
MOVE P,P0Movement from the current position to P0 occurs at 70% speed (= 100 * 70) of the robot 1.
ASPEED 50	
MOVE P,P1Movement from the current position to P1 occurs at 35% speed (= 50 * 70) of the robot 1.
MOVE P,P2,S=10Movement from the current position to P2 occurs at 5% speed (= 50 * 10) of the robot 1.
HALT	

Related commands

SPEED

ATN / ATN2

Acquires the arctangent of the specified value

FormatATN (*expression*)**Format**ATN2 (*expression 1, expression 2*)

Explanation ATN: Acquires the arctangent values of the specified *<expression>* values. The acquired values are radians within the following range: $-\pi/2$ to $+\pi/2$

ATN2: Acquires the arctangent values of the specified *<expression 1>* and *<expression 2>* X-Y coordinates. The acquired values are radians within the following range: $-\pi$ to $+\pi$

Sample	Description
A(0)=A*ATN(Y/X)The product of the expression (Y / X) arctangent value and variable A is assigned to array A (0).
A(0)=ATN(0.5)The 0.5 arctangent value is assigned to array A (0).
A(0)=ATN2(B,C)-DThe difference between the X-Y coordinates (B,C) arctangent value and variable D is assigned to array A (0).
A(1)=RADDEG(ATN2(B,C))The X-Y coordinates (B,C) arctangent value is converted to degrees, and is then assigned to array A (1).

Related commands COS, DEGRAD, RADDEG, SIN, TAN

Format

AXWGHT [*robot number*] (*axis number*) = *expression*

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	Varies according to the specified robot.

Explanation Changes the axis tip weight parameter for the specified axis to the <*expression*> value. This statement is valid in systems with "MULTI" axes and auxiliary axes (the robot type and auxiliary axes are factory set prior to shipment).

Functions**Format**

AXWGHT [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the axis tip weight parameter value for the specified axis. This statement is valid in systems with "MULTI" axes and auxiliary axes.

Sample	Description
A=5 B=0 C=AXWGHT(1)Axis tip weight value of the axis 1 of the robot 1 is acquired (the current value is saved to variable C).
AXWGHT(1)=A DRIVE(1,P0) AXWGHT(1)=B DRIVE(1,P1) AXWGHT(1)=CThe axis tip weight value of the axis 1 of the robot 1 is set again.
HALT	

Related commands WEIGHT, WEIGHTG

Format

```
CALL label (actual argument , actual argument...)
```

Explanation This statement calls up sub-procedures defined by the SUB to END SUB statements.

The *<label>* specifies the same name as that defined by the SUB statement.

1. When a constant or expression is specified as an actual argument, its value is passed on to the sub-procedure.
2. When a variable or array element is specified as an actual argument, its value is passed on to the sub-procedure. It will be passed on as a reference if "REF" is added at the head of the actual argument.
3. When an entire array (array name followed by parentheses) is specified as an actual argument, it is passed along as a reference.

**NOTE**

- When a value is passed on to a sub-procedure, the original value of the actual argument will not be changed even if it is changed in the sub-procedure.
- When a reference is passed on to a sub-procedure, the original value of the actual argument will also be changed if it is changed in the sub-procedure.
- For details, refer to Chapter 3 "8 Value Pass-Along & Reference Pass-Along".

**MEMO**

- CALL statements can be used up to 120 times in succession. Note that this number is reduced if commands which use stacks such as an FOR or GOSUB statement are used, or depending on the use status of identifiers.
- Always use the END SUB or EXT SUB statement to end a sub-procedure which has been called with the CALL statement. If another statement such as GOTO is used to jump out of the sub-routine, a "5.212: Stack overflow" error, etc., may occur.

Sample 1

```
X%=4
Y%=5
CALL *COMPARE ( REF X%, REF Y% )
HALT
'SUB ROUTINE: COMPARE
SUB *COMPARE ( A%, B% )
    IF A% < B% THEN
        TEMP%=A%
        A%=B%
        B%=TEMP%
    ENDIF
END SUB
```

Sample 2

```
I = 1
CALL *TEST( I )
HALT
'SUB ROUTINE: TEST
SUB *TEST
    X = X + 1
    IF X < 15 THEN
        CALL *TEST( X )
    ENDIF
END SUB
```

Reference For description of sample program, refer to "132 SUB to END SUB" in this Chapter.

Related commands

SUB, END SUB, EXIT SUB, SHARED

Format

CHANGE [robot number]	Hn
	OFF

Notation	Value	Range
	<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
n	Hand Number	0 to 31

Explanation CHANGE is used to switch the robot hand data.
If OFF is specified, the hand setting is not enabled.

Before switching the hand data, the hands must be defined at the HAND statement, the programming box, or the support software.

If the hand data with another robot setting is specified, "6.258: Illegal robot no" error occurs.

Reference "HAND"

Sample	Description
HAND H1= 0 150.000 0.000	
HAND H2= -5000 20.0000 0.000	
P1=150.000 300.000 0.000 0.000 0.000 0.000	
CHANGE H2Changes the hand data of the robot 1 to hand 2.
MOVE P,P1Moves the hand 2 tip of the robot 1 to P1 (1).
CHANGE H1Changes to hand 1.
MOVE P,P1Moves the hand 1 tip to P1 (2).
HALT	

Format

CHGPRI	Tn <program name> PGm	,p
--------	-----------------------------	----

Notation	Value	Range
m	Program Number	0 to 100
n	Task Number	1 to 16
p	Task Priority Ranking	1 to 64

Explanation Changes the priority ranking of task "n" to "p".
 The smaller the priority number, the higher the priority (high priority: 1 to low priority: 64).
 When a READY status occurs at a task with higher priority, all tasks with lower priority also remain in READY status.

Sample**Description**

```

START <SUB _ PGM>,T2,33          .....Main Program
*ST:
  MOVE P,P0,P1
  IF DI(20) = 1 THEN             .....When DI (20) is ON,
    CHGPRI T2,32                 .....The priority of Task 2 is No. 32
  ELSE
    CHGPRI T2,33                 .....When DI (20) is OFF,
    .....The priority of Task 2 is No. 33
  ENDIF
GOTO *ST
HALTALL

.....Program name: SUB _ PGM (Sub task)
'SUBTASK ROUTINE
.....From this line, Task 2
*SUBTASK:
  IF LOC3(WHERE) > 10000 THEN
    DO(20) = 1
    GOTO *SUBTASK
  ENDIF
  DO(20) = 0
GOTO *SUBTASK                   .....Down to this line, Task 2 processing
EXIT TASK                        .....Ends Task 2 (own task: SUB _ PGM)

```

Related commands CUT, EXIT TASK, RESTART, SUSPEND, START

Format

CHGWRK [robot number]	Wn	
	OFF	

Notation	Value	Range
	<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
n	Work Number	0 to 39

Explanation CHGWRK is used to switch the work data of robot.
If OFF is specified, the work setting is not enabled.

Before switching the work data, always define the work data using the WRKDEF statement, the programming box, or the support software.

Reference "WRKDEF", User's Manual "Work definitions"

Sample	Description
CHANGE H1Changes the hand data of the robot 1 to hand 1.
MOVE P,P1Moves the hand 1 tip of the robot 1 to P1.
WRKDEF W1 = 115.000 -50.000 0.000 30.000	
CHGWRK W1Changes the work data of the robot 1 to work 1.
MOVE P,P2Moves the work 1 tip of the robot 1 to P2.
HALT	

Related commands CREWRK, WRKDEF

CHR\$

Acquires a character with the specified character code

FormatCHR\$ *expression***Value** **Range***Expression* 0 to 255

Explanation Acquires a character with the specified character code. An error occurs if the *<expression>* value is outside the 0 to 255 range.

Sample **Description**

A\$=CHR\$(65) "A" is assigned to A\$.

Related commands ORD

Closes the specified General Ethernet Port

Format

CLOSE GPm

Notation	Value	Range
m	General Ethernet Port number	0 to 7

Explanation Closes the communication port of the specified General Ethernet Port.

Sample	Description
OPEN GP1Opens the General Ethernet Port 1.
SEND "123" TO GP1Sends the character strings "123" from the General Ethernet Port 1.
SEND GP1 TO A\$Receives the data from the General Ethernet Port 1 and Saves the received data in the variable A\$.
CLOSE GP1Closes the General Ethernet Port 1.

Related commands OPEN, SEND, SETGEP, GEPSTS

Specifies/acquires CONT pulse parameter of specified robot.

Format

1. CONTPLS [*robot number*] *expression*
2. CONTPLS [*robot number*] (*axis number*) = *expression*

Value

Range

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6 (If not input, all axes are specified.)
<i>Expression</i>	0 to 99999999 (unit: pulse)

Explanation Changes the CONT pulse parameter value of axis to the value indicated in the <*expression*>. [Format 1] changes all axes of specified robot.

[Format 2] changes only the axis specified by <*axis number*>.

Reference "MOVE" CONT setting

Functions

Format

CONTPLS [*robot number*] (*axis number*)

Value

Range

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6 (If not input, all axes are specified.)

Explanation Acquires the CONT pulse parameter value of specified axis.

Sample 1

Description

CONTPLS 20000Changes the CONTPLS parameter for all axes of Robot 1 to 20000

Sample 2

Description

CONTPLS (3) = 20000Changes the CONTPLS parameter for 3rd axis of Robot 1 to 20000

Sample 3

Description

A% = CONTPLS(3)Acquires the value of the CONTPLS parameter for 3rd axis of robot 1, Assigns it to integer variable A%


Acquires the target position corrected for workpiece gripping position misalignment.

Format

CORRECTXY [*robot number*] (*master position of robot tip, master position of workpiece, position of workpiece, target position before correction*)

Value	Range/Contents
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Master position of robot tip</i>	point data (unit: mm)
<i>Master position of workpiece</i>	point data (unit: mm)
<i>Position of workpiece</i>	point data when robot tip is at the master position of robot tip (unit: mm)
<i>Target position before correction</i>	point data (unit: mm)

- Explanation** Acquires the corrected target position of gripping position misalignment on XY coordinate plane.
 => For the target position, XYR-axes of <Target position before correction> are corrected and acquired.
 The axes position except XYR-axes remains the value of <Target position before correction>.
- Teach <Master position of robot tip>, <Master position of workpiece> and <Target position before correction> with gripping a workpiece beforehand.
 - This command is available as online command.



CAUTION

- All of usable point data are "mm" unit.
- This command is available only for the robot containing each XYR-axis. If this command is used for other robots, "2.354 Illegal coordinates for pos. correction" alarm will occur.

Sample

Description

P1 = CORRECTXY[1] (P2,P3,P4,P5)

.....The corrected target position is acquired and assigned to P1.
 Robot 1, Master position of robot tip P2, Master position of workpiece P3, Position of workpiece P4, Target position before correction P5.

Acquires the cosine value of a specified value

FormatCOS *expression***Value***Expression***Contents**

Angle (units: radians)

Explanation Acquires a cosine value for the *<expression>* value.**Sample****Description**

A(0)=B*COS(C)

.....The product of the C variable's cosine value and variable B is assigned to array A (0).

A(1)=COS(DEGRAD(20))

.....The 20.0° cosine value is assigned to array A (1).

Related commands

ATN, DEGRAD, RADDEG, SIN, TAN

Format

CREWRK [*robot number*] (*point of difference, standard point*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Point of Difference</i>	point in Cartesian coordinate system
<i>Standard Point</i>	point in Cartesian coordinate system (If not input, the current position is specified.)

Explanation The work data is made of the offset data; the differential value in the coordinates between the standard point and one of difference.

The current position will be treated as the standard point when it is omitted.

An error occurs unless both the standard point and one of difference are Cartesian coordinate system.

Reference "WRKDEF", User's Manual "Work definitions"

MEMO

If "pulse" is specified as the unit for the point of difference / standard, "6.205: Coordinate type error" may occur.

Sample	Description
CHANGE H1Changes the hand data of the robot 1 to hand 1.
MOVE P,P1Moves the hand 1 tip of the robot 1 to P1.
WRKDEF W1= CREWRK (P3)Defines work 1; the difference between the current position and P3 as the offset.
CHGWRK W1Changes the work data of the robot 1 to work 1.
MOVE P,P2Moves the work 1 tip of the robot 1 to P2.
HALT	

Related commands CHGWRK, WRKDEF

A

B

C

D

E

F

G

H

I

J

K

L

M

CURTQST

Acquires the ratio of the current torque (current) value of axis against the rated torque (current) value

Format

CURTQST [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the percentage (-1000 to 1000 [%]) of the current torque value against the rated torque value of axis.

Plus/minus signs indicate the direction.

Sample	Description
A = CURTQST(3)The ratio of the current torque (current) value against the rated torque (current)value of the axis 3 of robot 1 is assigned to variable A.

Acquires the ratio of the current torque (current) value of axis against the maximum torque (current) value

Format

CURTRQ [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the percentage (-100 to 100 [%]) of the current torque value against the maximum torque command value of axis .

Plus/minus signs indicate the direction.

Sample**Description**

A = CURTRQ(3)

.....The ratio of the current torque (current) value against the maximum torque (current)value of the axis 3 of robot 1 is assigned to variable A.

A

B

C

D

E

F

G

H

I

J

K

L

M

Terminates another task which is currently being executed

Format

CUT	Tn <program name> PGm
-----	-----------------------------

Notation	Value	Range
m	Program Number	0 to 100
n	Task number	1 to 16

Explanation Terminates another task which is currently being executed or which is temporarily stopped.
A task can be specified by the name or the number of a program in execution.
This statement cannot terminate its own task.

MEMO

.....
If a task (program) not active is specified for the execution, an error occurs.
.....

Sample**Description**

'TASK1 ROUTINE *ST: MO(20) = 0 START <SUB _ PGM>,T2 MOVE P,P0 MOVE P,P1 WAIT MO(20) = 1 CUT T2 GOTO *ST HALTALLTask 1 Registers SUB _ PGM program in Task No. 2 and starts it. Forced termination of Task 2 in running.
'TASK2 ROUTINE *SUBTASK2: P100=JTOXY(WHERE) IF LOC3(P100) >= 100.0 THEN MO(20) = 1 ELSE DELAY 100 ENDIF GOTO *SUBTASK2 EXIT TASKTask 2(Program name: SUB _ PGM) Ends Task 2 (own task: SUB _ PGM)

Related commands EXIT TASK, RESTART, START, SUSPEND

Format

DATE\$

Explanation

Acquires the date as a "yyyy/mm/dd" format character string.

"yyyy" indicates the year, "mm" indicates the month, and "dd" indicates the day.

Date setting is performed from an operation terminal such as a programming box.

Sample**Description**

Sample	Description
A\$=DATE\$Assigns the date into A as a string in yyyy / mm / dd format.
PRINT DATE\$Displays dates in yyyy / mm / dd format.
HALT	

Related commands

TIME\$

A

B

C

D

E

F

G

H

I

J

K

L

M

Format

1. DECEL [*robot number*] *expression*
2. DECEL [*robot number*] (*axis number*) = *expression*

Value**Range**

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	1 to 100 (units: %)

Explanation Changes the deceleration ratio parameter of axis to the *<expression>* value.

In format 1, the change occurs at all axes of a specified robot.

In format 2, the change occurs at the axis specified in *<axis number>*.

**MEMO**

The acceleration parameter can be changed by using the ACCEL statement.

Functions**Format**

DECEL [*robot number*] (*axis number*)

Value**Range**

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the deceleration ratio parameter value of axis.

Sample**Description**

```
A =50
```

```
DECEL A .....Specifies 50 in the deceleration rate parameter for all axes of robot 1.
```

```
DECEL(3)=100 .....Specifies 100 as the deceleration rate parameter for the axis 3 of robot 1.
```

```
'CYCLE WITH INCREASING DECELERATION
```

```
FOR A =10 TO 100 STEP 10
```

```
  DECEL A .....Specifies the variable A value in the deceleration rate parameter for all axes of robot 1.
```

```
  MOVE P ,P0
```

```
  MOVE P ,P1
```

```
NEXT A
```

```
A=DECEL(3) .....The deceleration rate parameter for the axis 3 of robot 1 is assigned to variable A.
```

```
HALT "END TEST"
```

Format

```
DEF FN name (dummy argument, dummy argument...)=function definition expression
```

Value	Range / Meaning
<i>name</i>	Function name. Max. of 16 characters including "FN".
<i>Dummy Argument</i>	Numeric or character string variable

Explanation Defines the functions which can be used by the user. Defined functions are called in the FN <*name*> (variable) format.

MEMO

- The <*dummy argument*> names are the same as the variable names used in the <*function definition expression*>. The names of these variables are valid only when the <*function definition expression*> is evaluated. There may be other variables with the same name in the program.
- When calling a function that uses a <*dummy argument*>, specify the constant, variable, or expression type which is the same as the <*dummy argument*> type. The <*dummy argument*> can be omitted. If <*dummy arguments*> are the same type, the difference of variable names does not affect.
- If a variable used in the <*function definition expression*> is not included in the <*dummy argument*> list, the current value of that particular variable is used for the calculation.
- A space must be entered between "DEF" and "FN". If no space is entered, DEFFN will be handled as a variable.
- The DEF FN statement cannot be used in sub-procedures.
- Definition by the DEF FN statement must be declared before statements which use functions.

Sample	Description
DEF FNPAI=3.141592	
DEF FNASIN(X)=ATN(X/SQR(-X^2+1))	
.Both the <dummy argument> and <function definition expression>
.	use "X".
.	
A=FNASIN(B)*10"X" is not required for calling.

DEGRAD

Angle conversion (degree → radian)

FormatDEGRAD (*expression*)**Value***Expression***Contents**

Angle (units: degrees)

Explanation The *<expression>* value is converted to radians.**MEMO**

To convert radians to degrees, use RADDEG.

Sample

A=COS(DEGRAD(30))

Description

.....A cosine value which is converted 30° to radians is assigned to variable A.

Related commands

ATN, COS, RADDEG, SIN, TAN

Format`DELAY expression`**Value**`Expression`**Range**

0 to 3600000 (units: ms)

Explanation A "program wait" status is established for the period of time specified by the `<expression>`. The minimum wait period is 1ms.

Sample	Description
DELAY 3500Waits 3,500 ms (3.5 seconds).
A-50 DELAY A*10Waits 500 ms (0,5 seconds).

A

B

C

D

E

F

G

H

I

J

K

L

M

Acquires the input status from the parallel port

Format

1. `LET expression = DI(m, ..., b)`
2. `LET expression = DI(mb, ..., mb)`
3. `LET expression = IO Name`

Notation	Value	Range / Meaning
m	Port Number	0 to 7, 10 to 17, 20 to 27
b	bit Definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	IO Name	Users can name specific bits of DI and DO as they desire. Note that it can be added and edited on the support software only (not with a programming box)

Explanation Indicates the parallel input signal status.
"0" will be entered if no input port exists.

Sample	Description
<code>A%=DI2()</code>The input status from DI (27) to DI (20) is assigned to variable A%.
<code>A%=DI5(7,4,0)</code>The DI (57), DI (54), DI (50) input status is assigned to variable A% (when all the above signals are "1" (ON), A% = 7).
<code>A%=DI(37,25,20)</code>The DI (37), DI (25), DI (20) input status is assigned to variable A% (when all the above signals except DI (20) are "1" (ON), A% = 6).
<code>A%=END_SENSOR</code>The IO Name "END_SENSOR" input status is assigned to variable A% (when the "END_SENSOR" is "1" (ON), A% = 1).

Reference Chapter 3 "9.3 Parallel input variable"

Format

```
DIM array definition , array definition,...
```

Format

<i>name</i>	%	(<i>constant</i> , <i>constant</i> , <i>constant</i>)
	!	
	\$	

Notation	Value	Range
<i>Constant</i>	Array subscript	0 to 32,767 (positive integer)

Explanation Declares the name and length (number of elements) of an array variable. A maximum of 3 dimensions may be used for the array subscripts. Multiple arrays can be declared in a single line by using comma (,) breakpoints to separate the arrays.

MEMO

- The total number of array elements is <constant> + 1.
- A "9.300: Memory full" error may occur depending on the size of each dimension defined in an array.

Sample	Description
DIM A%(10)Defines a integer array variable A% (0) to A% (10). (Number of elements: 11).
DIM B(2,3,4)Defines a real array variable B (0, 0, 0) to B (2, 3, 4). (Number of elements: 60).
DIM C%(2,2),D!(10)Defines an integer array C% (0,0) to C% (2,2) and a real array D! (0) to D! (10).

DIST

Acquires the distance between 2 specified points

FormatDIST (*point expression 1*, *point expression 2*)**Value****Meaning***Point Expression 1*

Cartesian coordinate system point

Point Expression 2

Cartesian coordinate system point

Explanation

Acquires the distance (units: mm) between the 2 points (X,Y,Z) specified by *<point expression 1>* and *<point expression 2>*. An error occurs if the 2 points specified by each *<point expression>* do not have Cartesian coordinates.

Sample**Description**

A=DIST(P0,P1)

.....The distance between P0 and P1 is assigned to variable A.

A

B

C

D

E

F

G

H

I

J

K

L

M

Format

1. `LET DOm(b,...,b) = expression`
2. `LET DO(mb,...,mb) = expression`
3. `LET IO Name = expression`

Notation	Value	Range / Meaning
m	Port Number	0 to 7, 10 to 17, 20 to 27
b	Bit Definition (*1)	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	Expression	Integer value (If real number is specified, rounds to an integer.) Bits beyond the number of bit whom an assignment destination is required are ignored. (If the port number is specified, the lower 8 bits are valid. If the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)
	IO Name	Users can name specific bits of DI and DO as they desire. Note that it can be added and edited on the support software only (not with a programming box)

Explanation Outputs the specified value to the DO port.
No output will occur if a nonexistent DO port is specified.

Reference (*1) Chapter 3 "10 Bit Settings"



CAUTION

Outputs to DO0() and DO1() are not possible. These ports are for reference only.

Sample	Description
<code>DO2() = &B10111000</code>DO (27, 25, 24, 23) are turned ON, and DO (26, 22, 21, 20) are turned OFF.
<code>DO2(6,5,1) = &B010</code>DO (25) are turned ON, and DO (26, 21) are turned OFF.
<code>DO3() = 15</code>DO (33, 32, 31, 30) are turned ON, and DO (37, 36, 35, 34) are turned OFF.
<code>DO(37,35,27,20) = A</code>The contents of the 4 lower bits acquired when variable A is converted to an integer are output to DO (37, 35, 27, 20) respectively.
<code>CHUCK = 1</code>IO name "CHUCK" is turned ON ("1" is output).

A

B

C

D

E

F

G

H

I

J

K

L

M

Functions

Format

LET *expression* = DOm (b, ..., b)

LET *expression* = DO (mb, ..., mb)

LET *expression* = IO Name

Notation	Value	Range / Meaning
m	Port Number	0 to 7, 10 to 17, 20 to 27
b	bit Definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	<i>Expression</i>	Integer value (If real number is specified, rounds to an integer.) Bits beyond the number of bit whom an assignment destination is required are ignored. (If the port number is specified, the lower 8 bits are valid. if the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)
	<i>IO Name</i>	Users can name specific bits of DI and DO as they desire. Note that it can be added and edited on the support software only (not with a programming box)

Explanation References the parallel port signal status.

Sample	Description
A% = DO2()Output status of DO(27) to DO(20) is assigned to variable A%.
A% = DO0(6, 5, 1)Output status of DO(06), DO(05) and DO(01) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
A% = DO(37,35,27,10)Output status of D0(37), DO(35) , DO(27) and D0(10) is assigned to variable A%. (If all above signals except D0(27) are 1 (ON), then A%=13.)
A% = CHUCKOutput status of IO name "CHUCK" is assigned to variable A%. (When "CHUCK" is ON, then A% =1.)

Related commands RESET, SET

Format

```
DRIVE [robot number] (axis number, expression), (axis number, expression)...,  
option, option ...
```

Value	Range / Meaning
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	Motor position (mm, degrees, pulses) or point expression

Explanation Executes absolute movement command for the specified axis
This command is also used in the same way for the auxiliary axes.

- Movement type : PTP movement of specified axis.
- Point setting method : Direct numeric value input, point definition.
- Options : Relative Speed setting, absolute Speed setting, STOPON conditions setting, CONTON conditions setting, CONT setting, XY setting.

A

B

C

D

E

F

G

H

I

J

K

L

M

Movement type

● PTP (Point to Point) movement of specified axis:

PTP movement begins after positioning of all axes specified at *<axis number>* is complete (within the tolerance range), and the command terminates when the specified axes enter the OUT position range. When two or more axes are specified, they will reach their target positions simultaneously.


If the next command following the DRIVE command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position tolerance range.

Example:

Signal output (DO, etc.)	Signal is output when axis enters within OUT position range.
DELAY	DELAY command is executed and standby starts, when axis enters the OUT position range.
HALT	Program stops and is reset when axis enters the OUT position range. Therefore, axis movement also stops.
HALTALL	All programs in execution stop when axis enters the OUT position range, task 1 is reset, and other tasks terminate. Therefore, the movement also stops.
HOLD	Program temporarily stops when axis enters the OUT position range. Therefore, axis movement also stops.
HOLDALL	All programs in execution temporarily stop when axis enters the OUT position range. Therefore, the movement also stops.
WAIT	WAIT command is executed when axis enters the OUT position range.

The WAIT ARM statement is used to execute the next command after the axis enters the tolerance range.

DRIVE command



Sample	Description
DRIVE(1,P0)Axis 1 of robot 1 moves from its current position to the position specified by P0.

Point data setting types

● **Direct numeric value input**

The target position is specified directly in *<expression>*.

If the numeric value is an integer, this is interpreted as "pulse" units. If the numeric value is a real number, this is interpreted as "mm/degrees" units, and each axis will move from the 0-pulse position to a pulse-converted position.

However, when using the optional XY setting, movement occurs from the Cartesian coordinate origin position.

Sample	Description
DRIVE(1,10000)Axis 1 of robot 1 moves from its current position to the 10000 pulses position.
DRIVE[2](2,90.00)Axis 2 of robot 2 moves from its current position to a position which is 90° in the plus-direction from the 0-pulse position.

● **Point definition**

Point data is specified in *<expressions>*. The axis data specified by the *<axis number>* is used. If the point expression is in "mm/degrees" units, movement for each axis occurs from the 0-pulse position to the pulse-converted position. However, when using the optional XY setting, movement occurs from the Cartesian coordinate origin position.



NOTE

If point data is specified with both integers and real numbers in the same statement, all values are handled in "mm/degrees" units.

Sample	Description
DRIVE(1,P1)Axis 1 of robot 1 moves from its current position to the position specified by P1.
DRIVE(4,P90)Axis 4 of robot 1 moves from its current position to the position specified by P90 (deg.) relative to the 0 pulse position. (When axis 4 is a rotating axis.)

A

B

C

D

E

F

G

H

I

J

K

L

M

Option types

- Relative speed setting
- Absolute Speed setting
- STOPON conditions setting
- CONTON conditions setting
- CONT setting

Reference "MOVE" statement

- XY setting

Format

XY

Explanation

Moves multiple specified axes to a position specified by Cartesian coordinates.

All the specified axes arrive at the target position at the same time.

If all axes which can be moved by MOVE statement have been specified, operation is identical to that which occurs when using MOVE statement. The following restrictions apply to this command:

1. Axes specified by <axis number> must include the axis 1 and 2.
2. This command can be specified at SCARA robots and Cartesian robots with X and Y- axes.
3. Point settings must be in "mm" or "deg." units (real number setting).

Sample

Description

```
DRIVE(1,P100),(2,P100),(4,P100),XY
```

.....The axis 1, 2 and 4 of robot 1 move from their current positions to the Cartesian coordinates position specified by P100.

Format

```
DRIVEI [robot number] (axis number, expression),
(axis number, expression)..., option, option
```

Value	Range / Meaning
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	Target position (mm, deg., pulses) or point expression

Explanation

Executes relative movement, including the auxiliary axes.

- Movement type (*) : PTP movement of a specified axis
- Point data setting (*) : Direct coordinate data input, point definition
- Options (*) : Relative Speed setting, absolute Speed setting, STOPON conditions setting, CONTON conditions setting, CONT setting,

Reference

"DRIVE" "MOVE" statement

(To use Sample program, replace "DRIVE" or "MOVE" in Sample to "DRIVEI".)

MEMO

When DRIVEI motion to the original target position is interrupted and then restarted, the target position for the resumed movement can be selected as the "MOVEI/DRIVEI start position" in the controller's parameters.

Reference RCX3 user's manual

- 1) KEEP (default)...Continues the previous (before interruption) movement. The original target position remains unchanged.
- 2) RESET...Relative movement begins anew from the current position. The target position before interruption is reset.

Movement type

● PTP (point-to-point) of specified axis

PTP movement begins after positioning of all axes specified at *<axis number>* is complete (within the tolerance range), and the command terminates when the specified axes enter the OUT position range. When two or more axes are specified, they will reach their target positions simultaneously.


If the next command following the DRIVEI command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position tolerance range.

Signal output (DO, etc.)	Signal is output when axis enters within OUT position range.
DELAY	DELAY command is executed and standby starts, when axis enters the OUT position range.
HALT	Program stops and is reset when axis enters the OUT position range. Therefore, axis movement also stops.
HALTALL	All programs in execution stop when axis enters the OUT position range, task 1 is reset, and other tasks terminate. Therefore, the movement also stops.
HOLD	Program temporarily stops when axis enters the OUT position range. Therefore, axis movement also stops.
HOLDALL	All programs in execution temporarily stop when axis enters the OUT position range. Therefore, the movement also stops.
WAIT	WAIT command is executed when axis enters the OUT position range.

The WAIT ARM statement are used to execute the next command after the axis enters the tolerance range.

DRIVEI command

WAIT ARM statement



Point data setting types

● Direct numeric value input

The target position is specified in *<expression>*.

If the target position's numeric value is a real number, this is interpreted as a "mm/ deg." units, and each axis will move from its current position to a pulse-converted position.

Sample	Description
DRIVEI(1,10000)From its current position, the axis 1 of robot 1 moves a distance of "+10000 pulses".
DRIVEI(4,90.00)From its current position, the axis 4 of robot 1 moves +90° (when axis 4 is a rotating axis).

● Point definition

Point data is specified in *<expression>*. The axis data specified by the *<axis number>* is used.

From its current position, the axis moves the distance specified by the point in a relative manner.

If the point expression is in "mm/ degrees" units, movement for each axis occurs from the 0-pulse position to the pulse-converted position.



NOTE

If point data is specified with both integers and real numbers in the same statement, all values are handled in "mm/degrees" units.

Sample	Description
DRIVEI(1,P1)The axis 1 of robot 1 moves from its current position the distance specified by P1.
DRIVEI(4,P90)The axis 4 of robot 1 moves from its current position the number of degrees specified by P90 (when axis 4 is a rotating axis).

Option types

● Speed setting

Format

1. SPEED = *expression*
2. S = *expression*

Value

Range

Value	Range
Expression	1 to 100 (units: %)

Explanation The program's movement speed is specified as an <expression>. The actual speed is determined as shown below.

- Robot's max. speed (mm/sec., or deg./sec.) × automatic movement speed (%) × value of expression (%)
- This option is enabled only for the specified DRIVE statement.



NOTE

This defines the maximum speed, and does not guarantee that all movement will occur at specified speed.

Sample

Description

Sample	Description
DRIVEI(1,10000),S=10The axis 1 of robot 1 moves from its current position to the +10000 pulses position at 10% of the program movement speed.

Format

1. DSPEED = *expression*
2. DS = *expression*

Value

Range

Value	Range
Expression	0.01 to 100.00 (units: %)

Explanation The axis movement speed is specified as an <expression>. The actual speed is determined as shown below.

- Robot's max. speed (mm/sec., or deg./sec.) × axis movement speed (%)

This option is enabled only for the specified DRIVEI statement.

Movement always occurs at the DSPEED <expression> value (%) without being affected by the automatic movement speed value (%).



NOTE

SPEED option and DSPEED option cannot be used together.

Sample

Description

Sample	Description
DRIVEI(1,10000),DS=0.1The axis 1 of robot 1 moves from its current position to the +10000 pulses position at 0.1% of the maximum speed.

● STOPON condition setting

Format

STOPON *conditional expression*

Explanation Stops movement when the conditions specified by the <conditional expression> are met.

Because this is a deceleration type stop, there will be some movement (during deceleration) after the conditions are satisfied.

- the <conditional expression> is specified with input/output signals or the variable.
- If the conditions are not satisfied, a robot moves to the target position.
- If the conditions are already satisfied before movement begins, the command is terminated without any movement.
- This option is enabled only by program execution.

Sample	Description
DRIVEI(1,10000),STOPON DI(20)=1Axis 1 of robot 1 moves from its current position toward the "+10000 pulses" position and stops at an intermediate point if the "DI (20) = 1" condition become satisfied. The next step is then executed.

MEMO

When the conditional expression used to designate the STOPON condition is a numeric expression, expression value other than "0" indicates a TRUE status, and "0" indicates a FALSE status.

Format

```

SELECT CASE expression

    CASE expression's list 1
        command block 1
    CASE expression's list 2
        command block 2
    :
    CASE ELSE
        command block n

END SELECT

```

Explanation Directly ends the SELECT CASE command block.
For details, refer to section "SELECT CASE to END SELECT".

Sample	Description
<pre> WHILE 1 SELECT CASE DI3(7,6,5,4,3,2,1,0) CASE &B00000001 MOVE P,P1 CASE &B00000010 MOVE P,P2 CASE &B00000011 MOVE P,P3 CASE ELSE MOVE P,P0 END SELECT WEND </pre>	<pre>Executes each command block according to the input status of DI3(8 bits)Command block when DI3(0) is ONWhen DI3(1) is ONWhen DI3(0) and DI3(1) is ONCase other than the aboveEnds SELECT CASE statement </pre>

Related commands SELECT CASE

Format

```
SUB label (dummy argument, dummy argument...)
    command block
END SUB
```

Explanation Ends the sub-procedure definition which begins at the SUB statement. For details, refer to section "SUB to END SUB".

Sample	Description
I=1	
CALL *TESTCalls sub-procedure *TEST
PRINT I	
HALT	
'SUB ROUTINE: TEST	(Comment: Subprocedure name is "TEST")
SUB *TESTDefines sub-procedure *TEST
I=50	
END SUBFinishes defining sub procedures

Related commands CALL, EXIT SUB, SUB to END SUB

A

B

C

D

E

F

G

H

I

J

K

L

M

ERR / ERL

Acquires the error code / error line number

FormatERR(*task number*)ERL(*task number*)**Value***Task Number***Range**

1 to 16 (If not input, the task being executed is specified.)

Explanation

Variables ERR and ERL are used in error processing routines specified by the ON ERROR GOTO statement.

ERR gives the error code of the error that has occurred and ERL gives the line number on which the error has occurred.

Sample**Description**

<pre>IF ERR(1) <> &H000600CC THEN HALT</pre>	<p>.....If "Point doesn't exist" error has occurred, This sample stops and resets the program.</p>
<pre>IF ERL =20 THEN RESUME NEXT</pre>	<p>.....If the line on which an error has occurred is 20, the program jumps to the next line of the error occurring line and continues the execution.</p>

Related commands

ON ERROR GOTO, RESUME

Format

ETHSTS

Explanation Acquires the Ethernet port status.

The values below are acquired depending on the status.

-2	Ethernet port is not opened yet.
-1	LAN cable is not connected.
0	The connection is not established.
1	The connection is established.
2	The connection is established / the data is stored in the reception buffer.

Sample**Description**

A=ETHSTSAssigns the Ethernet port status to the variable A.
----------	--

A

B

C

D

E

F

G

H

I

J

K

L

M

EXIT FOR

Terminates the FOR to NEXT statement loop

Format

EXIT FOR

Explanation Terminates the FOR to NEXT statement loop, then jumps to the command which follows the NEXT statement.

This statement is valid only between the FOR to NEXT statements.

MEMO

The FOR to NEXT statement loop will end when the FOR statement condition is satisfied or when the EXIT FOR statement is executed. A "5.212: Stack overflow" error, etc., will occur if another statement such as GOTO is used to jump out of the loop.

Sample	Description
<pre>*ST: WAIT DI(20)=1 FOR A%=101 TO 109 MOVE P,P100,Z=0 DO(20)=1 MOVE P,P[A%],Z=0 DO(20)=0 IF DI(20)=0 THEN EXIT FOR NEXT A% GOTO *ST HALT</pre>	<p>.....If DI(20) = 0 (false), exits between FOR and NEXT.</p>

Related commands FOR, NEXT

Format

EXIT SUB

Explanation The EXIT SUB statement terminates the sub-procedure defined by the SUB to END SUB statements, then jumps to the next command in the CALL statement that called up the sub-procedure. This statement is valid only within the sub-procedure defined by the SUB to END SUB statements.

MEMO

To end the sub-procedure defined by the SUB to END SUB statements, use the END SUB statement or EXIT SUB statement. A "5.212: Stack overflow" error, etc., will occur if another statement such as GOTO is used to jump out of the loop.

Sample	Description
<pre>'MAIN ROUTINE CALL *SORT2(REF X%,REF Y%) HALT</pre>Calls sub-procedure *SORT2
<pre>'SUB ROUTINE: SORT SUB *SORT2(X%, Y%) IF X%>=Y% THEN EXIT SUB TMP%=Y% Y%=X% X%=TMP% END SUB</pre>Defines *SORT2 as a sub-procedureIf X is Y or more, exits between SUB and END SUB

Related commands CALL, SUB to END SUB, END SUB

A

B

C

D

E

F

G

H

I

J

K

L

M

EXIT TASK

Terminates its own task which is in progress

Format

EXIT TASK

Explanation Terminates its own task which is currently being executed.**Sample****Description**

```
'TASK1 ROUTINE
*ST:
    MO(20)=0
    START <SUB _ PGM>,T2          .....Registers SUB _ PGM program in Task No. 2 and
    MOVE P,P0,P1                  starts it.
    WAIT MO(20)=1
    GOTO *ST
HALTALL

Program name:SUB _ PGM
'TASK2 ROUTINE
*SUBTASK2:
    P100=JTOXY(WHERE)
    IF LOCZ(P100)>=100.000 THEN
    MO(20)=1
    EXIT TASK                      .....Ends Task 2 (own task: SUB _ PGM)
    ENDIF
    DELAY 100
GOTO *SUBPTASK2                  .....Jumps to *SUBTASK 2
EXIT TASK                        .....Ends Task 2 (own task: SUB _ PGM)
```

Related commands CUT, RESTART, START, SUSPEND, CHGPRI

Format

```
FOR control variable = start value TO end value STEP step
    command block
NEXT control variable
```

Explanation These statements repeatedly execute commands between the FOR to NEXT statements for the <start value> to <end value> number of times, while changing the <control variable> value in steps specified by <STEP>.

- If <STEP> is omitted, its value becomes "1".
- The <STEP> value may be either positive or negative.
- The <control variable> must be a numeric <simple variable> or <array variable>.
- The FOR and NEXT statements are always used as a set.

Sample

```
'CYCLE WITH CYCLE NUMBER OUTPUT TO DISPLAY
FOR A=1 TO 10
    MOVE P,P0
    MOVE P,P1
    MOVE P,P2
    PRINT"CYCLE NUMBER=";A
NEXT A
HALT
```

FOR to NEXT is useful to make the program compact.

SAMPLE (Descriptions with FOR to NEXT)

```
FOR A=1 TO 5           .....Repeats 5 times between FOR and NEXT.
    MOVE P,P[A],A3=0.00  A number of destination point for MOVE changes depending
NEXT A                on a value of a variable.
MOVE P,P10,A3=0.00
DO(20)=1
```

A example without FOR to NEXT;

though the description is simple, the number of programming line increases in accordance with one of the destination.

SAMPLE (Descriptions without FOR to NEXT)

```
MOVE P,P1,A3=0.00
MOVE P,P2,A3=0.00
MOVE P,P3,A3=0.00
MOVE P,P4,A3=0.00
MOVE P,P5,A3=0.00
MOVE P,P10,A3=0.00
DO(20)=1
```

MEMO

While FOR to NEXT is processed, leaving the loop is disabled by GOTO and so on.

In order to leave FOR to NEXT, use EXIT FOR.

Related commands EXIT FOR

GEPSTS

Acquires the General Ethernet Port status

FormatGEPSTS (*General Ethernet Port number*)**Value** **Range***General Ethernet Port number* 1 to 4**Explanation** Acquires the General Ethernet Port status.

The values below are acquired depending on the status.

-2	Specified General Ethernet Port is not opened yet.
-1	LAN cable is not connected.
0	The connection is not established. (Only server)
1	The connection is established.
2	The connection is established / the data is stored in the reception buffer.

Sample**Description**

OPEN GP1Opens the port which is specified at the General Ethernet port 1.
IF GEPSTS(1) > 0 THENConfirms if the connection is established.
SEND "ABC" TO GP1Sends the character string "ABC".
IF GEPSTS(1)=2 THENConfirms if the data is stored in the reception buffer.
SEND GP1 TO RET\$Receives the data and assigns the received to the variable RET\$.
ENDIF	
ENDIF	
CLOSE GP1Closes the port which is specified at the General Ethernet port 1.
HALT	

Related commands OPEN, CLOSE, SEND, SETGEP

* GOSUB can also be expressed as "GO SUB".

Format

```
GOSUB label
:
label:
:
RETURN
```

Explanation Jumps to the <*label*> subroutine specified by the GOSUB statement.
A RETURN statement within the subroutine causes a jump to the next line of the GOSUB statement.

MEMO

- The GOSUB statement can be used up to 120 times in succession. Note that this number of times is reduced if commands containing a stack such as an FOR statement or CALL statement are used.
- When a jump to a subroutine was made with the GOSUB statement, always use the RETURN statement to end the subroutine. If another statement such as GOTO is used to jump out of the subroutine, an error such as "5.212: Stack overflow" may occur.

Sample	Description
*MAIN: MOVE P,P1,A3=0.00 GOSUB *SUB_DO MOVE P,P2,A3=0.00 HALTJumps to the label "*SUB_DO"Executes from this line after the subroutine *SUB_DO has reached RETURN
*SUB_DO: DO(20)=1 DELAY 500 DO(20)=0 RETURNDefines *SUB_DO as a subroutine labelExecutes from the next line of the GOSUB statement

Related commands RETURN

GOTO

Executes an unconditional jump to the specified line

Format

GOTO label * GOTO can also be expressed as "GO TO".

Explanation Executes an unconditional jump to the line specified by the <label>.

MEMO

"Label" is the name which is put on a programming line.

For specifying the programming line, it is necessary to create a label on the line and specify it.

In order to create/define a label, always begin with * and end with : .

For details, refer to Chapter 1 "6. LABEL Statement".

Sample	Description
*TOP: MOVE P,P1 DELAY 1000 MOVE P,P2 DELAY 1000 GOTO *TOPDefines *TOP as a label Jumps to the label *TOP

Stops the program and performs a reset

Format

HALT	<i>expression</i> <i>character string</i>
------	--

Explanation Stops the program and resets it. If restarted after a HALT, the program runs from its beginning. If an <expression> or a <character string> is written, the operation result of <expression> or the contents of <character string> are displayed on the programming box screen, respectively.

MEMO

- Variables are not reset by execution of HALT statement. HALTALL is available to reset variables.
- HALT is effective only in the executed task. The programs executed in other tasks continue execution.


Sample	Description
<pre>'MAIN ROUTINE *ST: MOVE P,P0,P1 IF DI(20) = 1 THEN GOTO *FIN ENDIF GOTO *ST *FIN: HALT "PROGRAM FIN"</pre>	<p>.....If DI(20) is ON</p> <p>.....Jumps to the label *FIN</p> <p>.....Defines *FIN as a label</p> <p>.....Stops and resets the program (displayed as "PROGRAM FIN")</p>

In PTP movement specified by movement commands such as MOVE and DRIVE, the next line's command is executed when the axis enters the OUT position range.

Therefore, if a HALT command exists immediately after a PTP movement command, that HALT command is executed before the axis arrives in the target position tolerance range.

Likewise, when specifying CONT options in interpolation movement during MOVE (L or C) command, the next command is executed immediately after movement starts. Therefore, if a HALT command exists immediately after the interpolation movement command during MOVE (L or C) command with CONT options, a HALT command is executed immediately after starting movement.

In either of the above cases, use the WAIT ARM command as shown below if desiring to execute the HALT command after the axis arrives within the target position tolerance range.

HALT command

33821-R7-00

Format

HALTALL

*expression**character string*

- Explanation** Stops and resets all programs. Dynamic variables, array variables, output variables are also reset. Output variables (DO/SO/MO/LO/TO/SOW) are reset under the condition as shown below.
- IO parameter "DO output at Program reset" is "IO_RESET".
 - Sequence program is in execution and the sequence program execution flag is enabled.

If a program is restarted after a HALTALL, the program runs from its beginning of the main program or of the last program executed at task 1.

If an <expression> or a <character string> is written, the calculation result of <expression> or the contents of <character string> are displayed on the programming box screen, respectively (if variable is written in an <expression>, the previous value before clearing is displayed).

MEMO

- HALTALL stops all the programs which is run in multi tasking.
After the reset, the main program or a current program is registered automatically at the task No.1 and the other tasks are cleared.
- Executing HALTALL resets all of general-purpose outputs and variables.
Note that the reset of general-purpose output won't be executed if "DO output at program reset <RESCDO>" within I/O parameters is set to "1: IO_HOLD".

Sample**Description**

```
MOVE P,P1
DELAY 1000
HALTALL
```


.....Reset is executed after the program.

In PTP movement specified by movement commands such as MOVE and DRIVE, the next line's command is executed when the axis enters the OUT position range.

Therefore, if a HALTALL command exists immediately after a PTP movement command, that HALTALL command is executed before the axis arrives in the target position tolerance range.

Likewise, when specifying CONT options in interpolation movement during MOVE (L or C) command, the next command is executed immediately after movement starts. Therefore, if a HALTALL command exists immediately after the interpolation movement command during MOVE (L or C) command with CONT options, a HALTALL command is executed immediately after starting movement.

In either of the above cases, use the WAIT ARM command as shown below if desiring to execute the HALTALL command after the axis arrives within the target position tolerance range.



Format

Definition statement:

HAND [*robot number*] Hn = *1st parameter 2nd parameter 3rd parameter* R

Selection statement:

CHANGE [*robot number*] Hn

Notation	Value	Range
	<i>Robot Number</i>	1 to 4
n	Hand Number	0 to 31
R	Attaching Hand to R-axis	

Explanation

The HAND statement only defines the hand.

To actually change the hands data, use the CHANGE statement.

For CHANGE statement details, refer to section "CHANGE".

If "R" is specified, the hand that are offset from the R-axis rotating center are selected.

MEMO


- If a power OFF occurs during execution of the hand definition statement, the "9.707 Hand data destroyed" error may occur.
- If specifying the hand data that was defined by specifying other robots in the CHANGE statement, "6.258: Illegal robot no" error may occur.

48.1 For SCARA Robots

48.1.1 <4th parameter> "R" is not specified.

Hands installed on the second arm tip are selected (see below).


- 1st parameter* Number of offset pulses between the standard second arm position and the virtual second arm position of hand "n". "+" indicates the counterclockwise direction [pulse].
- 2nd parameter* Difference between the hand "n" virtual second arm length and the standard second arm length [mm]
- 3rd parameter* Z-axis offset value for hand "n" [mm]



33803-R9-00

Sample	Description					
HAND H1=	0	150.000	0.0000			
HAND H2=	-5000	20.000	0.000			
P1=	150.000	300.000	0.000	0.000	0.000	0.000
CHANGE H2Changes the hand data of robot 1 to hand 2.					
MOVE P,P1Tip of hand 2 of robot 1 moves to P1.(1)					
CHANGE H1Changes the hand data of robot 1 to hand 1.					
MOVE P,P1Tip of hand 1 of robot 1 moves to P1.(2)					
HALT						

SAMPLE:HAND




33802-R7-01

48.1.2 <4th parameter> "R" is specified.

The hands that are offset from the R-axis rotating center are selected (see below).


- 1st parameter When the current position of R-axis is 0.00, this parameter shows the angle of hand "n" from the X-axis plus direction in a Cartesian coordinate system. ("+"indicates the counterclockwise direction.) [degree]
- 2nd parameter Length of hand "n" [mm] (>0)
- 3rd parameter Z-axis offset amount for hand "n" [mm]



33804-R9-00

Sample	Description
HAND H1=	0.00 150.0 0.0 R
HAND H2=	-90.00 100.00 0.0 R
P1=	150.00 300.00 0.00 0.00 0.00 0.00
CHANGE H1Changes the hand data of robot 1 to hand 1.
MOVE P,P1Tip of hand 1 of robot 1 moves to P1.(1)
CHANGE H2Changes the hand data of robot 1 to hand 2.
MOVE P,P1Tip of hand 2 of robot 1 moves to P1.(2)
HALT	

SAMPLE:HAND




33804-R7-01

48.2 For Cartesian Robots

48.2.1 <4th parameter> "R" is not specified.

Hands installed on the second arm tip are selected (see below).


1st parameter Hand "n" X-axis offset amount [mm]
 2nd parameter Hand "n" Y-axis offset amount [mm]
 3rd parameter Hand "n" Z-axis offset amount [mm]



33805-R9-00

Sample	Description					
HAND H1=	0.000	0.000	0.000			
HAND H2=	100.000	-100.000	-100.000			
P1=	200.000	250.000	0.000	0.000	0.000	0.000
CHANGE H2Changes the hand data of robot 1 to hand 2.					
MOVE P,P1Tip of hand 2 of robot 1 moves to P1.(1)					
CHANGE H1Changes the hand data of robot 1 to hand 1.					
MOVE P,P1Tip of hand 1 of robot 1 moves to P1.(2)					
HALT						

SAMPLE:HAND




33806-R7-01

48.2.2 <4th parameter> "R" is specified.

The hands that are offset from the R-axis rotating center are selected (see below).


- 1st parameter When the current position of R-axis is 0.00, this parameter shows the angle of hand "n" from the X-axis plus direction in a Cartesian coordinate system. ("+" indicates the counterclockwise direction.) [degree]
- 2nd parameter Length of hand "n". [mm] (>0)
- 3rd parameter Z-axis offset amount for hand "n". [mm]



33806-R9-00

Sample	Description
HAND H1=	0.000 100.000 0.000 R
HAND H2=	90.000 150.000 0.000 R
P1=	200.000 250.000 0.000 0.000 0.000 0.000
CHANGE H2Changes the hand data of robot 1 to hand 2.
MOVE P,P1Tip of hand 2 of robot 1 moves to P1.(1)
CHANGE H1Changes the hand data of robot 1 to hand 1.
MOVE P,P1Tip of hand 1 of robot 1 moves to P1.(2)
HALT	

SAMPLE:HAND



33808-R7-01

HOLD

Temporarily stops the program

Format

HOLD	<i>expression</i> <i>character string</i>	
------	--	--

Explanation Temporarily stops the program. When restarted, processing resumes from the next line after the HOLD statement. If an *<expression>* or *<character string>* is written in the statement, the contents of the *<expression>* or *<character string>* display on the programming box screen.

MEMO

HOLD is effective only in the task executed. The programs executed in other tasks continue execution.

Sample **Description**


'MAIN ROUTINE	
*ST:	
MOVE P,P0,P1	
IF DI(20)=1 THENIf DI(20) is ON
HOLD "PROGRAM STOP"Suspend the running task program (displayed as "PROGRAM STOP")
ENDIF	
GOTO *ST	
HALTStops and resets the program

In PTP movement specified by movement commands such as MOVE and DRIVE, the next line's command is executed when the axis enters the effective OUT position range.

Therefore, if a HOLD command exists immediately after a PTP movement command, that HOLD command is executed before the axis arrives in the target position tolerance range.

Likewise, when specifying CONT options in interpolation movement during MOVE (L or C) command, the next command is executed immediately after movement starts. Therefore, if a HOLD command exists immediately after the interpolation movement command during MOVE (L or C) command with CONT options, a HOLD command is executed immediately after starting movement.

In either of the above cases, use the WAIT ARM command as shown below if desiring to execute the HOLD command after the axis arrives within the target position tolerance range.

HOLD command

33822-R7-00

Format

HOLDALL	<i>expression</i> <i>character string</i>	
---------	--	--

Explanation Temporality stops all programs. When restarted, the program that has executed HOLDALL is executed from the next line after the statement, and other programs are resumed from the line that has interrupted execution. If an *<expression>* or *<character string>* is written in the statement, the contents of *<expression>* or *<character string>* displays on the programming box screen.


Sample	Description
<pre>'MAIN ROUTINE *ST: MOVE P,P0,P1 IF DI(20)=1 THENIf DI(20) is ON HOLD "PROGRAM STOP"Pauses all programs (displayed as "PROGRAM STOP") ENDIF GOTO *ST HALT</pre>	<pre>.....Stops and resets the program</pre>

In PTP movement specified by movement commands such as MOVE and DRIVE, the next line's command is executed when the axis enters the effective OUT position range.

Therefore, if a HOLDALL command exists immediately after a PTP movement command, that HOLDALL command is executed before the axis arrives in the target position tolerance range.

Likewise, when specifying CONT options in interpolation movement during MOVE (L or C) command, the next command is executed immediately after movement starts. Therefore, if a HOLDALL command exists immediately after the interpolation movement command during MOVE (L or C) command with CONT options, a HOLDALL command is executed immediately after starting movement.

In either of the above cases, use the WAIT ARM command as shown below if desiring to execute the HOLDALL command after the axis arrives within the target position tolerance range.

HOLDALL command

33702-R9-00

51.1 Simple IF statement

Format

IF <i>conditional expression</i> THEN	<i>label 1</i> <i>command 1</i>	ELSE	<i>label 2</i> <i>command 2</i>
---------------------------------------	------------------------------------	------	------------------------------------

Value

Range (Specifying format)

conditional expression Input/Output signals or variables

Explanation This type of IF statement is available to write only when the conditional expression is "true" or when the number of <command> executed in the "false" condition is one.

If the condition specified by the <conditional expression> is met **true**:

processing jumps either to the <label 1> which follows THEN,

or

to the next line after <command 1> is executed.

If the condition specified by the <conditional expression> is not met **false**:

1. Processing either jumps to the <label 2> specified after the ELSE statement,

or

to the next line after <command 2> is executed.

2. If nothing is specified after the ELSE statement, no action is taken, and processing simply jumps to the next line.

MEMO

When the conditional expression used to designate the IF statement condition is a numeric expression, an expression value other than "0" indicates a TRUE status, and "0" indicates a FALSE status.

Sample

```
IF DI(20)=1 THEN *MAIN1 ELSE *MAIN2
:
*MAIN1:
DO(20)=1
:
*MAIN2:
DO(21)=1
:
```

Description

.....If DI(20) is ON "True",
Jumps to label *MAIN1

If DI(20) is OFF "false",
Jumps to label *MAIN2

51.2 Block IF statement

Format

```

IF conditional expression 1 THEN
  command block 1
ELSEIF conditional expression 2 THEN
  command block 2
ELSE
  command block n
ENDIF

```

Value	Range (Specifying format)
<i>conditional expression</i>	Input/Output signals or variables

Explanation If the condition specified by *<conditional expression 1>* is met (true), this statement executes the instructions specified in *<command block 1>*, then jumps to the next line after ENDIF.

When an ELSEIF statement is present and the condition specified by *<conditional expression 2>* is met (true), the instructions specified in *<command block 2>* are executed.

If all the conditions specified by the conditional expression are not met (false), *<command block n>* is executed.

MEMO

When the conditional expression used to designate the IF statement condition is a numeric expression, an expression value other than "0" indicates a TRUE status, and "0" indicates a FALSE status.

Sample 1 (Block IF statement 1)	Description
MOVE P,P1,A3=0.00	
IF DI(20)=1 THENWhen DI(20) is ON, executes "true" command block.
DO(20)=1From this line, "true" command block
MOVE P,P10,A3=0.00	
DO(20)=0Down to this line, "true" command block
ELSEWhen DO(20) is OFF, executes "false" command block.
DO(21)=1From this line, "false" command block
MOVE P,P11,A3=0.00	
DO(21)=0Down to this line, "false" command block
ENDIFDefinition end of IF statement
MOVE P,P20,A3=0.00Jumps to this line after executing the IF statement
:	

Sample 2 (Block IF statement 2)	Description
MOVE P,P1,A3=0.00	
IF DI(20)=1 THENWhen DI(20) is ON, executes "true" command block.
DO(20)=1From this line, "true" command block
MOVE P,P10,A3=0.00Down to this line, "true" command block
ENDIFDefinition end of IF statement
DO(20)=0Jumps to this line after executing the IF statement
:	

Format

INPUT <i>prompt statement</i>	;	<i>variable</i>	,	<i>variable</i>	,	...
	,	<i>point variable</i>		<i>point variable</i>		
		<i>shift variable</i>		<i>shift variable</i>		

Explanation Assigns a value to the variable specified from the programming box.

The input definitions are as follows:

- When two or more variables are specified by separating them with a comma (,), the specified input data items must also be separated with a comma (,).
- At the <prompt statement>, enter a character string enclosed in double quotation marks (") that will appear as a message requiring data input. When a semicolon (;) is entered following the <prompt statement>, a question mark (?) and a space will appear at the end of the message. When a comma (,) is entered, nothing will be displayed following the message.
- When the <prompt statement> is omitted, only a question mark (?) and a space will be displayed.
- The input data type must match the type of the corresponding variables. When data is input to a point variable or shift variable, insufficient elements are set to "0".
- If only the ENTER key is pressed without making any entry, the program interprets this as a "0" or "null string" input. However, if specifying two or more variables, a comma (,) must be used to separate them.
- If the specified variable is a character type and a significant space is to be entered before and after a comma (,), double quotation mark (") or character string, the character string must be enclosed in double quotation marks ("). Note that in this case, you must enter two double quotation marks in succession so that they will be identified as a double quotation mark input.

Entry Example	Result ; Contents of A\$
ABC	ABC
(space)ABC(space)	ABC: space is not entered before and after ABC
" ABC "	ABC : spaces are entered before and after ABC
ABC,XYZ	ABC is entered, and XYZ is entered when the next INPUT statement is executed.
"ABC,XYZ"	ABC,XYZ
""ABC""	"ABC"

- Pressing the ESC key skips this command.

 MEMO

- If the variable and the value to be assigned are different types, the specified message displays, and a "waiting for input" status is established.
- When assigning alphanumeric characters to a character variable, it is not necessary to enclose the character string in double quotation marks (").
- When using INPUT statement, the value is assigned to the variable from the channel specified in controller parameter "INPUT/PRINT using channel".

Sample	Description
INPUT AConverts the entered character string to a real number and assigns to variable A!.
INPUT "INPUT POINT NUMBER";A1Displays INPUT POINT NUMBER on a prompt of programming box, etc. and converts the entered character string to a real number and assigns to variable A!.
INPUT "INPUT STRING",B\$(0),B\$(1)Displays INPUT STRING on a prompt of programming box, etc. If commas are contained in the entered character string, the first character string is assigned to 0 element of the array variable B\$ and the second character string is assigned to its 1 element.
INPUT P100Assigns the entered character string to P100.
HALT	

A

B

C

D

E

F

G

H

I

J

K

L

M

INROFST

Specifies/acquires R axis inertia offset for SCARA parameter.

Format

INROFST [*robot number*] *expression*

Value**Range**

Robot Number

1 to 4 (If not input, robot 1 is specified.)

Expression

Value of R axis inertia offset for SCARA parameter
0 to 9999999 (units: 0.001mm)

Explanation Changes the value of "R axis inertia offset for SCARA" parameter of specified robot to the <expression> value.

Sample**Description**

INROFST 10Sets "R axis inertia offset for SCARA" parameter of robot 1 to 10.
INROFST[2] 20Sets "R axis inertia offset for SCARA" parameter of robot 2 to 20.

Functions**Format**

INROFST [*robot number*]

Value**Range**

Robot Number

1 to 4 (If not input, robot 1 is specified.)

Explanation This function acquires the value of "R axis inertia offset for SCARA" parameter of specified robot.

Sample**Description**

A%=INROFSTThe "R axis inertia offset for SCARA" parameter of robot 1 is assigned to the variable A%.
A%=INROFST[2]The "R axis inertia offset for SCARA" parameter of robot 2 is assigned to the variable A%.

Format

INT (*expression*)

Explanation This function acquires an integer value with decimal fractions truncated.
The maximum integer value which does not exceed the <*expression*> value is acquired..

Sample**Description**

A=INT(A(0))"-2" is assigned to B.
B=INT(-1. 233)	

A

B

C

D

E

F

G

H

I

J

K

L

M

JTOXY

Performs axis unit system conversions (pulse → mm)

FormatJTOXY [*robot number*] (*point expression*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)

Explanation Converts the joint coordinate data (unit: pulse) specified by the <*point expression*> into Cartesian coordinate data (unit: mm, degree) of the robot specified by the <*robot number*>.

Sample	Description
P10=JTOXY(WHERE)Current position data of robot 1 is converted to Cartesian coordinate data and assigned to P10.

Related commands XYTOJ

Format

LEFT\$ (*character string expression*, *expression*)

Value	Range
<i>Expression</i>	0 to 255

Explanation This function extracts a character string with the digits specified by the <expression> from the left end of the character string specified by <character string expression>.

- The <expression> value must be between 0 and 255; otherwise an error will occur.
- If the <expression> value is 0; extracted character string will be a null string (empty character string).
- If the <expression> value has more characters than the <character string expression>; extracted character string will become the same as the <character string expression>.

Sample	Description
B\$=LEFT\$(A\$,4)4 characters from the left end of A\$ are assigned to B\$.

Related commands MID\$, RIGHT\$

A

B

C

D

E

F

G

H

I

J

K

L

M

LEFTY

Sets the SCARA robot hand system as a left-handed system

FormatLEFTY [*robot number*]**Value***Robot Number***Range**

1 to 4 (If not input, robot 1 is specified.)


Explanation Specifies the robot as a left-handed system.
This command is only valid for SCARA robots.

This statement only specifies the hand system, and does not move the robot.

If executed while the robot arm is moving, execution waits until movement is complete (positioned within tolerance range).

Sample**Description**

RIGHTYSpecifies the hand system of robot 1 as a right-handed system.
MOVE P,P1(1)
LEFTYSpecifies the hand system of robot 1 as a left-handed system.
MOVE P,P1(2)
RIGHTYSpecifies the hand system of robot 1 as a right-handed system.
HALT	

SAMPLE:LEFTY/RIGHTY

33809-R7-00

Related commands

RIGHTY

Format

```
LEN(character string expression)
```

Explanation Returns the character string length of the *<character string expression>* as a number of bytes.

Sample	Description
A\$="YAMAHA"	
B\$="YAMAHA MOTOR"	
C\$="YAMAHA CO., LTD."	
PRINT LEN(A\$)Indicates "6".
PRINT LEN(B\$)Indicates "12".
PRINT LEN(C\$)Indicates "16".

A

B

C

D

E

F

G

H

I

J

K

L

M

Format

LET	<i>arithmetic assignment statement</i> <i>character string assignment statement</i> <i>point assignment statement</i> <i>shift assignment statement</i>
------------	--

Explanation Executes the specified assignment statement. The right-side value is assigned to the left side.
 An assignment statement can also be directly written to the program without using a LET statement.

MEMO

If the controller power is turned off during execution of a <point assignment statement> or <shift assignment statement>, a memory-related error such as the "9.702: Point data destroyed" or the "9.706: Shift data destroyed" may occur

59.1 Arithmetic assignment statement**Format**

LET	<i>integer variable</i> <i>real variable</i> <i>parallel output variable</i> <i>internal output variable</i> <i>arm lock output variable</i> <i>timer output variable</i> <i>serial output variable</i> <i>serial word output variable</i> <i>serial double-word output variable</i>	= <i>expression</i>
------------	--	---------------------

Value*Expression***Contents**Variables (except character string variables, point data variables, shift variables),
Function, Numeric value

Explanation The expression value is assigned to the left-side variable

Sample

```
A!=B!+1
B%(1,2,3)=INT(10.88)
DO2()=&B00101101
MO(21,20)=2
LO(00)=1
TO(01)=0
SO12()=255
```

Reference For details of assignment statements and output variables, refer to "5.1 Assignment statements" "5.2 Input/output variables" in Chapter 7.

59.2 Character string assignment statement

Format

```
LET character string variable = character string expression
```

Explanation The *<character string expression>* value is assigned to the character string variable. Only the plus (+) arithmetic operator can be used in the *<character string expression>*. Other arithmetic operators and parentheses cannot be used.

Sample

```
A$ ="YAMAHA"  
B$ ="ROBOT"  
D$ = A$ + "-" + B$
```

Execution result: YAMAHA-ROBOT

MEMO

The "+" arithmetic operator is used to link character strings..

59.3 Point assignment statement

Format

```
LET point variablee = point expression
```

Explanation Assigns *<point expression>* values to point variables. Only 4 arithmetic operators (+, -, *, /) can be used in the *<point expression>*. Multiplication and division are performed only for constant or variable arithmetic operations.

- Addition / Subtraction: Addition / subtraction is performed for each element of each axis.
- Multiplication / Division: Multiplication / division by a constant or variable is performed for each element of each axis.

Multiplication results vary according to the point data type.

- For "pulse" units: Assigned after being rounded to an integer.
- Assigned a real number after being rounded off to two decimal places.

Sample	Description
P1 =P10Point 10 is assigned to P1.
P20=P20+P5Each element of point 20 and point 5 is summed and assigned to P20.
P30=P30-P3Each element of point 3 is subtracted from point 30 and assigned to P30.
P80=P70*4Each element of point 70 is multiplied by 4 and assigned to P80.
P60=P5/3Each element of point 5 is divided by 3 and assigned to P60.

MEMO

- Permissible examples: P15 * 5, P[E]/A, etc.
- Prohibited examples: P10 * P11, 3/P10, etc.

59.4 Shift assignment statement

Format

```
LET shift variable = shift expression
```

Explanation Assigns <shift expression> values to <shift variables>.

- Available elements in <shift expressions> are only shift elements.
- Available operators in <shift expressions> are only addition and subtraction arithmetic operators.
*Addition/subtraction is performed for each element of each axis.
- Parentheses are not available.

Sample	Description
S1=S0"shift 0" is assigned to "shift 1".
S2=S1+S0Each element of "shift 1" and "shift 0" is summed and assigned to "shift 2".

MEMO

- Permissible examples: S1 + S2
- Prohibited examples: S1 + 3

Format

1. `LET LOm (b, ..., b) = expression`
2. `LET LO (mb, ..., mb) = expression`

Notation	Value	Range
m	Port Number	0, 1
b	Bit Definition(*)	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	Expression	Integer value (If real number is specified, rounds to an integer.) Bits beyond the number of bit whom an assignment destination is required are ignored. (If the port number is specified, the lower 8 bits are valid. if the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)

Explanation This statement outputs the specified value to the LO port to either prohibit or allow axis movement.

- LO(00) to LO(07) correspond to axes 1 to 8, LO(10) to LO(17) correspond to axes 9 to 16, respectively.
- An arm lock ON status occurs at axes where bits are set, and axis movement is prohibited.

Reference * Chapter 3 "10 Bit Settings"

MEMO

.....
 This statement is valid for axes whose movement is started.

Sample	Description
<code>LO0()=&B00001010</code>Prohibits movement at axes 2 and 4.
<code>LO0(2,1)=&B10</code>Prohibits movement at axis 3, permits movement at axis 2.

Functions

Format

1. `LET expression = LOm (b, ..., b)`
2. `LET expression = LO (mb, ..., mb)`

Notation	Value	Range
m	Port Number	0, 1
b	bit Definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).

Explanation Acquires the output status of the specified LO port.

- LO(00) to LO(07) correspond to axes 1 to 8, LO(10) to LO(17) correspond to axes 9 to 16, respectively.
- An arm lock ON status occurs at axes where bits are set, and axis movement is prohibited.

Sample	Description
<code>A%= LO0()</code>Output status of ports DO(07) to LO(00) is assigned to variable A%.
<code>A%= LO0(6, 5, 1)</code>Output status of LO(06), LO(05) and LO(01) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
<code>A%=LO(17,15,00)</code>Output status of L0(17), LO(15) and L0(00) is assigned to variable A%. (If all above signals except L0(15) are 1 (ON), then A%=5.)

Related commands RESET, SET

Format

1. LOCx (*point expression*) = *expression*
2. LOCx (*shift expression*) = *expression*
3. LOCx (Wn) = *expression*

	Value	Range / Meaning
Format 1	x	1 to 6 (axis setting) F (hand system flag setting) F1 (first arm rotation information) F2 (second arm rotation information)
Format 2	x	1 to 4 (element setting)
Format 3	x	1 to 4 (element setting)
	n	0 to 39 (work number)
	<i>Expression</i>	<ul style="list-style-type: none"> • For Axis or element setting: coordinate value, variables • For Hand system flag setting: 0 (no setting), 1 (right-handed system), 2 (left-handed system) • For first / second arm rotation information(*1): 0, 1, -1
*1: The first arm and the second arm rotation information is only for YK-TW. For details, refer to Chapter 4 "3. Point data format".		

Explanation Format 1: Changes the value of the point data specified axis, the hand system flag, and the first arm and the second arm rotation information.

Format 2: Changes the value of a specified element from the shift coordinate data.

Format 3: Changes the value of a specified element from the work data.

**NOTE**

When changing the work data, execution will be in a waiting state until the operation of the target robot enters within the tolerance range.

(For LOCx during conveyor tracking, refer to the separate manual "Tracking System" CTMOVE.)

MEMO

Points where data is to be changed must be registered in advance. An error occurs when attempting to change an unregistered (no coordinate values / no element data) point, shift coordinate, or work data.

A

B

C

D

E

F

G

H

I

J

K

L

M

Functions

Format

1. LOCx (*point expression*)
2. LOCx (*shift expression*)
3. LOCx (Wn)

	Value	Range
Format 1	x	1 to 6 (axis setting) F (hand system flag setting) F1 (first arm rotation information) F2 (second arm rotation information)
Format 2	x	1 to 4 (element setting)
Format 3	x	1 to 4 (element setting)
	n	0 to 39 (work number)
<i>Expression</i> For Axis or element setting: coordinate value, variables		

- Explanation** Format 1: Acquires the value of the point data specified axis, the hand system flag, and the first arm and the second arm rotation information.
 Format 2: Acquires a specified axis element from the shift coordinate data.
 Format 3: Acquires a specified axis element from the work data.

Sample	Description
LOC1(P10)=A(1)Axis 1 data of P10 is changed to the array A (1) value.
LOC2(S1)=B2nd element (Y direction) of S1 is changed to the B value.
LOC3(W1)=C3rd element (Z direction) of W1 is changed to the C value.
A(1)=LOC1(P10)Axis 1 data of P10 is assigned to array A (1).
B(2)=LOC1(S1)1st element (X direction) of S1 is assigned to array B (2).
C(3)=LOC1(W1)1st element (X direction) of W1 is assigned to array C (3).

Related commands Point variable, Shift variable, Work data

Format

```
LSHIFT (expression 1, expression 2)
```

Explanation Shifts the *<expression 1>* bit value to the left by the amount of *<expression 2>*. Spaces left blank by the shift are filled with zeros (0).

Sample	Description
A=LSHIFT(&B10111011,2)The 2-bit-left-shifted &B10111011 value (&B11101100) is assigned to A.

Related commands **RSHIFT**

A

B

C

D

E

F

G

H

I

J

K

L

M

MCHREF

Acquires the machine reference value (axes: sensor method / stroke-end method)

FormatMCHREF [*robot number*] (*axis number*)**Value****Range***Robot Number* 1 to 4 (If not input, robot 1 is specified.)*Axis Number* 1 to 6**Explanation**

This function returns the return-to-origin or absolute-search machine reference value (unit: %) of specified axes.

This function is valid only for axes whose return-to-origin method is set as "Sensor" or "Stroke-end".

Sample**Description**

A=MCHREF(1)

.....The machine reference of axis 1 of robot 1 is assigned to variable A.

Format

MID\$ (*character string expression*, *expression 1*, *expression 2*)

Value	Range
<i>Expression 1</i>	1 to 255
<i>Expression 2</i>	0 to 255

Explanation This function extracts a character string of a desired length (number of characters) from the character string specified by <character string expression>. <expression 1> specifies the character where the extraction is to begin, and <expression 2> specifies the number of characters to be extracted.

- If the <expression 1> and <expression 2> values violate the permissible value ranges, An error will occur
- If <expression 2> is omitted, or if the number of characters to the right of the character of <expression 1> is less than the value of <expression 2>, then all characters to the right of the character specified by <expression 1> will be extracted.
- If <expression 1> is longer than the character string, the extracted value will be a null string (empty character string).

Sample	Description
B\$=MID\$(A\$,2,4)The 2nd to 4th characters (up to the 5th characters) of A\$ are assigned to B\$.

Related commands LEFT\$, RIGHT\$

Outputs a specified value to the MO port or acquires the output status

Format

1. `LET MOm(b, ..., b) = expression`
2. `LET MO(mb, ..., mb) = expression`

Notation	Value	Range / Meaning
m	Port Number	2 to 7, 10 to 17, 20 to 27, 30 to 37
b	Bit Definition(*)	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	Expression	Integer value (If real number is specified, rounds to an integer.) Bits beyond the number of bit whom an assignment destination is required are ignored. (If the port number is specified, the lower 8 bits are valid. if the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)

Explanation Outputs a specified value to the MO port.

In order to maintain the origin sensor status and axis HOLD status at each axis, ports "30" to "37" cannot be used as output ports (these ports are for referencing only). (Ports 32, 33, 36, and 37 are reserved by the system.)

Reference * Chapter 3 "10 Bit Settings"

Ports "30", "31", "34", and "35" outputs

Bit	7	6	5	4	3	2	1	0
Port 30	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1
Port 31	Axis 16	Axis 15	Axis 14	Axis 13	Axis 12	Axis 11	Axis 10	Axis 9
Origin sensor status 0: ON; 1: OFF (Axis 1 is not connected)								
Port 34	Axis 8	Axis 7	Axis 6	Axis 5	Axis 4	Axis 3	Axis 2	Axis 1
Port 35	Axis 16	Axis 15	Axis 14	Axis 13	Axis 12	Axis 11	Axis 10	Axis 9
HOLD status 0: No HOLD / 1: HOLD (Axis 1 is not connected)								

MEMO

For details regarding MO ports "30" to "37", refer to Chapter 3 "9.5 Internal output variable".

Sample	Description
<code>MO2()=&B10111000</code>MO(27,25,24,23) are turned ON, and MO(26,22,21,20) are turned OFF.
<code>MO2(6,5,1)=&B010</code>MO(25) are turned ON, and MO (26,21) are turned OFF.
<code>MO3() = 15</code>MO(33,32,31,30) are turned ON, and MO(37,36,35,34) are turned OFF.
<code>MO(37,35,27,20)=A</code>The contents of the 4 lower bits acquired when variable A is converted to an integer are output to MO(37,35,27,20), respectively.

Functions

Format

1. `LET expression = MOm(b, ..., b)`
2. `LET expression = MO(mb, ..., mb)`

Notation	Value	Range
m	Port Number	2 to 7, 10 to 17, 20 to 27, 30 to 37
b	bit Definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	<i>Expression</i>	Integer value (If real number is specified, rounds to an integer.) Bits beyond the number of bit whom an assignment destination is required are ignored. (If the port number is specified, the lower 8 bits are valid. if the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)

Explanation Acquires the output status of the specified MO port.

Sample	Description
<code>A%= MO0()</code>Output status of ports MO(07) to MO(00) is assigned to variable A%.
<code>A%= MO0(6, 5, 1)</code>Output status of MO(06), MO(05) and MO(01) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
<code>A%=MO(17,15,00)</code>Output status of M0(17), MO(15) and M0(00) is assigned to variable A%. (If all above signals except M0(15) are 1 (ON), then A%=5.)
<code>A%=MO(377,365,255,123)</code>Output status of M0(377), MO(365), MO(255) and M0(123) is assigned to variable A%. (If all above signals except M0(15) are 1 (ON), then A%=15.)

Related commands RESET, SET

MOTOR

Controls the motor power status

Format

MOTOR	ON OFF PWR	
-------	------------------	--

Explanation This command controls the motor power on/off. The servo on/off of all robots can also be controlled at the same time.

- ON: Turns on the motor power. All robot servos are also turned on at the same time.
- OFF: Turns off the motor power. All robot servos are also turned off at the same time to apply the dynamic brake. For the axis with the brake, the brake is applied to lock it.
- PWR: Turns on only the motor power.

Sample Description

MOTOR ONTurns on the motor power and all robot servos.
----------	---

Format

MOVE <i>robot number (axis number, ...)</i>	PTP	, <i>point of destination</i> , <i>option</i> ,
	P	<i>option...</i>
	L	
	C	

Explanation Executes absolute movement of robot (axis).

It is not enabled for axes of other robots or for auxiliary axes.

Value	Range / Type
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6 (Multiple axes specifiabl. If not input, all axes are specified.)
PTP, P, L, C	Movement type. PTP/P: PTP, L: Linear interpolation, C: Circular interpolation
<i>Point of Destination</i>	Robot stopping (target) position. Specify the following data format: • Direct numeric value (coordinate data) • Point definition (Point number) • Point name* * For the method of adding/editing point name, refer to "Point editing" in RCX 3 user's manual.
<i>Option</i> multiple options specifiable	Relative Speed setting, Absolute speed setting, Linear speed setting Arch motion setting STOPON condition setting, CONTON condition setting, CONT setting, Acceleration setting, Deceleration setting, Plane coordinate setting, Port output setting

Options	PTP	Linear interpolation	Arch interpolation	Remarks
Relative speed setting (SPEED)	✓	✓	✓	Enabled only in specified MOVE statement
Absolute speed setting (DSPEED)	✓	✓	✓	Enabled only in specified MOVE statement
Linear speed setting (VEL)	–	✓	✓	Enabled only in specified MOVE statement
Arch motion	✓	–	–	Enabled only in specified MOVE statement
STOPON condition setting	✓	✓	✓	Enabled only when program execution
CONTON condition setting	✓	✓	✓	Enabled only when program execution
CONT setting	✓	✓	✓	Enabled only in specified MOVE statement
Acceleration setting	✓	✓	✓	Enabled only in specified MOVE statement
Deceleration setting	✓	✓	✓	Enabled only in specified MOVE statement
Plane coordinate setting	–	–	✓	Enabled only in specified MOVE statement
Port output setting	–	✓	✓	Enabled only in specified MOVE statement

Movement type

● PTP (point-to-point) movement (MOVE P)

Robot moves from the currently stopping position to the specified point position along the shortest path for each axis. The path is thus not a straight line.

- Execution START condition: Movement of all specified axes is complete (within the tolerance range*¹).
- Execution END condition: All specified axes have entered the OUT position range*².

When two or more axes are specified, they will reach their target positions simultaneously. The movement path of the axes is not guaranteed.

Sample	Description
MOVE P,P0Robot 1 moves from its current position to the position specified by P0. (the same occurs for MOVE PTP, P0).
MOVE P,END _ POINTRobot 1 moves from its current position to the position specified by point name "END _ POINT".


MEMO

- PTP movement is faster than interpolation movement, but when executing continuous movement to multiple points, a positioning stop occurs at each point.
- Refer to "Point editing" in RCX3 user's manual for details of adding and editing point names.

*1) Axis parameter "Tolerance <TOLE>"

This parameter sets the positioning completion range to the target position when the robot moves.

When the current position of the robot enters the specified range, this is judged to the positioning completion.



Note) Depending on the movement type, the timing of the command completion (the timing when the command on the next line is executed) differs from one judged to the positioning completion .

***2) Caution regarding commands which follow the MOVE P command; Axis parameter "OUT position <OUTPOS>"**

This parameter sets the execution completion range to the target position when a PTP movement command is executed.


If the next command following the MOVE P command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position tolerance range.

Signal output (DO, etc.)	Signal is output when the axis enters within OUT position range.
DELAY	DELAY command is executed and standby starts, when the axis enters the OUT position range.
HALT	Program stops and is reset when the axis enters the OUT position range. Therefore, the axis movement also stops.
HALTALL	All programs in execution stop when the axis enters the OUT position range, task 1 is reset, and other tasks terminate. Therefore, the movement also stops.
HOLD	Program temporarily stops when the axis enters the OUT position range. Therefore, the axis movement also stops.
HOLDALL	All programs in execution temporarily stop when the axis enters the OUT position range. Therefore, the movement also stops.
WAIT	WAIT command is executed when the axis enters the OUT position range.

The WAIT ARM statements are used to execute the next command after the axis enters the tolerance range.

MEMO

The OUT position value is specified by parameter setting. This value can be changed within the program by using the OUTPOS command.



● Linear interpolation movement (MOVE L)

Robot follows the linear path made by connecting 2 dots between the currently stopping position and the specified point position.

- Execution START condition: Movement of all specified axes is complete (within the tolerance range).
- Execution END condition: Movement of all specified axes has begun (within the tolerance range).

All movement axes arrive at the same time.



CAUTION

For the continuous motion specified by several points, **CONT setting (continuous motion)** is required. In RCX340/RCX320, the motion of interpolation movement command and END condition are different from conventional model. Addition of the CONT setting to the movement command allows to the equivalent movement and END condition in conventional model.




MEMO

On robots with R-axis, the R-axis speed may become too fast and cause an error, depending on the R-axis movement distance.


Sample	Description
MOVE L,P0,P1The robot 1 moves (linear interpolation movement) from its current position to the position specified by P0, P1.

SAMPLE:MOVE L




Movement command types and the corresponding movement

1. PTP movement



2. Interpolation movement



● Circular interpolation movement (MOVE C)

Robot follows the circular path made by connecting 3 dots between the currently stopping position and the specified point positions.

In circular interpolation, an arc is generated based on 3 points: the current position, an intermediate position, and the target position. **Therefore, circular interpolation must be specified by an even number of points.**

- Execution START condition: Movement of all specified axes is complete (within the tolerance range).
- Execution END condition: Movement of all specified axes has begun.

All movement axes arrive at the same time.




CAUTION

In RCX340/RCX320, the motion of interpolation movement command and END condition are different from conventional model. Addition of the CONT setting to the movement command allows to the equivalent movement and END condition in conventional model.

Sample	Description
MOVE L,P20Linear interpolation movement of robot 1 occurs from the current position to P20.
MOVE C,P21,P22,P23,P20Circular interpolation movement occurs through points P21, P22, P23, P20.
MOVE L,P24Linear interpolation movement occurs to P24.

SAMPLE:MOVE C



MEMO

- Circular interpolation is possible within the following range: radius 0.100mm to 5,000.000mm.
- In order to create a locus of closed circle, connect 2 arcs.
- Circle distortion may occur, depending on the speed, acceleration, and the distance between points.
- On robots with an R-axis, the R-axis speed may become too fast and cause an error, depending on the R-axis movement distance.

Point data setting types

● Direct numeric value input

PTP

Linear interpolation

Circular interpolation

Format

p1 p2 p3 p4 p5 p6 f f1 f2

Notation	Value
p1 to p6	Space-separated coordinate values for each axis
f	Hand system flag (SCARA robot only)
f1	First arm rotation information (YK-TW series only)
f2	Second arm rotation information (YK-TW series only)

Explanation

Directly specifies coordinate data by a numeric value. Units for the coordinate is as follows;

- Integer: "pulse" units
- Real number (with decimal point): "mm/deg." units
- Integers and real numbers (mixed): All coordinate values will be handled in "mm/deg." units.

The types of movements in which this specification is possible are the PTP movement and the linear interpolation movement.

Notation: f) SCARA robots with coordinate data in "mm" units --> Hand system flags can be specified. (*1)

To set the hand system flag, set either 1 or 2 at "f".

If a number other than 1 or 2 is set, or if no number is designated, 0 will be set to indicate that there is no hand system flag.

f	0	Hand system flag is not set. Any value other than 1 / 2, or no setting.
	1	Right-handed system is used to move to a specified position.
	2	Left-handed system is used to move to a specified position.

Notation: f1,2) YK-TW series with coordinate data in "mm" units -->

The first and second arm rotation information can be specified. (*1)

To set the rotation information, set "-1", "0", or "1" at f1 and f2.

Any other value or no setting will be processed as "0".

f1, 2	0	Indicates arm rotation information where movement to the "0" position has been specified. Any value other than -1 / 0 / 1, or no setting.
	1	Indicates arm rotation information where movement to the "1" position has been specified.
	-1	Indicates arm rotation information where movement to the "-1" position has been specified.

Reference

*1: Chapter 4 "3. Point data format"



CAUTION

- When performing linear interpolation with a hand system flag specified, be sure that the same hand system is used at the current position and target position. If the hand system are different, an error will occur and robot movement will be disabled.
- When performing a linear interpolation, the current position's first arm and second arm rotation information must be the same as the movement destination's first arm and second arm rotation information. If the two are different, an error will occur and movement will be disabled.

 MEMO

At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

Sample	Description
MOVE P,10000	10000 1000 1000 0 0PTP movement of robot 1 occurs from current position to the specified position.
MOVE P,100.0	100.0 50.0 45.0 0.0 0.0 2PTP movement of robot 1 occurs from current position to the specified position with Left-handed system.
MOVE P,-180.0	-430.0 50.0 180.0 0.0 0.0 1 -1 1PTP movement of robot 1 occurs from current position to the specified position (first arm: -180°to 360°, second arm: 180° to 360°) with right-handed system.

● Point definition

PTP **Linear interpolation** **Circular interpolation**

Format

point expression , *point expression...*

Explanation Specifies a <point expression>. Two or more data items can be designated by separating them with a comma (,).
Circular interpolation must be specified by an even number of points.



CAUTION

When moving the robot by linear or circular interpolation to a point where a hand system flag is specified, be sure that the same hand system is used at both the current and target positions. If the hand system are different, an error will occur and robot movement will be disabled.

 MEMO

At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

Sample	Description
MOVE P,P1Robot 1 moves from the current position to the position specified by P1.
MOVE P,P20,P0,P100Robot 1 moves in sequence from the current position to positions specified by P20, P0, P100.



CAUTION

When performing a linear and circular interpolation, the current position's first arm and second arm rotation information must be the same as the movement destination's first arm and second arm rotation information. If the two are different, an error will occur and movement will be disabled.

● Point name definition

PTP Linear interpolation Circular interpolation

Format

```
point name , point name...
```

Explanation Specifies a <point name>. Two or more data items can be designated by separating them with a comma (,). Circular interpolation must be specified by an even number of points.

 MEMO

At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting

Sample	Description
MOVE P,PICK_POINTRobot 1 moves from the current position to positions specified by the point name "PICK_POINT".
MOVE C, CIRCLE_PNT1,CIRCLE_PNT2Robot 1 moves in coordinates specified by the current position and point name "CIRCLE_PNT1" and "CIRCLE_PNT2" in circular interpolation movement.

Option types

● Relative speed setting (SPEED)

PTP Linear interpolation Circular interpolation

Format

1. SPEED = expression
2. S = expression

Value Range

Expression	1 to 100 (units: %)
------------	---------------------

Explanation Specifies the program speed in an <expression>.

Robot max. speed (mm/sec or deg/sec) × automatic movement speed (%) × program movement speed S (%)

"S" setting superimposes the speed on the current automatic movement speed.

automatic movement speed (%) × program movement speed S (%) = actual speed (%)

100%	50%	50%
50%	50%	25%



NOTE

This option specifies only the maximum speed and does not guarantee the movement at the specified speed.

- Automatic movement speed: Specified by programming box operation or by the ASPEED command.
- Program movement speed: Specified by SPEED commands or MOVE, DRIVE speed settings.

Sample (Automatic movement speed: 80%)	Description
MOVE P,P0PTP movement to P0 (Actual speed is 80%)
MOVE P,P1,S=50PTP movement to P1 (Actual speed is 40%)

● **Absolute speed setting (DSPEED)**

PTP Linear interpolation Circular interpolation

Format

1. DSPEED = *expression*
2. DS = *expression*

Value	Range
<i>Expression</i>	0.01 to 100.00 (units: %)

Explanation Specifies the ratio to the maximum speed of the robot. (This setting is enabled only for the specified MOVE statement.)

Robot max. speed (mm/sec. or deg./sec.) × movement speed DS (%)

Movement always occurs at the DSPEED <expression> value (%) without being affected by the automatic movement speed value (%).



NOTE SPEED option and DSPEED option cannot be used together.

Sample (Automatic movement speed: 80%)	Description
MOVE P,P0PTP movement to P0 (Actual speed is 80%)
MOVE P,P1,DS=50PTP movement to P1 (Actual speed is 40%)
MOVE P,P2,DS=0.1PTP movement to P2 (Actual speed is 0.1%)

● **Speed setting (VEL)**

PTP Linear interpolation Circular interpolation

Format

VEL = *expression*

Value	Range
<i>Expression</i>	0.01 to 100.00 (units: %)

Explanation Specifies the maximum composite speed (in "mm/sec." units) of the XYZ axes in an <expression>. This option is enabled only for the specified MOVE statement.

The setting "VEL=" moves a robot in the specified velocity regardless of automatic movement speed.



- NOTE**
- This option specifies only the maximum resultant speed and does not guarantee movement at the specified speed.
 - Although the values after decimal point can be entered, it is removed when execution and does not affect the motion.

Sample	Description
MOVE L,P10,VEL=100Robot 1 moves from the current position to the position specified by P10 at the maximum composite speed of 100 mm/sec. of the XYZ axis.

● Arch motion setting

PTP

Linear interpolation

Circular interpolation

Format

 $x = \text{expression} \{ \text{expression 1}, \text{expression 2} \}$

Value	Contents
x	Specifies an arch axis from A1 to A6
Expression	Arch position (Specify with Direct numeric value / or / Variable) Integer value: "pulse" units. Real number (with decimal point): "mm/deg." units.
Expression 1	Linear distance from the start (current) position; Arch distance 1 Integer value: "pulse" units. Real number (with decimal point): "mm/deg." units.
Expression 2	Linear distance to the end (target) position; Arch distance 2 Integer value: "pulse" units. Real number (with decimal point): "mm/deg." units.

MEMO

- When there is a real value in any of the *<expression>*, *<expression 1>*, and *<expression 2>*, all expressions are handed as real value.
- The Value specified in *<expression>* is based on the robot coordinates. Settings such as hand definition and work definition are not considered.

Explanation

1. The "x" specified axis begins moving toward the position specified by the *<expression>* ("1" shown in the Fig. below).
2. When the axis specified by "x" moves the arch distance 1 or more, other axes move to their target positions ("2" shown in the figure below).
3. The axis specified by "x" moves to the target position so that the remaining movement distance becomes the arch distance 2 when the movement of other axes is completed ("3" shown in the figure below).
4. The command ends when all axis enter the OUT position range.

This option can be used only for PTP movement.


When the axis specified by "x" is the first arm or second arm of the SCARA robot or the axis 1 or axis 2 of the XY robot, the *<expression>* and target position value are limited to an integer (pulse units).



NOTE


The axis arch distance parameters can be changed using ARCHP1/ARCHP2 (arch pulse1 and 2 are equivalent to arch distance 1 and 2, respectively). The smaller the value, the shorter the movement execution time.

Sample	Description
MOVE P,P0,A3=0.00 {50.00, 70.00}The A3-axis moves from the current position to the "0.00 mm" position. After that, other axes move to P0. Finally, the A3-axis moves to P0.



MEMO

When multiple points are specified in PTP movement, the axis in arch motion setting also moves to the target position.



● **STOPON condition setting**

PTP **linear interpolation** **Circular interpolation**

Format

STOPON *conditional expression*

Explanation

Stops movement when the conditions specified by the conditional expression are met. Because this is a deceleration type stop, **there will be some movement (during deceleration) after the conditions are met.**

If the conditions are already met before movement begins, no movement occurs, and the command is terminated.


This option can only be used for PTP movement and linear interpolation movement.
 This option is enabled only when program execution.



CAUTION

If STOPON condition is simultaneously specified with CONTON and CONT setting, the lower setting will be invalidated as shown below;
 STOPON condition setting > CONTON condition setting > CONT setting

Sample	Description
<pre>MOVE P,P0,STOPON DI(20)=1 MOVE P, P1</pre>	<p>.....Robot 1 moves from the current position to the position specified by P100. If the "DI (20) = 1" condition is met during movement, a deceleration and stop occurs. The next step (PTP movement to P1) is then executed.</p>



MEMO

When the conditional expression used to designate the STOPON condition is a numeric expression, expression value other than "0" indicates a TRUE status, and "0" indicates a FALSE status.

● CONTON condition setting (Continuous Motion)

PTP

linear interpolation

Circular interpolation

Format

CONTON *conditional expression*

Explanation When the conditions specified by the conditional expression are met, the robot starts deceleration stop and executes the next command without waiting the movement completion (entering the tolerance range) of axis.

The deceleration movement distance will be generated during the deceleration stop.

If the next command is a movement command, the 2 movement paths are linked by connecting the deceleration and acceleration sections, enabling continuous movement without intermediate stops.

- If the conditions are not met, the robot moves to the specified target position and terminates the command.
- This option is enabled only when a program execution.




CAUTION

If STOPON condition is simultaneously specified with CONTON and CONT setting, the lower setting will be invalidated as shown below;

STOPON condition setting > CONTON condition setting > CONT setting

Sample	Description
MOVE P,P1,CONTON DI(20)=1Robot 1 moves from the current position to the position specified by P1. If the "DI (20) = 1" condition is met during movement, the robot starts decelerating and executes the next step.

Difference from STOPON condition setting



MEMO

When < conditional expression > is a numeric expression, expression value other than "0" indicates a TRUE status, and "0" indicates a FALSE status.

● **CONT setting (Continuous Motion)**

PTP **Linear interpolation** **Circular interpolation**

Format

CONT

Explanation When movement is executed with CONT setting option, Movable axes will begin to execute the next command without waiting the completion their movement (entering the tolerance range). If the next command is a movement command, the 2 movement paths are linked by connecting the deceleration and acceleration sections, enabling continuous movement without intermediate stops. This option is enabled only for the specified MOVE statement.



CAUTION

- In RCX340/RCX320, the motion of interpolation movement command and END condition are different from conventional model. Addition of the CONT setting to the movement command allows to the equivalent movement and END condition in conventional model.
- If STOPON condition is simultaneously specified with CONTON and CONT setting, the lower setting will be invalidated as shown below;
STOPON condition setting > CONTON condition setting > CONT setting



NOTE


The CONT setting can be used to reduce the movement END positioning time. The path to the target point is not guaranteed.

Caution regarding MOVE L / MOVE C command with CONT setting:

If the next command following the MOVE L / MOVE C command with CONT setting is an executable command such as a signal output command, that next command will start immediately after axis movement begins. In other words, that next command starts before the axis arrives within the target position tolerance range.

Signal output (DO, etc.)	Signal is output immediately after movement along the final path begins.
DELAY	DELAY command is executed and standby starts immediately after movement along the final path begins.
HALT	Program stops and is reset immediately after movement along the final path begins. Therefore, axis movement also stops.
HALTALL	All programs in execution stop immediately after movement along the final path begins, task 1 is reset, and other tasks terminate. Therefore, the movement also stops.
HOLD	Program temporarily stops immediately after movement along the final path begins. Therefore, axis movement also stops.
HOLDALL	All programs in execution temporarily stop immediately after movement along the final path begins. Therefore, the movement also stops.
WAIT	WAIT command is executed immediately after movement along the final path begins.


MOVE command



33808-R9-00

Sample	Description
MOVE P,P10,P11,CONTRobot 1 Moves from the current position to the position specified by P10, and then moves to P11 without waiting for the moving axes to arrive in the tolerance range.

SAMPLE:MOVE P CONT




33814-R7-00

Sample	Description
MOVE L,P10,CONT MOVE L,P11Robot 1 Moves from the current position to the position specified by P10, and then moves (linear interpolation movement) to P11 without waiting for the moving axes to arrive in the tolerance range, and completes the movement within the tolerance range.

MEMO

The interpolation movement with CONT setting doesn't stop at intermediate points in the continuous movement.

SAMPLE:MOVE L CONT



33810-R9-00

● Acceleration setting

PTP Linear interpolation Circular interpolation

Format	
ACC = <i>expression</i>	
Value	Range
<i>Expression</i>	1 to 100 (units: %)

Explanation Specifies the robot acceleration rate in the <expression>. The actual robot acceleration is determined by the acceleration coefficient parameter setting.

$$\text{Acceleration coefficient Parameter} \times \text{Acceleration}$$

This option is enabled only for the specified MOVE statement.

Sample	Description
MOVE L,P100,ACC=10Robot 1 moves at an acceleration rate of 10% from the current position to the position specified by P100.

● Deceleration setting

PTP Linear interpolation Circular interpolation

Format	
DEC = <i>expression</i>	
Value	Range
<i>Expression</i>	1 to 100 (units: %)

Explanation Specifies the robot deceleration rate in an <expression>. The actual robot deceleration is determined by the acceleration coefficient parameter setting (the setting is specified as a percentage of the acceleration setting value (100%).

$$\text{Acceleration coefficient Parameter} \times \text{Deceleration}$$

This option is enabled only for the specified MOVE statement.

Sample	Description
MOVE L,P100,DEC=20Robot 1 moves at a deceleration rate of 20% from the current position to the position specified by P100.

● Coordinate plane setting

PTP Linear interpolation **Circular interpolation**

Format	
	XY
	YZ
	ZX
Value	Meaning
XY	XY coordinate plane
YZ	YZ coordinate plane
ZX	ZX coordinate plane

Explanation When circular interpolation is executed by setting coordinates, this option executes circular interpolation so that the projection on the specified coordinate plane becomes a circle. This option can be used for circular interpolation movement and is enabled only for the specified MOVE statement.




NOTE

- If no coordinate plane is specified, the robot moves along a 3-dimensional circle.
- When a 2-axis robot is used, the robot moves along a circle on the XY plane.

Sample	Description
P10 = 100.000 100.000 20.000 0.000 0.000 0.000	
P11 = 150.000 100.000 0.000 0.000 0.000 0.000	
P12 = 150.000 150.000 20.000 0.000 0.000 0.000	
P13 = 100.000 150.000 40.000 0.000 0.000 0.000	
MOVE P,P10Robot 1 moves from the current position to the position specified by P10.
MOVE C,P11,P12	
MOVE C,P13,P10Moves continuously along a 3-dimensional circle generated at P10, P11, P12, and P12, P13, P10(1)
MOVE C,P11,P12,XY	
MOVE C,P13,P10,XYMoves continuously along a circle on an XY plane generated at P10, P11, P12, and P12, P13, P10. Z-axis moves to the position specified by P12 and P10 (the circle's target position)(2)

SAMPLE MOVE C coordinate plane



33822-R9-00

● Port output setting

PTP Linear interpolation Circular interpolation

Format	
DO	$m(b, \dots, b) = \text{expression 1} @ \text{expression 2}$
MO	
SO	

Format	
DO	$(mb, \dots, mb) = \text{expression 1} @ \text{expression 2}$
MO	
SO	

Notation	Value	Range
m	Port Number	2 to 7, 10 to 17, 20 to 27
b	bit Definition(*)	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	<i>Expression 1</i>	Value which is output to the specified port (only integers are valid).
	<i>Expression 2</i>	Position where the port output occurs. This position can be specified in "mm" units down to the 3rd decimal position.

Explanation During linear interpolation or circular interpolation movement, this command option outputs the value of <expression 1> to the specified port when the robot reaches the <expression 2> distance (units: "mm") from the start position.
The <expression 2> numeric value represents a circle radius (not arc length) centered on the movement START point.

This command option can only be used with linear or circular interpolation movement, and it can be specified no more than 2 times per MOVE statement.
If no hardware port exists, nothing is output.



CAUTION Output to ports "0" and "1" is not allowed at DO and SO.

Reference * Chapter 3 "10 Bit Settings"

Sample 1	Description
<pre>MOVE P,P0 MOVE L,P1,DO2()=105@25.85</pre>	<p>.....During linear interpolation movement of robot 1 to P1, 105 (&B01101001) is output to DO2() when the robot reaches a distance of 25.85mm from P0.</p>

Sample 2	Description
<pre>A!=10 B!=20 MOVE L,P2,MO(22)=1@A!,MO(22)=0@B!</pre>	<p>.....After the robot 1 starts toward P2, MO(22) switches ON when robot 1 leaves a distance of 10mm, and switches OFF when robot 1 leaves a distance of 20mm.</p>

Related commands MOVEI, MOVET, DRIVE, DRIVEI, WAIT ARM

A
B
C
D
E
F
G
H
I
J
K
L
M

MOVEI

Moves robot to the relative position

Format

```
MOVEI robot number (axis number,...) PTP ,point of destination, option,  
P option...  
L
```

Explanation Executes relative position movement of robot (axis).
It is not enabled for axes of other robots or for auxiliary axes.

Value	Range / Type
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6 (Multiple axes specifiiable. If not input, all axes are specified.)
PTP, P, L (*)	Movement type. PTP/P: PTP, L: Linear interpolation
<i>Point of Destination</i> (*)	Robot stopping (target) position. Specify the following data format: • Direct numeric value • Point definition (Point number)
<i>Option</i> (*)	Relative Speed setting, Absolute speed setting, Linear speed setting STOPON condition setting, CONTON condition setting, CONT setting, Acceleration setting, Deceleration setting,

* **Reference** "MOVE" statement (To use Sample program, replace "MOVE" in Sample to "MOVEI".)

Options	PTP	Linear interpolation	Remarks
Relative speed setting (SPEED)	✓	✓	Enabled only in specified MOVEI statement
Absolute speed setting (DSPEED)	✓	✓	Enabled only in specified MOVEI statement
Linear speed setting (VEL)	–	✓	Enabled only in specified MOVEI statement
STOPON condition setting	✓	✓	Enabled only when program execution
CONTON condition setting	✓	✓	Enabled only when program execution
CONT setting	✓	✓	Enabled only in specified MOVEI statement
Acceleration setting	✓	✓	Enabled only in specified MOVEI statement
Deceleration setting	–	✓	Enabled only in specified MOVEI statement

MEMO

If the MOVEI statement is interrupted and then re-executed, the movement target position can be selected at the "MOVEI/DRIVEI start position" setting in the controller parameter. For details, refer to RCX3 user's manual.

- 1) KEEP (default setting) Continues the previous (before interruption) movement. The original target position remains unchanged.
- 2) RESET Relative movement begins anew from the current position. The new target position is different from the original one (before interruption). (Backward compatibility)

Related commands MOVE, MOVET, DRIVE, DRIVEI, WAIT ARM

Format

MOVET	[robot number] (axis number, ...)	PTP	, point of destination, option,
		P	option...
		L	

Explanation Executes relative position movement of the specified axes in the tool coordinates.
It is not enabled for axes of other robots or for auxiliary axes.

Value	Range / Type
Robot Number	1 to 4 (If not input, robot 1 is specified.)
Axis Number	1 to 6 (Multiple axes specifiabl. If not input, all axes are specified.)
PTP, P, L (*)	Movement type. PTP/P: PTP, L: Linear interpolation
Point of Destination (*)	Robot stopping (target) position. Specify the following data format: • Direct numeric value (Coordinate value) • Point definition (Point number)
Option (*)	Relative Speed setting, Absolute speed setting, Linear speed setting STOPON condition setting, CONTON condition setting, CONT setting, Acceleration setting, Deceleration setting,

* **Reference** "MOVE" statement (To use Sample program, replace "MOVE" in Sample to "MOVET".)

Options	PTP	Linear interpolation	Remarks
Relative speed setting (SPEED)	✓	✓	Enabled only in specified MOVET statement
Absolute speed setting (DSPEED)	✓	✓	Enabled only in specified MOVET statement
Linear speed setting (VEL)	–	✓	Enabled only in specified MOVET statement
STOPON condition setting	✓	✓	Enabled only when program execution
CONTON condition setting	✓	✓	Enabled only when program execution
CONT setting	✓	✓	Enabled only in specified MOVET statement
Acceleration setting	✓	✓	Enabled only in specified MOVET statement
Deceleration setting	–	✓	Enabled only in specified MOVET statement

Related commands MOVE, MOVEI, DRIVE, DRIVEI, WAIT ARM

MTRDUTY

Acquires the motor load factor of the specified axis

FormatMTRDUTY [*robot number*] (*axis number*)**Value****Range***Robot Number* 1 to 4 (If not input, robot 1 is specified.)*Axis Number* 1 to 6**Explanation** Acquires the motor load factor (1 to 100 [%]) of the specified axis.

The motor load factor increases when the current value of the specified axis exceeds the rated current value. When the factor reaches 100%, "17.800 Motor overload" error occurs.

Sample**Description**

A=MTRDUTY(1)

.....The motor load factor of axis 1 of robot 1 is assigned to variable A.

Sets a specified communication port to the "offline" mode

Format

OFFLINE

ETH

CMU

Explanation Changes the communication mode parameter in order to switch the communication mode to OFFLINE.

ETH	Changes the Ethernet communication mode parameter to OFFLINE , clears the transmission and reception buffers.
CMU	Changes the RS-232C communication mode parameter to OFFLINE, resets the communication error, and clears the transmission and reception buffers.
No setting	Changes the Ethernet and RS-232C communication mode parameter to OFFLINE, resets the communication error (RS-232C only), and clears the transmission and reception buffers.

MEMO

Online command is invalid in OFFLINE (mode).

Sample

```
OFFLINE
SEND CMU TO A$
SEND CMU TO P10
ONLINE
HALT
```

Reference For details of SEND statements, refer to "112 SEND" in this Chapter.

Related commands ONLINE

ON ERROR GOTO

Jumps to a specified label when an error occurs

Format

1. ON ERROR GOTO *label*
2. ON ERROR GOTO 0

Explanation Even if an error occurs during execution of the robot language, this statement allows the program to jump to the error processing routine specified by the *<label>*, allowing the program to continue without being stopped (this is not possible for some serious errors.)

- If "0" is specified instead of the *<label>*, the program stops when an error occurs, and an error message displays.
- If ON ERROR GOTO "0" is executed at any place other than an error processing routine, the ON ERROR GOTO command is canceled (interruption canceled).
- The error processing routine can process an error using the RESUME statement and the error output information (ERR, ERL).

Error Output Information	ERR	Error code number
		ERL

MEMO

- If a serious error such as "17.800: Motor overload" occurs, the program execution stops.
- The most recently executed "ON ERROR GOTO *<label>*" statement is valid.
- If an error occurs during an error processing routine, the program will stop.
- "ON ERROR GOTO *<label>*" statements cannot be used within error processing routines.

Sample	Description
<pre>ON ERROR GOTO *ER1 FOR A = 0 TO 9 P[A+10] = P[A] NEXT A *L99: HALT 'ERROR ROUTINE *ER1: IF ERR = &H000600CC THEN *NEXT1 Checks to see if a "Point doesn't exist" error has occurred. IF ERR = &H000600CE THEN *NEXT2 Checks to see if a "Subscript out of range" error has occurred. ON ERROR GOTO 0Displays the error message and stops the program. *NEXT1:Jumps to the next line after the error line and resumes RESUME NEXT program execution. *NEXT2:Jumps to label *L99 and resumes program execution. RESUME *L99</pre>	

Related commands RESUME

Executes the subroutine specified by the *<expression>* value

* GOSUB can also be expressed as "GO SUB".

Format

```
ON expression GOSUB label 1, label 2...
```

Value	Meaning
-------	---------

<i>Expression</i>	Expression whose result is 0 or positive integer
-------------------	--

Explanation The *<expression>* value determines the program's jump destination.

An *<expression>* value of "1" specifies a jump to *<label 1>*, "2" specifies a jump to *<label 2>*, etc. Likewise, (*<expression>* value "n" specifies a jump to *<label n>*.)

If the *<expression>* value is "0" or if the *<expression>* value exceeds the number of existing labels, no jump occurs, and the next command is executed.

After executing a jump destination subroutine, the next command after the ON to GOSUB statement is executed.

Sample	Description
--------	-------------

'MAIN ROUTINE *ST: ON DI3() GOSUB *SUB1,*SUB2,*SUB3 GOTO *ST HALT*SUB1 to *SUB3 are executed.Checks to see if a "Point doesn't exist" error has occurred.
'SUB ROUTINE *SUB1: MOVE P,P10,Z=0 RETURN *SUB2: DO(30) = 1 RETURN *SUB3: DO(30) = 0 RETURN	

Related commands GOSUB, RETURN

* GOTO can also be expressed as "GO TO".

FormatON *expression* GOTO *label 1, label 2...***Value****Meaning***Expression* Expression whose result is 0 or positive integer**Explanation** The *<expression>* value determines the program's jump destination.

An *<expression>* value of "1" specifies a jump to *<label 1>*, "2" specifies a jump to *<label 2>*, etc. Likewise, (*<expression>* value "n" specifies a jump to *<label n>*.)

If the *<expression>* value is "0" or if the *<expression>* value exceeds the number of existing labels, no jump occurs, and the next command is executed.

Sample**Description**

```
'MAIN ROUTINE
*ST:
ON DI3() GOTO *L1,*L2,*L3
                                .....Jumps to *L1 to *L3 in accordance with the DI3() value.
                                .....Returns to *ST

GOTO *ST
HALT
'SUB ROUTINE
*L1:
    MOVE P,P10,Z=0
    GOTO *ST
*L2:
    DO(30) = 1
    GOTO *ST
*L3:
    DO(30) = 0
    GOTO *ST
```

Related commands

GOTO

Sets the specified communication port to the "online" mode

Format

ONLINE

ETH

CMU

Explanation Changes the communication mode parameter in order to switch the communication mode to ONLINE.

ETH	Changes the Ethernet communication mode parameter to ONLINE , clears the transmission and reception buffers.
CMU	Changes the RS-232C communication mode parameter to ONLINE, resets the communication error, and clears the transmission and reception buffers.
No setting	Changes the Ethernet and RS-232C communication mode parameter to ONLINE, resets the communication error (RS-232C only), and clears the transmission and reception buffers.

MEMO

Online command is valid in ONLINE (mode).

Sample

```

OFFLINE
SEND CMU TO A$
SEND CMU TO P10
ONLINE
HALT

```

Reference For details of SEND statements, refer to "112 SEND" in this Chapter.**Related commands** OFFLINE

OPEN

Opens the specified General Ethernet Port

Format

OPEN GPm

Notation	Value	Range
m	General Ethernet Port Number	2 to 7, 10 to 17, 20 to 27, 30 to 37

Explanation Opens the communication port of the specified General Ethernet Port.

Sample	Description
OPEN GP1Opens the General Ethernet Port 1.
SEND "123" TO GP1Sends the character strings "123" from the General Ethernet Port 1.
SEND GP1 TO A\$Receives the data from the General Ethernet Port 1 and saves the received data in the variable A\$.
CLOSE GP1Closes the General Ethernet Port 1.

Related commands CLOSE, SEND, SETGEP, GEPSTS

Format

```
ORD (character string expression)
```

Explanation Acquires the character code of the first character in a *<character string expression>*.

Sample	Description
A=ORD("B")66 (= &H42) is assigned to A.

Related commands CHR\$

ORGORD

Specifies/acquires the robot's return-to-origin sequence

FormatORGORD [*robot number*] *expression***Value Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Expression</i>	n to nnnnnn (n : 0 to 6)

Explanation Sets the axis sequence parameter for return-to-origin and absolute search operation of the robot specified by the *<robot number>*.

The 1 to 6 axes are expressed as "1 to 6" values, respectively, and the *<expression>* value must be 1-digit to 6-digit integer.

The same axis cannot be specified twice.

After the specified axes are returned to their origin points in sequence, from left to right, the remaining axes return to their origin points simultaneously.

If the *<expression>* value is "0", all axes will be returned to their origin points simultaneously.

Functions**Format**ORGORD [*robot number*]**Value Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
---------------------	--

Explanation Acquires the axis sequence parameter for return-to-origin and absolute search operation of the robot specified by the *<robot number>*.

Sample Description

A=3	
ORGORD AReturn-to-origin is executed first for axis 3 of robot 1.
ORIGINAfter the return-to-origin of axis 3 of robot 1 is completed, return-to-origin is executed for the remaining axes.
MOVE P,P0	
A=ORGORDReturn-to-origin sequence parameter of robot 1 is assigned to variable A.
HALT	

Related commands ORIGIN

Format

ORIGIN *robot number, motor type*

Value	Range / Meaning
<i>Robot Number</i>	0: all robots 1 to 4: specified robot only
<i>Motor Type</i>	0: all types 1: incremental motor only 2: absolute motor only 9: incomplete return-to-origin axis only (If omitted, 0 (all types) is specified.)

Explanation This statement performs return-to-origin of a robot, or absolute search for a semi-absolute axis.

If the movement is stopped at an intermediate point, "incomplete return-to-origin" status will occur. If *<robot number>* is omitted or "0" is specified during multiple robots setting, the return-to-origin and absolute search are first performed for the robot 1 and then for the robots 2 to 4.

Sample	Description
ORIGIN 0, 1Performs return-to-origin for incremental motor axes only of all robots.

Related commands ORGORD, MCHREF

Format

OUT	DOm (b, ..., b) DO (mb, ..., mb) MOm (b, ..., b) MO (mb, ..., mb) SOm (b, ..., b) SO (mb, ..., mb) LOO (b, ..., b) LO (0b, ..., 0b) TOO (b, ..., b) TO (0b, ..., 0b)	, <i>expression</i>
-----	---	---------------------

Notation	Value	Range / Content
m	Port Number	2 to 7, 10 to 17, 20 to 27 If no hardware port exists, nothing is output.
b	Bit definition(*)	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	<i>Expression</i>	time 0 to 3600000 (units: ms)

Explanation This statement turns ON the specified port output and terminates the command. (The program proceeds to the next line.) Output to that port is then turned OFF after the time specified by the <expression> has elapsed. If the operation is stopped temporarily at an intermediate point and then restarted, that port's output is turned OFF when the remaining <expression> specified time has elapsed.

If this <expression> is omitted, the specified port's output remains ON.

Up to 16 OUT statements using <expressions> can be executed at the same time. Attempting to execute 17 or more OUT statements will activate error "6.225: No sufficient memory for OUT".

Reference * Chapter 3 "10 Bit Settings"

**CAUTION**

Output to ports "0" and "1" are not allowed at DO, and SO.

Sample	Description
OUT DO2(),200Turns DO(27 to 20) ON, then turns them OFF 200 ms later.Turns DO(37, 35, 27, 20) ON.
OUT DO(37,35,27,20)	

Related commands DO, MO, SO, TO, LO

Specifies/acquires the OUT enable position parameter of the robot

Format

1. OUTPOS [*robot number*] *expression*
2. OUTPOS [*robot number*] (*axis number*) = *expression*

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axist Number</i>	1 to 6 (If not input, all axes are specified.)
<i>Expression</i>	1 to 9999999 (Unit: pulse)

Explanation Changes the "OUT position" parameter of the specified axis to the value of *<expression>*.

Format 1: The change is applied to all axes of the specified robot.

Format 2: The change is applied only to the axis specified by *<axis number>*.

Reference "MOVE" Axis parameter; "OUT position <OUTPOS>"

Functions

Format

OUTPOS [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axist Number</i>	1 to 6 (If not input, all axes are specified.)

Explanation Acquires the "OUT position" parameter's value for the specified axis.

Sample 1	Description
OUTPOS 2000Changes the OUTPOS parameter for all axes of Robot 1 to 2000
Sample 2	Description
OUTPOS (3) = 2000Changes the OUTPOS parameter for 3rd axis of Robot 1 to 2000
Sample 3	Description
A% = OUTPOS(3)Acquires the value of the OUTPOS parameter for 3rd axis of robot 1, assigns it to integer variable A%

Sample

```
'CYCLE WITH DECREASING OUTPOS
DIM SAV(3)
GOSUB *SAVE _ OUTPOS
FOR A=1000 TO 10000 STEP 1000
    GOSUB *CHANGE _ OUTPOS
    MOVE P,P0
    DO3(0)=1
    MOVE P,P1
    DO3(0)=0
NEXT A
GOSUB *RESTORE _ OUTPOS
HALT
*CHANGE _ OUTPOS:
    FOR B=1 TO 4
        OUTPOS(B)=A
    NEXT B
    RETURN
*SAVE _ OUTPOS:
    FOR B=1 TO 4
        SAV(B-1)=OUTPOS(B)
    NEXT B
    RETURN
*RESTORE _ OUTPOS:
    FOR B=1 TO 4
        OUTPOS(B)=SAV(B-1)
    NEXT B
    RETURN
```


Format

PATH	[robot number](axis number,...)	L C	point of destination , option, option...
------	---------------------------------	--------	---

Value	Range / Type
Robot Number	1 to 4 (If not input, robot 1 is specified.)
Axis Number	1 to 6 (Multiple axes specifiabl. If not input, all axes are specified.)
L, C	Movement type. L: Linear interpolation, C: Circular interpolation
Point of Destination	Robot stopping (target) position. Specify the following data format: • Direct numeric value (Coordinate value) • Point definition (Point number)
Option	Speed setting, coordinate plane setting (for circular interpolation only), port output setting

Explanation Sets the motion path for the specified axis.

This command can only be executed between the PATH SET and PATH END commands.
If execution is attempted elsewhere, an error will occur.

**CAUTION**

- Be careful not to set the same position in the coordinates as the start point and the following path points. If the position of each point is duplicated, an error might occur.
- When "R" axis only is specified in the coordinate attribute parameter, an error will occur.
- Only the X, Y and Z coordinate values among the specified points are valid for PATH motion. Any other coordinates use the coordinate values at the START point of the PATH motion; R-axis can not be moved to the specified point even if it is used.

MEMO

When PATH command is executed on SCARA robots or Cartesian robots with rotation axes, the R-axis holds the coordinates (angles) at execution start.

Path motion types

- **Linear interpolation movement**

"PATH L..." is set for linear interpolation movement.

- **Circular interpolation movement**

"PATH C..." is set for circular interpolation movement.

Only the X, Y and Z coordinate values of the specified points are valid for PATH motion. Any other coordinates use the coordinate values of the PATH motion START point.

The motion path can be connected by repeated PATH commands ("PATH L", "PATH C") to allow movement without stopping.

Point data setting types

● Direct numeric value input

Linear interpolation

Circular interpolation

Format

p1 p2 p3 p4 p5 p6 f f1 f2

Notation	Value
p1 to p6	Space-separated coordinate values for each axis
f	Hand system flag (SCARA robot only)
f1	First arm rotation information (YK-TW series only)
f2	Second arm rotation information (YK-TW series only)

Explanation

Directly specifies coordinate data by a numeric value. Units for the coordinate is as follows;

- Integer: "pulse" units
- Real number (with decimal point): "mm/deg." units
- Integers and real numbers (mixed): All coordinate values will be handled in "mm/deg." units.

With this format, only 1 point can be specified as the movement destination coordinates.

The only type of movement specified by this point data setting is linear interpolation.

The hand system / first and second arm rotation information must be the same throughout the movement. They cannot be changed at any point along the path.

Notation: f) SCARA robots with coordinate data in "mm" units --> Hand system flags can be specified. (*1)

To set the hand system flag, set either 1 or 2 at "f". If a number other than 1 or 2 is set, or if no number is designated, 0 will be set to indicate that there is no hand system flag.

f	0	Hand system flag is not set.
		Any value other than 1 / 2, or no setting.
	1	Right-handed system is used to move to a specified position.
	2	Left-handed system is used to move to a specified position.



CAUTION

The hand system used during PATH motion must be the same as the hand system used at the path motion route's start point. The same applies if the path is to pass through points where hand system flags are set. Differing hand systems will cause an error and disable motion.

Notation: f1,2)YK-TW series with coordinate data in "mm" units -->

The first and second arm rotation information can be specified. (*1)

To set the rotation information, set "-1", "0", or "1" at f1 and f2.

Any other value or no setting will be processed as "0".

f1, 2	0	Indicates arm rotation information where movement to the "0" position has been specified.
		Any value other than -1 / 0 / 1, or no setting.
	1	Indicates arm rotation information where movement to the "1" position has been specified.
	-1	Indicates arm rotation information where movement to the "-1" position has been specified.



CAUTION

The first arm and second arm rotation information during PATH movement must be the same as the first arm and second arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled..

Reference

*1: Chapter 4 "3. Point data format"

 **MEMO**

At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

Sample	Description
PATH L,10000 10000 1000 1000 0 0Sets the linear interpolation movement path of robot 1 in "pulse" units.
IPATH L,150.000 250.000 10.000 30.000 0.000 0.000 1The linear interpolation movement path of robot 1 is set in the coordinate values specified by the right-handed system in "mm" units.

● **Point definition**

Linear interpolation **Circular interpolation**

Format

point definition , *point definition...*

Explanation Specifies the movement destination as <point expression> value. Two or more data items can be designated by separating them with a comma (,).
For circular interpolation movement, 2 points must be specified for each arc.

 **MEMO**

At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.



CAUTION

- The hand system used during PATH motion must be the same as the hand system used at the path motion route's start point. The same applies if the path is to pass through points where hand system flags are set. Differing hand systems will cause an error and disable motion.
- The first arm and second arm rotation information during PATH movement must be the same as the first arm and second arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.

Sample	Description
PATH L,P1,P2,P3Specifies sequential linear interpolation movement of robot 1 from its current position to the positions specified by P1, P2 and P3 from its current position.
PATH C P5,P6,P7,P8Specifies circular interpolation movement of robot 1 through the following points: current position, P5, P6, and P6, P7, P8.

Option types

- Speed setting 1
- Speed setting 2

Linear interpolation Circular interpolation

Linear interpolation Circular interpolation

Reference "MOVE" statement (To use Sample program, replace "MOVE" in Sample to "PATH".)

- Coordinate plane setting

Linear interpolation Circular interpolation

Format

XY
YZ
ZX

Reference "MOVE" statement (To use Sample program, replace "MOVE" in Sample to "PATH".)

- Port output setting

Linear interpolation Circular interpolation

Format 1

DO	$m(b, \dots, b) = \text{expression 1} @ \text{expression 2}$
MO	
SO	

Format 2

DO	$(mb, \dots, mb) = \text{expression 1} @ \text{expression 2}$
MO	
SO	

Reference "MOVE" statement

Sample	Description
--------	-------------

PATH SET	
PATH L,P1,DO(20)=1@10Specifies to output "1" to DO(20) at a 10mm radius position from the START position during linear interpolation movement of robot 1 from its current position to P1.
PATH L,P2,DO(21)=1@12.5Specifies to output "1" to DO(21) at a 12.5mm radius position from P1 during linear interpolation movement of robot 1 from its current position to P2.
PATH END	
PATH START	

Related commands PATH SET, PATH END, PATH START

Format

```
PATH [robot number] END
```

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
---------------------	--

Explanation

Ends the path setting of specified robot's PATH motion.

The PATH END command must always be paired with a PATH SET command. The PATH motion path end-point is the final point specified by the final PATH command (PATH L, PATH C) which exists between the PATH SET and PATH END commands.

Attempting to execute a PATH END command when no PATH SET command has been executed will result in an error.

Sample**Description**

PATH ENDEnds the path setting of robot 1's PATH motion
----------	---

Related commands

PATH, PATH SET, PATH START

Reference

Chapter 9 "PATH Statements"

Format

PATH [*point definition*] SET *point definition*

Value**Range**

Robot Number 1 to 4 (If not input, robot 1 is specified.)

Explanation

Starts the path setting of specified robot's PATH motion.

Specifies the <point definition> position as the PATH motion start-point. (This only sets the PATH motion start point and does not actually begin robot motion.) If the <point definition> value is omitted, the current robot position is set as the start point.

However, if robot movement is in progress, the target position of that movement becomes the start point. (Example: The OUT position range is wider for the MOVE command which precedes the PATH SET command, so the robot is still moving when the PATH SET command is executed, etc.)

The PATH SET command must always be paired with a PATH END.

**CAUTION**

Be careful not to set the same position in the coordinates as the start point and the following path points. If the position of each point is duplicated, an error might occur.

**NOTE**

The PATH SET statement is available in software version 1.11 onwards.

Point data setting types● **Point definition****Format**

point expression

Explanation

The PATH motion's start-point is specified by the <point expression>.

**MEMO**

At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

**CAUTION**

- The hand system used during PATH motion must be the same as the hand system used at the path motion route's start point. Differing hand systems will cause an error and disable motion.
- The first arm and second arm rotation information during PATH movement must be the same as the first arm and second arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.

Sample**Description**

PATH SET P10The start-point of the PATH motion is set to P10.

PATH SET WHERE.....The start-point of the PATH motion becomes the current position.

Reference

Chapter 9 "PATH Statements"

● Direct numeric value input

Format

p1 p2 p3 p4 p5 p6 f f1 f2

Notation	Value
p1 to p6	Space-separated coordinate values for each axis
f	Hand system flag (SCARA robot only)
f1	First arm rotation information (YK-TW series only)
f2	Second arm rotation information (YK-TW series only)

Explanation

Directly specifies coordinate data by a numeric value. Units for the coordinate is as follows;

- Integer: "pulse" units
- Real number (with decimal point): "mm/deg." units
- Integers and real numbers (mixed): All coordinate values will be handled in "mm/deg." units.

Notation: f) SCARA robots with coordinate data in "mm" units --> Hand system flags can be specified. (*1)

To set the hand system flag, set either 1 or 2 at "f".

If a number other than 1 or 2 is set, or if no number is designated, 0 will be set to indicate that there is no hand system flag.

f	0	Hand system flag is not set. Any value other than 1 / 2, or no setting.
	1	Indicates that a right-handed system is specified for the PATH motion's start-point
	2	Indicates that a left-handed system is specified for the PATH motion's start-point.



CAUTION

The hand system used during PATH motion must be the same hand system as that at the PATH motion's start-point. An error will occur if the hand systems are different.

Notation: f1,2)YK-TW series with coordinate data in "mm" units -->

The first and second arm rotation information can be specified. (*1)

To set the rotation information, set "-1", "0", or "1" at f1 and f2.

Any other value or no setting will be processed as "0".

f1, 2	0	Indicates arm rotation information where movement to the "0" position has been specified. Any value other than -1 / 0 / 1, or no setting.
	1	Indicates arm rotation information where movement to the "1" position has been specified.
	-1	Indicates arm rotation information where movement to the "-1" position has been specified.



CAUTION

The first arm and second arm rotation information during PATH movement must be the same as the first arm and second arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.

Reference

*1: Chapter 4 "3. Point data format"

MEMO

At SCARA robots with a hand system flag set in the movement destination's coordinate data, the specified hand system will have priority over the current arm type or LEFTY/RIGHTY setting.

PATH SET

Sample	Description
<pre>PATH SET 120 250.000 55.2 20.33 0 0</pre>	<p>.....The PATH motion's start-point of robot 1 is specified in "mm" units as follows: 120.000 250.000 55.200 20.330 0.000 0.000.</p>
<pre>PATH SET -51200 80521 7045 204410 0 0</pre>	<p>.....The PATH motion's start-point of robot 1 is specified in "pulse" units.</p>

Related commands **PATH, PATH END, PATH START**

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Format

PATH [*robot number*] START, option, option...

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Option</i>	STOPON condition setting, CONTON condition setting, CONT setting

Options	PTP	Remarks
STOPON condition setting	✓	Enabled only while program execution
CONTON condition setting	✓	Enabled only while program execution
CONT setting	✓	Enabled only in specified PATH START statement

Explanation Starts PATH motion of specified robot.

Before PATH START can be executed, the PATH motion path must be specified by the PATH SET command, PATH commands (PATH L, PATH C) and the PATH END command. The robot must also be positioned at the motion path's start-point which was specified by the PATH SET command.

The robot's PATH motion speed is the automatic movement speed (%) which was in effect when the PATH START was executed, multiplied by the program movement speed (%) specified by the SPEED command or the (SPEED or S) option of the PATH command. A speed specified by the "VEL" option of the PATH command does not rely on the automatic movement speed.

After PATH motion begins, the PATH START command is terminated when the robot reaches the PATH motion end-point, or when movement is stopped by a stop input, etc.

Option types

● STOPON condition setting

Format

```
STOPON conditional expression
```

Sample

Description

```
PATH START,STOPON DI(20)=1
```

.....Robot 1 starts PATH movement, if the "DI (20) = 1" condition is met during movement, a deceleration and stop occurs, and the next step is then executed.

Reference "MOVE" statement

● CONTON condition setting (Continuous motion)

Format

```
CONTON conditional expression
```

Sample

Description

```
PATH START,CONTON DI(20)=1
```

.....Robot 1 starts PATH movement, if the "DI (20) = 1" conditions are met during movement, robot starts decelerating and executes the next step.

Reference "MOVE" statement

● CONT setting (Continuous motion)

Format

```
CONT
```

Sample

Description

```
PATH START,CONT
```

```
MOVE P,P10
```

.....PATH motion starts, and movement to P10 begins after the moving axes enter the deceleration zone of final PATH motion.

Reference

- "MOVE" statement
- Chapter 9 "PATH Statements"

Related commands PATH, PATH SET, PATH END

Format

PDEF (Pallet definition number) = expression 1, expression 2, expression 3, point definition

Value	Range / Meaning
Pallet Definition Number	0 to 39
Expression 1	Number of elements (NX) between P[1] and P[2]
Expression 2	Number of elements (NY) between P[1] and P[3]
Expression 3	Number of elements (NZ) between P[1] and P[5]
Point definition	The point used for a pallet definition. Continuous 5 points starting with the specified point are used.

Explanation Defines the pallets to permit execution of the pallet movement command.

For previously defined pallet data, the contents of definition can be changed.

After specifying the number of points per axis, the equally-spaced points for each axis are automatically calculated and defined in the sequence shown in the figure below.

- If <expression 3> (Z-axis direction) is omitted, the value becomes "1".
- The total number of elements defined for a single pallet must not exceed 32,767.


If the point specification is omitted, 5 consecutive points are used, starting with the following points.

First/Top point = palette definition number \times 5 + 10000

Example: PDEF(1)=2, 3, 4

Use 5 consecutive points with P10005 at the top. (P10005 - P10009)

However, if the palette data defined with the point specification is changed without specifying the points, the previously specified points will be used.

Automatic point calculation**Sample****Description**

PDEF(1)=3,4,2,P3991

.....Pallet definition 1 is defined as 3 x 4 x 2 by using P3991 to P3995.

Related commands

PMOVE

PGMTSK

Acquires the task number in which a specified program is registered

FormatPGMTSK (*program number*)**Value** **Range***Program Number* 1 to 100**Explanation** Acquires the task number in which the program specified by *<program number>* is registered. **MEMO**

If the program number which is not registered in the task is specified, "3.203: Program doesn't exist" error occurs.

Sample **Description**

A = PGMTSK(1)Assigns the task number in which the program number 1's program is registered to variable A.
---------------	---

Related commands PGN, TSKPGM

Acquires the program number from a specified program name

Format

PGN ("program name")

Value**Range***Program Name*

32 characters or less consisting of alphanumeric characters and underscore (_)

Explanation

Acquires the program number of the program specified by *<program name>*.
The program name must be enclosed in double quotation marks (").

Sample**Description**

A = PGN("PG _ SUB")

.....The program number of PG _ SUB is assigned to variable A.

Related commands

PGMTSK, TSKPGM

PMOVE

Executes a pallet movement command for the robot

Format

```
PMOVE [robot number] (pallet definition number, pallet position number),
option, option...
```

Value	Range / Type
Robot Number	1 to 4 (If not input, robot 1 is specified.)
Pallet Definition Number	0 to 39
Pallet Position Number	1 to 32767
Options	Relative speed setting, arch motion setting, STOPON condition setting, CONTON condition setting, CONT setting


Options	PTP	Remarks
Relative speed setting (SPEED)	✓	Enabled only in specified PMOVE statement
Arch motion	✓	Enabled only in specified PMOVE statement
STOPON condition setting	✓	Enabled only when program execution
CONTON condition setting	✓	Enabled only when program execution
CONT setting	✓	Enabled only in specified PMOVE statement

Explanation Executes "pallet move" command of the specified axes. (The specified pallet numbers must be registered in advance.)
It is not enabled for axes of other robots or for auxiliary axes.

- Movement type: PTP **Reference** "MOVE" statement
- Pallet definition number: Numeric expression
- Pallet position number: Numeric expression

The position numbers for each pallet definition are shown below.

Position numbers for each pallet definition



MEMO

Acquires the XYZ axes move to the position determined by calculated values, the R attribute axis moves to the position specified by pallet point data P [1].

Sample	Description
PMOVE(1,16)Robot 1 moves from its current position to the position specified by pallet position number 16 of pallet definition number 1.

Movement type

● PTP (point-to-point) movement

PTP movement begins after positioning of all movement axes is complete (within the tolerance range*1), and **the command terminates when the movement axes enter the OUT position range*2.**

Although the movement axes reach their target positions simultaneously, their paths are not guaranteed.

*1) Axis parameter "Tolerance <TOLE>"

This parameter sets the positioning completion range to the target position when the robot moves.

When the current position of the robot enters the specified range, this is judged to the positioning completion.


*2) Caution regarding commands which follow the MOVE P command; Axis parameter "OUT position <OUTPOS>"

This parameter sets the execution completion range to the target position when a movement command is executed.

If the next command following the PMOVE command is an executable command such as a signal output command, that next command will start when the movement axis enters the OUT position range. In other words, that next command starts before the axis arrives within the target position OUT position range.

Signal output (DO, etc.)	Signal is output when the axis enters within OUT position range.
DELAY	DELAY command is executed and standby starts, when the axis enters the OUT position range.
HALT	Program stops and is reset when the axis enters the OUT position range. Therefore, the axis movement also stops.
HALTALL	All programs in execution stop when axis enters the OUT position range, task 1 is reset, and other tasks terminate. Therefore, the movement also stops.
HOLD	Program temporarily stops when the axis enters the OUT position range. Therefore, the axis movement also stops.
HOLDALL	All programs in execution temporarily stop when the axis enters the OUT position range. Therefore, the movement also stops.
WAIT	WAIT command is executed when the axis enters the OUT position range.

The WAIT ARM statement is used to execute the next command after the axis enters the tolerance range.



PMOVE

Option types

● Relative speed setting

Format

1. SPEED = *expression*
2. S = *expression*

Value	Range
<i>Expression</i>	1 to 100 (units: %)

Explanation Specifies the program speed in an <expression>.

$\text{Robot max. speed (mm/sec or deg/sec)} \times \text{automatic movement speed (\%)} \times \text{program movement speed S (\%)}$

"S" setting superimposes the speed on the current automatic movement speed.

$\text{automatic movement speed (\%)} \times \text{program movement speed S (\%)} = \text{actual speed (\%)}$

100%	50%	50%
50%	50%	25%



NOTE

This option specifies only the maximum speed and does not guarantee the movement at the specified speed.

- Automatic movement speed: Specified by programming box operation or by the ASPEED command.
- Program movement speed: Specified by SPEED commands or MOVE, DRIVE speed settings.

Sample (Automatic movement speed: 80%)	Description
PMOVE(1,3),S=50Robot 1 moves from its current position to the position specified by pallet position number 3 of pallet definition number 1 at 50% (Actual speed is 40%) of the program speed.

● Arch motion setting

Format

`x = expression, x = expression...`

Value	Range
X	Specifies the Z,R,A,B axis.
<i>Expression</i>	An integer value is processed in "pulse" units. A real number (with decimal point) is process in "mm/deg." units.


Explanation

1. The "x" specified axis begins moving toward the position specified by the <expression> ("1" shown in the figure below).
2. When the axis specified by "x" moves the arch distance 1 or more, other axes move to their target positions ("2" shown in the figure below).
3. The axis specified by "x" moves to the target position so that the remaining movement distance becomes the arch distance 2 when the movement of other axes is completed ("3" shown in the figure below).
4. The command ends when all axis enter the OUT position range.

MEMO

The Value specified in <expression> is based on the robot coordinates. Settings such as hand definition and work definition are not considered.

Sample	Description
<code>PMOVE(1,A),Z=0</code>First the Z-axis of robot 1 moves from the current position to the "0 pulse" position. Then the other axes of robot 1 move to the position specified by pallet position number A of pallet definition number 1. Finally the Z-axis of robot 1 moves to the position specified by pallet position number A.



PMOVE

● STOPON condition setting

Format

STOPON *conditional expression*

Sample	Description
PMOVE(A,16),STOPON DI(20)=1Robot 1 moves to the position specified by pallet position number 16 of pallet definition number A, then decelerates and stops when DI(20) turns ON (the condition "DI(20) = 1" is met).
PMOVE(A,17)PTP movement to 17; Execution of the next step

Reference "MOVE" statement

● CONT setting (Continuous Motion)

Format

CONTON *conditional expression*

Sample	Description
PMOVE(A,16),CONTON DI(20)=1While robot 1 moves to the position specified by pallet position number 16 / pallet definition number A, if DI(20) turns ON (the condition "DI(20) = 1" is met), the robot starts decelerating and executes the next step.

Reference "MOVE" statement

Related commands	PDEF
------------------	------

Format

```
LET Pn = p1 p2 p3 p4 p5 p6 f f1 f2
```

Notation	Value	Range
n	Point number	0 to 29999
p1 to p6	Point data	According to the format
f	Hand system flag	1 or 2 (for SCARA robots only)
f1	First arm rotation information	-1, 0, 1 (YK-TW series only)
f2	Second arm rotation information	-1, 0, 1 (YK-TW series only).

Explanation Defines the point data.

- 1: "n" indicates the point number.
- 2: Input data for "p1" to "p6" must be separated with a space (blank).
- 3.: If all input data for "p1" to "p6" are integers (no decimal points), the movement units are viewed as "pulses". "p1" through "p6" then correspond to axis 1 through axis 6.
- 4: **If there is even 1 real number (with decimal point) in the input data for "p1" through "p6", the movement units are recognized as "mm".**
- 5: The input data ranges are as follows:
 - For "pulse" units: -6,144,000 to 6,144,000 range
 - For "mm" units: -99,999.99 to 99,999.99 range



NOTE

If both integers and real numbers are used together (mixed), all coordinate values will be handled in "mm/deg" units.

Notation: f) SCARA robots with coordinate data in "mm" units --> Hand system flags can be specified. (*1)

To set the hand system flag, set either 1 or 2 at "f".

If a number other than 1 or 2 is set, or if no number is designated, 0 will be set to indicate that there is no hand system flag.

f	0	Hand system flag is not set.
		Any value other than 1 / 2, or no setting.
	1	Point setting in Right-handed system
		Point setting in Left-handed system

Notation: f1,2)YK-TW series with coordinate data in "mm" units -->

The first and second arm rotation information can be specified. (*1)

To set the rotation information, set "-1", "0", or "1" at f1 and f2.

Any other value or no setting will be processed as "0".

f1, 2	0	"0" is set at arm rotation information.
		Any value other than -1 / 0 / 1, or no setting.
	1	"1" is set at arm rotation information.
		"-1" is set at arm rotation information.

Reference

*1: Chapter 4 "3. Point data format"

Sample	Description
P1 = 0 0 0 0 0 0Defines point data P1 to P3
P2 = 100.000 200.000 50.000 0.000 0.000 0.000	
P3 = 10.000 0.000 0.000 0.000 0.000 0.000	
P10= P2Substitute P2 for P10
FOR A=10 TO 15	
P[A+1]=P[A]+P3	
NEXT A	
FOR A=10 TO 16	
MOVE P,P1,P[A]PTP movement from the position of P1
NEXT A	to the position of P[A]
HALT	



NOTE

- All input values are handled as constants.
- If controller power is turned off during execution of a point definition statement, a memory-related error such as "9.702: Point data destroyed" may occur.

Related commands Point assignment statement (LET)

Format

```
PPNT(pallet definition number, pallet position number)
```

Explanation Creates the point data specified by the pallet definition number and the pallet position number.

Sample	Description
P10=PPNT(1,24)Creates, at P10, the point data specified by pallet position number 24 of pallet definition number 1.

Related commands PDEF, PMOVE

Displays the specified expression value at the programming box

Format

```
PRINT expression , expression... ;
```

Value**Contents**

Expression Character string, numeric value, variable

Explanation Displays a specified variable on the programming box screen.

Output definitions are as follows:

- 1: If numbers or character strings are specified in an <expression>, they display as they are. If variables or arrays are specified, the values assigned to the specified variables or arrays display.
- 2: If no <expression> is specified, only a line-feed occurs.
- 3: If the data length exceeds the screen width, a line-feed occurs, and the data is displayed on the next line.
- 4: If a comma (,) is used as a display delimiter, a space (blank) is inserted between the displayed items.
- 5: If a semicolon (;) is used as a display delimiter, the displayed items appear in succession without being separated.
- 6: If the data ends with a delimiter, a line-feed does not occur. When not ended with a display delimiter, a line-feed occurs with a display delimiter, a line-feed occurs.

MEMO

- Data communication to the programming box screen occurs in order for the PRINT statement to be displayed there. Therefore, program execution may be delayed when several PRINT statements are executed consecutively.
- On the programming box, the PRINT statement is displayed on "Message" space in "Automatic Operation (ALL TASK)" screen.

Sample**Description**

```
PRINT A           .....Displays the value of variable A.
PRINT "A1 =";A1   .....Displays the value of variable A1 after "A1 =".
PRINT "B(0),B(1) = ";B(0);",";B(1)
PRINT P100        .....Displays the P100 value.
```

Related commands

INPUT

Format

1. PSHFRC [*robot number*] *expression*
2. PSHFRC [*robot number*] (*axis number*) = *expression*

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	-1000 to 1000 (unit: %)

Explanation Changes the "push force" parameter of the specified axis to the value of <expression>. If the "F" option is omitted in the PUSH statement, the pushing control is executed with the setting of the pushing thrust parameter.

Actual pushing thrust is as follows.

- Rated thrust x <expression> / 100

[Format 1] Changes parameters of all axes.

[Format 2] Changes parameter of the axis specified by the <axis number>.

Sample	Description
PSHFRC (1) = 10Changes the pushing thrust parameter of axis 1 of robot 1 to 10%.

Functions**Format**

PSHFRC [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the value of "push force" parameter of the specified axis.

Sample	Description
A=PSHFRC (1)The pushing thrust parameter of axis 1 of robot 1 is assigned to variable A.

Format

1. PSHJGSP [*robot number*] *expression*
2. PSHJGSP [*robot number*] (*axis number*) = *expression*

Value	Range / Meaning
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	0 (Invalid), 1 to 100 (units: %)

Explanation Changes the "push judge speed" parameter of the specified axis to the value of the *<expression>*. If the push judge speed parameter is enabled, a pushing operation is detected only when the movement speed is below *<expression>* with the pushing thrust in the PUSH statement at the specified value.

The setting of *<expression>* can be specified as follows.

- 0: A pushing operation is detected if the pushing thrust reaches the specified value with the threshold setting invalid.
- 1 to 100: The movement speed in the PUSH statement is 100% to specify thresholds with a rate.

Sample	Description
PSHJGSP (1) = 50Changes the push judge speed parameter of axis 1 of robot 1 to 50%.

Functions**Format**

PSHJGSP [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the value of "push judge speed" parameter of the axis specified by *<axis number>*.

Sample	Description
A=PSHJGSP (1)The pushing detection speed threshold parameter of axis 1 of robot 1 is assigned to variable A.

Format

1. PSHMTD [*robot number*] *expression*
2. PSHMTD [*robot number*] (*axis number*) = *expression*

Value	Range / Meaning
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	0: Totalizing method, 1: Resetting method

Explanation Changes the "push method" parameter of the specified axis to the value of the <expression>.

The pushing type in the PUSH statement can be specified as follows by the <expression>.

- 0: The time for the pushing thrust to reach the specified value is totalized to execute the pushing control end detection.
- 1: The pushing control end detection is executed only when the pushing thrust continuously reaches the specified value. If the pushing thrust is lower than the specified value, the elapsed time is reset to 0.

In format 1, the change occurs at all axes.

In format 2, the change occurs at the parameter of the axis specified by <axis number>.

Sample	Description
PSHMTD (1) = 1Changes the push method parameter of axis 1 of robot 1 to the resetting method.

Functions**Format**

PSHMTD [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the value of "push method" parameter of the axis specified by <axis number>.

Sample	Description
A=PSHMTD (1)The pushing method parameter of axis 1 of robot 1 is assigned to variable A.

Format

```
PSHRSLT [robot number] (axis number)
```

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the end status of PUSH statement executed for the axis.

0: The PUSH statement was ended for a reason other than the arrival of the pushing time.

1: The PUSH statement was ended by the arrival of the pushing time.

Sample**Description**

PUSH(3,P1)Moves the axis 3 of robot 1 is under the pushing control to the position specified with P1.
IF PSHRSLT(3) = 1 THENEnded by the arrival of the pushing time.
GOTO *OK	
ELSEEnded for a reason other than the arrival of the pushing time.
GOTO *NG	
ENDIF	

Format

1. PSHSPD [*robot number*] *expression*
2. PSHSPD [*robot number*] (*axis number*) = *expression*

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	1 to 100 (units: %)

Explanation Changes the "push speed" parameter of the axis to the value of *<expression>*.

The motion speed in the PUSH statement is as follows.

- Neither "S" nor "DS" is set as an option in the PUSH statement:
Max. speed of robot (mm/sec. or deg./sec.) x Push speed ratio (%) x Auto. movement speed (%) x Program movement speed (%)
- "S" is set as an option in the PUSH statement:
Max. speed of robot (mm/sec. or deg./sec.) x Push speed ratio (%) x Auto. movement speed (%) x Program movement speed specified by S (%)
- "DS" is set as an option in the PUSH statement:
Max. speed of robot (mm/sec. or deg./sec.) x Push speed ratio (%) x Movement speed of an axis specified by DS (%)

Sample	Description
PSHSPD (1) = 50Changes the push speed parameter of axis 1 of robot 1 to 50%.

Functions**Format**

PSHSPD [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the "push speed" parameter value of the axis specified by *<axis number>*.

Sample	Description
A=PSHSPD (1)The push speed parameter of axis 1 of robot 1 is assigned to variable A.

PSHTIME

Specifies/acquires the push time parameter

Format

1. PSHTIME [*robot number*] *expression*
2. PSHTIME [*robot number*] (*axis number*) = *expression*

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	1 to 32767 (unit: ms)

Explanation

Changes the "push time" parameter of the specified axis to the value indicated in *<expression>*.

If the TIM option is omitted in the PUSH statement, the pushing control is executed with the setting of the push time parameter.

In format 1, the change occurs at all axes.

In format 2, the change occurs at the axis specified by the *<axis number>*.

Sample**Description**

PSHTIME (1) = 1000Changes the push time parameter of axis 1 of robot 1 to 1000 ms.
--------------------	---

Functions**Format**

PSHTIME [*robot number*] (*axis number*)

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation

Acquires the value of "push time" parameter of the axis specified by the *<axis number>*.

Sample**Description**

A=PSHTIME (1)The push time parameter of axis 1 of robot 1 is assigned to variable A.
---------------	--

Format

PUSH [*robot number*] (*axis number*, *expression*), *option*, *option*

Value	Range / Meaning
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	Motor position (mm, degree, pulse) or point expression

Explanation Executes an absolute position movement of the specified axis with controlling the pushing thrust in the forwarding direction.

- Movement type : Pushing PTP movement of specified axis
- Point data setting : Direct coordinate data input, point definition
- Options : Pushing thrust setting, pushing time, pushing speed setting, STOPON condition setting, CONTON condition setting

Movement type

● **PTP (point-to-point) of specified axis**

PTP movement begins after the operation of the axis specified by the <axis number> is completed (within the tolerance range), controlling the pushing thrust in the forwarding direction of the axis.

The conditions to start the pushing control are as follows.

- Immediately after the start of movement of an axis by the PUSH statement
- After the merge operation is completed (when the PUSH statement is specified in the line next to the movement command with CONT specified)

The conditions to terminate the command are as follows.

- The axis arrives within the tolerance range of the target position.
- The status where the pushing thrust of the axis reaches <pushing thrust value> elapses the time specified to <pushing time value>.

The end status for the PUSH statement can be confirmed with the PSHRSLT statement.

The conditions to cancel the pushing thrust (to cancel the torque value defined by PUSH statement) are as follows.

- When PUSH command finishes and then either of movement commands below is executed. Note that only finishing PUSH command is not enough to cancel the pushing thrust
 1. In push status at PUSH command finish
 - When the target axis starts to move in the opposite direction of that specified by PUSH statement
 2. The target axis moves to the target position at PUSH command finish (not in push status)
 - When the target axis starts to move either direction
- When a servo off occurs
- When the power source to the controller is interrupted and restarted

PUSH

If the next command following to the PUSH statement is an executable command such as a signal output command, the next command will start when the pushing conditions of an axis to be moved are satisfied, or when an axis arrives within the tolerance range of the target position.

Example:

Signal output (DO, etc.)	Signal is output when the pushing conditions are satisfied or within the tolerance range.
DELAY	DELAY command is executed and standby starts, when the pushing conditions are satisfied or within the tolerance range.
HALT	Program stops and is reset when the axis enters the OUT position range. Therefore, the axis movement also stops.
HALTALL	When the pushing conditions are satisfied or within the tolerance range, the programs in execution are all stopped, task 1 is reset, and other tasks are terminated. Therefore, the axis movement also stops.
HOLD	Program temporarily stops when the axis enters the OUT position range. Therefore, the axis movement also stops.
HOLDALL	When the pushing conditions are satisfied or within the tolerance range, the programs in execution are all temporarily stopped. Therefore, the axis movement also stops.
WAIT	WAIT command is executed, when the pushing conditions are satisfied or within the tolerance range.

Sample	Description
PUSH(1,P0)Axis 1 of robot 1 moves from its current position to the position specified by P0.

Point data setting types

● Direct numeric value input

The motor position is specified directly in *<expression>*.

If the motor position's numeric value is an integer, this is interpreted as a "pulse" unit. If the motor position's numeric value is a real number, this is interpreted as a "mm/degrees" unit, and each axis will move from the 0-pulse position to a pulse-converted position.

Sample	Description
PUSH(1,10000)Axis 1 of robot 1 moves from its current position to the 100000 pulse position.
PUSH[2](2,90.000)Axis 2 of robot 2 moves from its current position to the 90° position (when axis 2 is a rotating axis).

● Point definition

Point data is specified in *<expression>*. The axis data specified by the *<axis number>* is used. If the point expression is in "mm/degrees" units, movement for each axis occurs from the 0-pulse position to the pulse-converted position.

Sample	Description
PUSH(1,P1)Axis 1 of robot 1 moves from its current position to the position specified by P1.
PUSH[2](2,P90)Axis 2 of robot 2 moves from its current position to the position specified by P90 (deg.) (when axis 2 is a rotating axis.)

Option types

● Pushing thrust setting

Format

$F = \textit{expression}$

Value Range

Expression -1000 to 1000 (units: %)

Explanation The pushing thrust in the forwarding direction of an axis is specified as an *<expression>*. The actual pushing thrust is determined as shown below.

- Rated thrust x *<expression>*/100

If *<expression>* is omitted, pushing thrust value specified with the parameter is used.

Sample	Description
PUSH(1,10000),F=10Axis 1 of robot 1 moves from its current position to the 100000 pulse position with the pushing thrust at 10% of the rated thrust.

● Pushing time setting

Format

$TIM = \textit{expression}$

Value Range

Expression 1 to 32767 (units: ms)

Explanation The time to keep pushing with the specified pushing thrust is specified as an *<expression>*. When the status where the pushing thrust reaches the specified value exceeds *<expression>*, the PUSH statement terminates.

If this option is omitted, the setting of the parameter is used.

Sample	Description
PUSH(1,10000),TIM=5000Axis 1 of robot 1 moves from its current position to the 100000 pulse position with keeping pushing for 5 seconds.

● Pushing speed setting

Format

1. SPEED = *expression*
2. S = *expression*

Value

Range

Expression 1 to 100 (units: %)

Explanation The program movement speed is specified in <expression>. This option is enabled only for the specified PUSH statement.

The actual speed is determined as shown below.

- Max. speed of a robot (mm/s or deg./s) x Push speed (%) x automatic. movement speed (%) x <expression> (%)

Sample

Description

PUSH(1,10000),S=10

.....Axis 1 of robot 1 moves from its current position to the 100000 pulse position with the speed at 10% of the multiplication of the push speed and the automatic movement speed.

Format

1. DSPEED = *expression*
2. DS = *expression*

Value

Range

Expression 0.01 to 100.00 (units: %)

Explanation The axis movement speed is specified in <expression>. This option is enabled only for the specified PUSH statement. Movement always occurs at the DSPEED <expression> value (%) without being affected by automatic movement speed value (%).

The actual speed is determined as shown below.

- Max. speed of a robot (mm/s or deg./s) x Push speed (%) x <expression> (%)

Sample

Description

PUSH(1,10000),DS=0.1

.....Axis 1 moves of robot 1 from its current position to the 100000 pulse position with the speed at 0.1% of the pushing movement speed.

● **STOPON conditions setting**

Format

STOPON *conditional expression*

Sample	Description
PUSH(1,10000),STOPON DI(20) = 1Axis 1 of robot 1 moves from its current position toward the "10000 pulses" position and stops at an intermediate point if the "DI (20) = 1" condition is met. The next step is then executed.

Reference "MOVE" statement

● **CONT setting (Continuous Motion)**

Format

CONTON *conditional expression*

Sample	Description
PMOVE(1,P1),CONTON DI(20)=1Axis 1 of robot 1 moves from its current position toward the "P1" position. When "DI (20) = 1" conditions are met, the robot starts decelerating and executed the next step.

Reference "MOVE" statement

Related commands PSHFRC, PSHTIME, PSHMTD, PSHSPD, PSHRSLT, CURTRQ, CURTQST

RADDEG

Performs a unit conversion (radians → degrees)

Format`RADDEG(expression)`**Value****Contents***Expression* Angle (units: radians)**Explanation** Converts the <expression> value to degrees.**Sample****Description**`LOC4(P0)=RADDEG(ATN(B))`

.....Converts the variable B arctangent value to degrees, and assigns it to 4th-axis data of P0.

Related commands

ATN, COS, DEGRAD, SIN, TAN

Format

```
REFTSK(task number)
```

Value **Range**

Value	Range
<i>Task Number</i>	Variable can be specified

Return Value **Range**

Return Value	Range
<i>Task Status</i>	-1 : NON EXISTENT
	0 : STOP
	1 : READY, RUN
	2 : WAIT
	3 : SUSPEND

Explanation Acquires the state of the specified task.
The return value is acquired depending on the status.

By acquiring the task status on the program using this function,
it makes possible to process according to the task status such as task startup.
REFTSK can also be used as an online command.

Reference for Each task status: Chapter 6 "Task status and transition"

SAMPLE 1: Starting task 2

```
A% = REFTSK(2)           ..... Acquires the status of task 2
IF A% = -1 THEN          ..... If task 2 is unregistered (NON EXISTENT),
    START <SUB_PGM>,T2    makes task 2 start.
ELSE
    `Processes in case that task 2 is not started
ENDIF
```

SAMPLE 2: Processing the own task after completing the process of task 2

```
WAIT REFTSK(2) <= 0     ..... Waits until task 2 is stopped (STOP) or
`The following:          unregistered (NON EXISTENT) staus.
processing for own task
```

Format

1. REM *character string*
2. ' *character string*

Explanation

All characters which follow REM or an apostrophe (') are handled as a comment.

This comment statement is used only to insert comments in the program, and it does not execute any command. REM or an apostrophe (') can be entered at any point in the line.

Sample	Description
	All are comment examples
REM *** MAIN PROGRAM ***Comment; *** MAIN PROGRAM ***
'*** SUBROUTINE ***Comment; *** SUBROUTINE ***
HALT 'HALT COMMANDComment; HALT COMMAND

Format 1

RESET	DOm (b, . . . , b) DO (mb, . . . , mb) MOm (b, . . . , b) MO (mb, . . . , mb) TOm (b, . . . , b) TO (nb, . . . , nb) LOm (b, . . . , b) LO (nb, . . . , nb) SOm (b, . . . , b) SO (mb, . . . , mb)
-------	---

Format 2

RESET TCOUNTER

Notation	Value	Range
m	Port Number	2 to 7, 10 to 17, 20 to 27
n	Port Number	0, 1
b	Bit definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).

Reference Bit definition: Chapter 3 "10 Bit Settings"**CAUTION****Output to ports "0" and "1" is not allowed at DO and SO.****Explanation**

Format 1: Turns the bits of specified ports OFF.

Format 2: Clears the 1ms counter variables

(1ms counter variables are used to measure the time in 1ms units).

Sample	Description
RESET DO2()Turns OFF DO(27 to 20).
RESET DO2(6,5,1)Turns OFF DO(26, 25, 21).
RESET (37,35,27,20)Turns OFF DO(37, 35, 27, 20).
RESET TCOUNTERClears the 1ms counter variables.

Related commands SET, DO, MO, SO, TO, LO

Restarts another task during a temporary stop

Format

RESTART	Tn <i><program name></i> PGm	
---------	--	--

Notation	Value	Range
n	Task Number	1 to 16
m	Program Number	1 to 100

Explanation Restarts another task that has been temporarily stopped (SUSPEND status).
A task can be specified by the name or the number of a program in execution.
The program name must be enclosed in < > (angle brackets).

MEMO

.....
If a task (program) not temporarily stopped is specified and executed, an error occurs.
.....

Sample	Description
<pre> START <SUB _ PGM>,T2 FLAG=1 *L0: IF FLAG=1 AND DI2(0)=1 THEN SUSPEND T2 FLAG=2 WAIT DI2(0)=0 ENDIF IF FLAG=2 AND DI2(0)=1 THEN RESTART T2 FLAG=1 WAIT DI2(1)=0 ENDIF MOVE P,P0 MOVE P,P1 GOTO *L0 HALTALL </pre>	<p>Main task</p> <p>.....Registers program i.e. SUB _ PGM in Task 2 and starts it</p> <p>.....Execution set for exclusive control flag 1</p> <p>.....If flag 1 and DI2(0) are ON</p> <p>.....Pauses Task 2</p> <p>.....Substitutes 2 for FLAG</p> <p>(execution set for exclusive control flag 2)</p> <p>.....Waits until DI2(0) turns OFF</p> <p>.....If flag 2 and DI2(0) are ON</p> <p>.....Restarts Task 2</p> <p>.....Execution set for exclusive control flag 1</p> <p>.....Waits until DI2(1) turns OFF</p>
<pre> 'SUBTASK ROUTINE *SUBTASK: DO2(0)=1 DELAY 1000 DO2(0)=0 DELAY 1000 GOTO *SUBPGM EXIT TASK </pre>	<p>Sub Task (Program name: SUB _ PGM)</p> <p>.....Ends the task</p>

Reference "Multi-Task" item in Chapter 6

Related commands CUT, EXIT TASK, START, SUSPEND

Format

1. RESUME
2. RESUME NEXT
3. RESUME *label*

Explanation Resumes program execution after recovery from an error.

Depending on its location, a program can be resumed in the following 3 ways:

1. RESUME The program resumes from the command which caused the error.
2. RESUME NEXT The program resumes from the next command after the command which caused the error.
3. RESUME label The program resumes from the command specified by the <label>.

MEMO

- The RESUME statement can also be executed in an error processing routine..
- Error recovery processing is not possible for serious errors such as "17.800 : Motor overload".

Reference "ON ERROR GOTO"

Related commands ON ERROR GOTO

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Processing which was branched by GOSUB, is returned to the next line after GOSUB

* GOSUB can also be expressed as "GO SUB".

Format

```
GOSUB label
:
label:
:
RETURN
```

Explanation Ends the subroutine and returns to the next line after the jump source GOSUB statement.

- Jump to a subroutine by a GOSUB statement; the subroutine (jump destinations) must end by a RETURN statement.
- Jump from a routine by a GOTO statement; an error such as "5.212: Stack overflow" may occur.

Sample**Description**

*ST:Main program (label definition)
MOVE P,P0	
GOSUB *CLOSEHANDJumps to Subroutine *CLOSEHAND
MOVE P,P1	
GOSUB *OPENHANDJumps to Subroutine *OPENHAND
GOTO *STJumps to Main program *ST
HALT	
'SUB ROUTINE	(Comment) The following is a subroutine
*CLOSEHAND:Subroutine *CLOSEHAND label definition
DO(20) = 1When DO(20) is turned ON
RETURNExecutes from the next line of GOSUB statement *CLOSEHAND
*OPENHAND:Subroutine *OPENHAND label definition
DO(20) = 0When DO(20) is turned OFF
RETURNExecutes from the next line of GOSUB statement *OPENHAND

Related commands GOSUB

Extracts a character string from the right end of another character string

Format

RIGHT\$ (*character string expression* , *expression*)

Value	Range
<i>Expression</i>	0 to 255

Explanation This function extracts a character string with the digits specified by the <expression> from the right end of the character string specified by <character string expression>.

- If the <expression> value is out of the range of 0 - 255; an error will occur.
- If the <expression> value is 0; the extracted character string will be a null string (empty character string).
- If the <expression> value has more characters than the <character string expression>; extracted character string will become the same as the <character string expression>.

Sample	Description
B\$=RIGHT\$(A\$,4)4 characters from the right end of A\$ are assigned to B\$.

Related commands LEFT\$, MID\$

RIGHTY

Sets the SCARA robot hand system as a right-handed system

FormatRIGHTY [*robot number*]**Value***Robot Number***Range**

1 to 4 (If not input, robot 1 is specified.)

Explanation


Specifies the robot as a right-handed system.

The robot moves to a point specified in the Cartesian coordinates.

- This statement only selects the hand system, and does not move the robot. If executed.
- While the robot arm is moving, execution waits until movement is complete (positioned within tolerance range).
- This command is only valid for SCARA robots.

Sample**Description**

RIGHTYSpecifies the hand system of robot 1 as a right-handed system.
MOVE P,P1(1)
LEFTYSpecifies the hand system of robot 1 as a left-handed system.
MOVE P,P1(2)
RIGHTYSpecifies the hand system of robot 1 as a right-handed system.
HALT	

SAMPLE:LEFTY/RIGHTY**Related commands**

LEFTY

Format

```
RSHIFT(expression 1, expression 2)
```

Explanation Shifts the *<expression 1>* bit value to the right by the amount of *<expression 2>*. Spaces left blank by the shift are filled with zeros (0).

Sample	Description
A=RSHIFT(&B10111011,2)The 2-bit-right-shifted &B10111011 value (&B00101110) is assigned to A.

Related commands	LSHIFT
------------------	--------

Specifies/acquires R axis inertia for SCARA parameter.

Format

SCRINR [*robot number*] *expression*

Value**Range**

Robot Number

1 to 4 (If not input, robot 1 is specified.)

Expression

Value of R axis inertia for SCARA parameter
0 to 32767 (units: $\text{kgm}^2 \times 10^{-4}$)

Explanation Changes the value of "R axis inertia for SCARA" parameter of specified robot to the <expression> value. This command is invalid for robots other than the SCARA robot.

Sample**Description**

SCRINR 100Sets "R axis inertia for SCARA" parameter of robot 1 to 100.
SCRINR[2] 200Sets "R axis inertia for SCARA" parameter of robot 2 to 200.

Functions**Format**

SCRINR [*robot number*]

Value**Range**

Robot Number

1 to 4 (If not input, robot 1 is specified.)

Explanation This function acquires the value of "R axis inertia for SCARA" parameter of specified robot.

Sample**Description**

A% = SCRINRThe "R axis inertia for SCARA" parameter of robot 1 is assigned to the variable A%.
A% = SCRINR[2]The "R axis inertia for SCARA" parameter of robot 2 is assigned to the variable A%.

Format

```

SELECT CASE expression
  CASE expression list 1
    command block 1
  CASE expression list 2
    command block 2
  :
  CASE ELSE
    command block n
END SELECT

```

Value	Range / Meaning (Setting Method)
<i>Expression</i>	General purpose input signals or Variables
<i>Expression List</i>	Decimal value or string. Multiple items are specifiable by separating with comma ","
<i>Command Block</i>	One command should be written within one line

MEMO Sample of <expression>

DI (24, 23, 22, 21, 20) :

Recognizes the specified I/O for 5 bit in binary and executes the corresponding <command block> in the <expression list>.

ABC% : Specifies a variable. It executes the <command block> in the <expression list> according to the variable value.

Explanation These statements execute multiple command blocks in accordance with the <expression> value.

If the <Expression> value matches one of expressions contained in the <expression list>

The specified command block is executed. After executing the command block, the program jumps to the next command which follows the END SELECT statement.

If the <expression> value does not match any of the expressions contained in the <expression list>

The command block indicated after the CASE ELSE statement is executed. After executing the command block, the program jumps to the next command which follows the END SELECT statement.

If the <expression> value does not match any of the expressions contained in <expression list> and no CASE ELSE statement exists

The program jumps to the next command following the END SELECT statement.

Sample	Description
<pre> WHILE 1 SELECT CASE DI3(7,6,5,4,3,2,1,0) CASE &B00000001 MOVE P,P1 CASE &B00000010 MOVE P,P2 CASE &B00000011 MOVE P,P3 CASE ELSE MOVE P,P0 END SELECT WEND </pre>	<pre>Executes each command block according to the input status of DI3(8 bits)Command block when DI3(0) is ONWhen DI3(1) is ONWhen DI3(0) and DI3(1) is ONCase other than the aboveEnds SELECT CASE statement </pre>

Format

```
SEND read-out file TO write file
```

Explanation Sends <read-out file> data to the <write file>.

- An entire DO, MO, TO, LO, SO, or SOW port (DO(), MO(), etc.), cannot be specified as a write file.
- Some individual files (DOn(), MOn(), etc.) cannot be specified as a write file.

Reference Chapter 10 "Data file description"

- Writing to read-only files (indicated by a "--" in the "Write" column of the table shown below) is not permitted.
- Even if the read-out/write files are specified correctly, it may not be possible to execute them if there is a data format mismatch between the files.

**NOTE**

1. Examples of erroneous writing to a read-only file:

- SEND CMU TO DIR
- SEND PNT TO SIQ

2. Examples of data format mismatches:

- SEND PGM TO PNT
- SEND SIQ TO SFT

Type	File Name	Definition Format		Read-out	Write	
		All	Individual File			
User	All file	ALL	————	✓	✓	
	Program	PGM	<bbbbbbb> PGn	✓	✓	
	Point	PNT	Pn	✓	✓	
	Point comment	PCM	PCn	✓	✓	
	Point name	PNM	PNn	✓	✓	
	Parameter	PRM	/ccccccc/ #ccccccc# \ccccccc\	✓	✓	
	Shift coordinate definition	SFT	Sn	✓	✓	
	Hand definition	HND	Hn	✓	✓	
	Work definition	WRKDEF	Wn	✓	✓	
	Pallet definition	PLT	PLn	✓	✓	
	General Ethernet Port	GEP	GPn	✓	✓	
	Input/output name	ION	iNMn(n)	✓	✓	
	Area check output	ACO	ACn	✓	✓	
	Real time output	RTO	RTn	✓	✓	
Variable, Constant	Variable	VAR	ab...by	✓	✓	
	Array variable	ARY	ab...by(x)	✓	✓	
	Constant	————	"cc...c"	✓	—	
Status	Program directory	DIR	<<bbbbbbb>>	✓	—	
	Parameter directory	DPM	————	✓	—	
	Machine reference	sensor, stroke-end	MRF	————	✓	—
		mark	ARP	————	✓	—

Type	File Name	Definition Format		Read-out	Write
		All	Individual File		
Status	Accumulated data (*)	ACD	_____	✓ (*)	-
	System configuration information	CFG	_____	✓	-
	Version information	VER	_____	✓	-
	Option board	OPT	_____	✓	-
	Self check	SCK	_____	✓	-
	Alarm history	LOG	_____	✓	-
	Remaining memory size	MEM	_____	✓	-
Device	DI port	DI()	DIn()	✓	-
	DO port	DO()	DOn()	✓	✓
	MO port	MO()	MOn()	✓	✓
	TO port	TO()	TOn()	✓	✓
	LO port	LO()	LOn()	✓	✓
	SI port	SI()	SIn()	✓	-
	SO port	SO()	SOn()	✓	✓
	SIW port	SIW()	SIWn()	✓	-
	SOW port	SOW()	SOWn()	✓	✓
	RS-232C	CMU	_____	✓	✓
	Ethernet	ETH	_____	✓	✓
Other	File END code	EOF	_____	✓	-

✓: Permitted - : Not Permitted

n: number a: Alphabetic character b: Alphanumeric character or underscore (_)
c: Alphanumeric character or special symbol x: Expression (array argument) y: Variable type
i: Input/output type

*) While Accumulated data files is supported with software Ver. 1.73 or later,
Read-out of Accumulated data files is only supported with Ver. 2.04 or later.

MEMO

The following cautions apply when a restart is performed after a stop occurred during execution of the SEND statement.

1. When reading from RS-232C / Ethernet (SEND CMU TO XXX, SEND ETH TO XXX):
When the SEND statement is stopped during data reading from the reception buffer, the data acquired up to that point is discarded.
2. When writing to RS-232C / Ethernet (SEND XXX TO CMU, SEND XXX TO ETH):
When the SEND statement is stopped during data writing to the transmission buffer, the data is written from the beginning.

Sample	Description
SEND PGM TO CMUOutputs all user programs from the RS-232C port.
SEND <PRG1> TO CMUOutputs the PRG1 program from the RS-232C port.
SEND <PRG1> TO CMUInputs a point data file from the RS-232C port.
SEND CMU TO PNTOutputs the "T1" character string from the RS-232C port.
SEND "T1" TO CMUInputs character string data to variable A\$ from the RS-232C port.
SEND CMU TO A\$	

Reference Chapter 10 "Data file description"

Related commands OPEN, CLOSE, SETGEP, GEPSTS

Format

SERVO [robot number]	ON	(axis number)
	OFF	
	FREE	

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6 (• Multiple axes not specifiable • If not input, all axes are specified.)

Explanation This command controls the servo ON/OFF at the specified axes or all axes.

SERVO command	SERVO	Motor power	Dynamic brake	Electromagnetic brake
ON	ON	ON	OFF	OFF
OFF	OFF	OFF (During all axes servo OFF)	ON	ON
FREE	OFF	Continues the previous status	OFF	OFF

**CAUTION**

- Always check that the Emergency Stop is ON and Servo is OFF when working within the robot movement range.
- Electromagnetic brake is the brake to prevent the vertical axis from sliding downward. The vertical axis will slide downward when the servo is FREE, causing a hazardous situation.

**MEMO**

- This command is executed after the operation of all axes of the specified robot has been complete (after positioned within the tolerance).
- The motor power is a power supply unit for robot (motor) in the controller.
- The dynamic brake controls the motor by using the electric power which is generated in the motor when the servo is turned OFF.

Sample**Description**

SERVO ONTurns servos ON at all axes of robot 1.
SERVO OFFTurns the servo OFF and applies the dynamic brake at all axes of robot 1. Axes equipped with brakes are all locked by the brake.
SERVO FREE(3)Turns servos OFF at axis 3 (Z-axis) of robot 1, and releases the brake.

Format		
SET	DOm (b , . . . , b) DO (mb , . . . , mb) MOm (b , . . . , b) MO (mb , . . . , mb) TO n (b , . . . , b) TO (nb , . . . , nb) LO n (b , . . . , b) LO (nb , . . . , nb) SOm (b , . . . , b) SO (mb , . . . , mb)	, time

Notation	Value	Range
m	Port Number	2 to 7, 10 to 17, 20 to 27
n	Port Number (TO, LO)	0, 1
b	Bit definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	Time	10 to 3600000 (units: ms)

Reference Bit definition: Chapter 3 "10 Bit Settings"



CAUTION

Output to ports "0" and "1" are NOT allowed at DO and SO.

Explanation Turns ON the bits of specified ports.

The pulse output time (unit: ms) is specified by the <time> value.

The program execution is WAIT status while the output is ON. When the specified time elapses, the output is turned OFF, and the execution ends.

If no hardware port exists, nothing is output.

Sample	Description
SET DO2 ()Turns OFF DO(27 to 20).
SET DO2 (6,5,1),200DO(26,25,21) switches ON for 200 ms.
SET DO (37,35,27,20)Turns DO(37, 35, 27, 20) ON.

Related commands RESET, DO, MO, SO, TO, LO

Format

```
SETGEP m, n, "IP address", ppppp, e, t
```

Notation	Value	Range / Meaning
m	General Ethernet Port number	0 to 7
n	Mode	0: server, 1: client
	IP address	0.0.0.0 to 255.255.255.255
ppppp	Port Number	0 to 65535
e	Termination code	0: CRLF, 1: CR
t	Port Type	0: TCP

Explanation Sets the specified General Ethernet Port. The General Ethernet Port can open/ close the communication port by OPEN/ CLOSE commands.
 <IP address> must be enclosed in " " (double quotation marks).
 When "0: server" is selected at "n: mode", although <IP address> can be omitted, " " (double quotation marks) must be written.

MEMO**When Server mode is selected,**

- IP address: IP address already set on the controller is used to communicate, so IP address setting is unnecessary. (The IP address set by <IP address> is invalid in this case.)
- Port number: Set a port number which differs from the one on the controller.

When Client mode is selected,

- IP address and port number: Set the IP address and port number of the connection destination server.

Sample	Description
IPADRS\$="192.168.0.100"Assigns the IP address(192.168.0.100) of the server to connect to variable IPADRS\$.
SETGEP 1, 1, IPADRS\$, 100, 0, 0Sets the conditions below on General Ethernet Port 1. <ul style="list-style-type: none"> • Mode: client • IP address of the server to connect to: 192.168.0.100 • Port number of the server to connect to: 100 • Termination code : CRLF
OPEN GP1Connects the server specified at General Ethernet Port 1.Sends the character strings "123" from General Ethernet Port 1.
SEND "123" TO GP1Disconnects from the server specified at General Ethernet Port 1.
CLOSE GP1	

Related commands OPEN, CLOSE, SEND, GEPSTS

Format

1. SGI n=xxxxxxx
2. SGI (n) =xxxxxxx

Notation	Value	Range
n	Integer Type Static Variable Number	0 to 31
xxxxxx		Integer of -2147483648 to 2147483647

Explanation Assigns xxxxxx to the integer type static variable (SGI) specified by "n". If a real number with decimal point is specified at xxxxxx, assigns a value with decimal fractions truncated.

Sample	Description
SGI1=300Assigns 300 to SGI1.

Functions**Format**

1. SGI n
2. SGI (n)

Notation	Value	Range
n	Integer Type Static Variable Number	0 to 31

Explanation Acquires the value of the integer type static variable (SGI) specified by "n".

Sample	Description
A%=SGI1Assigns the value of SGI1 to variable A%.

Related commands SGR

Assigns /acquires the value to a specified real type static variable

Format

- 1 .SGRn=xxxxxx
- 2 .SGR (n) =xxxxxx

Notation	Value	Range
n	Real Type Static Variable Number	0 to 31
xxxxxx	<ol style="list-style-type: none"> 1. Single-precision Real Numbers 	-999999.9 to +999999.9 Note: 7 digits including integers and decimals. (For example, ".0000001" may be used.)
	<ol style="list-style-type: none"> 2. Single-precision Real Numbers in Exponent Form 	-1.0×10 ³⁸ to +1.0×10 ³⁸ Note: Mantissas should be 7 digits or less, including integers and decimals.

Explanation Assigns xxxxxx to the real type static variable (SGR) specified by "n".

Sample	Description
SGR1=1320.355Assigns 1320.355 to SGR1.

Functions**Format**

- 1 .SGRn
- 2 .SGR (n)

Notation	Value	Range
n	Real Type Static Variable Number	0 to 31

Explanation Acquires the value of the real type static variable (SGR) specified by "n".

Sample	Description
A!=SGR1Assigns the value of SGR1 to variable A!.

Related commands SGI

Format

```
SHARED variable( ), variable( ) ...
```

Explanation This statement allows variables declared with a program level code to be referenced with a sub-procedure without passing on the variables as dummy arguments.
The program level variable used by the sub-procedure is specified by the *<variable>* value.
A simple variable or an array variable followed by parentheses is specified. If an array is specified, that entire array is selected



NOTE

The program level code is a program written outside the sub-procedure.

MEMO

- Normally, a dummy argument passes along the variable to a sub-procedure, but the SHARED statement allows referencing to occur without passing along the dummy argument.
- The SHARED statement allows variables to be shared only between a program level code and sub-procedure which are within the same program level

Sample	Description
<pre>DIM Y!(10) X!=2. 5 Y!(10)=1. 2 CALL *DISTANCE CALL *AREA HALT SUB *DISTANCE SHARED X!,Y!() PRINT X!^2+Y!(10)^2 END SUB SUB *AREA DIM Y!(10) PRINT X!*Y!(10) END SUB</pre>	<pre>.....Variable referencing is declared by SHARED.The variable is shared.The variable is not shared.</pre>

Related commands SUB, END SUB

Format

SHIFT [<i>robot number</i>]	<i>shift variable</i>	
	OFF	

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
---------------------	--

Explanation Sets the shift coordinates specified by <shift variable> to the robot specified by <robot number>. When OFF is specified, the coordinates shift by <shift variable> does not occur.

MEMO

- This statement is executed after axis positioning is complete (within the tolerance range).
- When OFF is specified, it is the same as the setting: 0.000 at each X, Y, Z and rotation direction-offset by the <shift variable>.

Sample**Description**

SHIFT S1Shifts the coordinate of robot 1 to the "shift 1" coordinate.
MOVE P,P10 SHIFT S[A]Shifts the coordinate of robot 1 to the coordinate specified by variable A.
MOVE P,P20 HALT	

Related commands

Shift definition statement, shift assignment statement

Format

```
LET expression = SI(m(b, ..., b))
```

```
LET expression = SI(mb, ..., mb)
```

Notation	Value	Range
m	Port Number	0 to 7, 10 to 17, 20 to 27
b	bit Definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).

Explanation Acquires SI port input status specified by "m".

Sample	Description
A%=SI2()The input status from SI (27) to SI (20) is assigned to variable A%.
A%=SI0(6,5,1)The SI (06), SI (05), SI (01) input status is assigned to variable A% (when all the above signals are "1" (ON), A% = 7).
A%=SI(37,35,27,10)The SI (37), SI (35), SI (27) SI(10) input status is assigned to variable A% (when all the above signals except SI (27) are "1" (ON), A% = 13).

Format

```
LET SID (m)
```

Notation	Value	Range
m	port number	2, 4, 6, 8, 10, 12, 14*

The output (acquisition) range is -2,147,483,648(&H80000000) to 2,147,483,647(&H7FFFFFFF).

*When SLOW extension is enabled, the range of port number is extended to 2, 4, 6 -14, 24, 26, 28 -126.
For details, refer to RCX3 user's manual "Option board related parameters".

Explanation Acquires the value at the SID port specified by "m".

MEMO

- The information is handled as signed double word data.
 - "0" is input if the specified port does not exist.
 - The lower port number data is placed at the lower address.
- For example, if SIW(2) =&H2345, SIW(3) =&H0001, then SID(2) =&H00012345.

Sample	Description
A%=SID(2)The input status of SIW(2), SIW(3) is assigned to variable A%.
A%=SID(14)The input status of SIW(14), SIW(15) is assigned to variable A%.

Related commands SIW

Acquires the sine value for a specified value

Format`SIN(expression)`**Value***Expression***Contents**

Angle (units: radians)

Explanation This function gives the sine value for the *<expression>* value.**Sample****Description**`A(0)=SIN(B*2+C)`

.....Assigns the expression B*2+C sine value to array A (0).

`A(1)=SIN(DEGRAD(30))`

.....Assigns a 30.0° sine value to array A (1).

Related commands

ATN, COS, DEGRAD, RADDEG, TAN

Format

```
LET SIW(m)
```

Notation	Value	Range
m	port number	2 to 15*

The output (acquisition) range is 0 (&H0000) to 65,535 (&HFFFF).

*When SLOW extension is enabled, the range of port number is extended to 2 -15, 24 - 127.

For details, refer to RCX3 user's manual "Option board related parameters".

Explanation Acquires the value at the SIW port specified by "m".

MEMO

- The information is handled as unsigned word data
- "0" is input if the specified port does not exist.

Sample	Description
A%=SIW(2)The input status of SIW (2) is assigned to variable A%.
A%=SIW(15)The input status of SIW (15) is assigned to variable A%.

Related commands SID

Format

```
Sn = x y z r
```

Value	Range
<i>n</i>	0 to 39
<i>x, y, z, r</i>	-99,999.99 to 99,999.99

Explanation Defines shift coordinate values in order to shift the coordinates for robot movement. Only "mm" units can be used for these coordinate values ("pulse" units cannot be used).

- 1: "n" indicates the shift number.
- 2: The "x" to "r" input data must be separated with spaces (blanks).
- 3: The "x" to "r" input data is recognized as "mm" unit data.
- 4: "x" to "z" correspond to the Cartesian coordinate system's x, y, z coordinate shift values, and "r" corresponds to the xy coordinates' rotational shift values.

**NOTE**

- All input values are handled as constants.
- If the controller power is turned off during execution of a shift coordinate definition statement, a memory-related error such as "9.706: Shift data destroyed" may occur.

Sample	Description
S0 = 0.000 0.000 0.000 0.000	...Defines shift coordinates for S0
S1 = 100.000 200.000 50.000 90.000	...Defines shift coordinates for S1
P3 = 100.000 0.000 0.000 0.000 0.000 0.000	...Defines P3 point data
SHIFT S0	...Changes the coordinates of Robot 1 to S0
MOVE P,P3	...Moves to P3 in PTP
SHIFT S1	...Changes the coordinates of Robot 1 to S1
MOVE P,P3	...Moves to P3 in PTP
HALT	

Related commands Shift assignment statement, SHIFT

Format

1. **LET** SOm(b, ..., b) = *expression*
2. **LET** SO (mb, ..., mb) = *expression*

Notation	Value	Range
m	Port Number	2 to 7, 10 to 17, 20 to 27
b	Bit Definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	<i>Expression</i>	Integer value (If real number is specified, rounds to an integer.) Bits beyond the number of bit whom an assignment destination is required are ignored. (If the port number is specified, the lower 8 bits are valid. if the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)

Explanation Outputs a specified value to the SO port.

Only the <value> data's integer-converted lower bits corresponding to the bits defined at the left side can be output. If the port which does not exist is specified, nothing is output.

Reference Bit Definition: Chapter 3 "10 Bit Settings"



CAUTION Outputs to SO0() and SO1() are not possible.

Sample	Description
SO2()=&B10111000	SO (27, 25, 24, 23) are turned ON, and SO (26, 22, 21, 20) are turned OFF.
SO2(6,5,1)=&B010	SO (25) are turned ON, and SO (26, 21) are turned OFF.
SO3()=15	SO (33, 32, 31, 30) are turned ON, and SO (37, 36, 35, 34) are turned OFF.
SO(37,35,27,20)=A.....	The lower 4 bits of integer-converted variable A are output to SO (37, 35, 27, 20).

Functions**Format**

1. **LET** *expression* = SOm (b, ..., b)
2. **LET** *expression* = SO (mb, ..., mb)

Explanation Indicates SO port output status.

Sample	Description
A%= SO2()Output status of ports SO(27) to SO(20) is assigned to variable A%.
A%= SO0(6, 5, 1)Output status of SO(06), SO(05) and SO(01) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
A%= SO(37,35,27,10)Output status of SO(37), SO(35) , SO(27) and SO(10) is assigned to variable A%. (If all above signals except SO(27) are 1 (ON), then A%=13.)

Related commands RESET, SET

Functions

Format

1. `LET SOm (b, ..., b)`
2. `LET SO (mb, ..., mb)`

Explanation Indicates SO port output status.

Sample	Description
<code>A%= SO2()</code>Output status of ports SO(27) to SO(20) is assigned to variable A%.
<code>A%= SO0(6, 5, 1)</code>Output status of SO(06), SO(05) and SO(01) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
<code>A%= SO(37,35,27,10)</code>Output status of S0(37), SO(35) , SO(27) and S0(10) is assigned to variable A%. (If all above signals except S0(27) are 1 (ON), then A%=13.)

Related commands RESET, SET

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Outputs a specified serial output's double-word information or acquires the output status

Format

```
LET SOD(m) = expression
```

Notation	Value	Range
m	port number	2, 4, 6, 8, 10, 12, 14 (*1)
	<i>Expression</i> (*2)	Integer value (If real number is specified, rounds to an integer.) Bits that exceed the number of bits required for the assignment destination are discarded. (If the port number is specified, the lower 8 bits are valid. If the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)

*1) When SLOW extension is enabled, the range of port number is extended to 2, 4, 6 -14, 24, 26, 28 -126.
For details, refer to RCX3 user's manual "Option board related parameters".

*2) The output range is -2,147,483,648(&H80000000) to 2,147,483,647(&H7FFFFFFF).

Explanation Outputs the value to the SOD port specified by "m".

MEMO

- The information is handled as signed double word data.
 - If a serial port does not actually exist, the information is not output externally
 - The lower port number data is placed at the lower address.
- For example, if SOW(2) = &H2345, SOW(3) = &H0001, then SOD(2) = &H00012345.

Sample	Description
SOD(2) = &H12345678Outputs &H12345678 to SOD(2).
SOD(4) = 1048575Outputs 1048575(&HFFFFFF) to SOD(4).
SOD(2) = A%Outputs the value of variable A% to SOD(2).

Functions

Format

```
LET expression = SOD(m)
```

Notation	Value	Range
m	Port Number	2, 4, 6, 8, 10, 12, 14

Explanation Acquires the SOD port output status specified by "m".

Sample	Description
A% = SOD(2)The output status of SOD(2) is assigned to variable A%.

Related commands SOW

Format

```
LET SOW(m) = expression
```

Notation	Value	Range
m	port number	2 to 15*
	<i>Expression</i>	Integer value (If real number is specified, rounds to an integer.) Bits that exceed the number of bits required for the assignment destination are discarded. (If the port number is specified, the lower 8 bits are valid.) (If the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)

*When SLOW extension is enabled, the range of port number is extended to 2 -15, 24 - 127.
For details, refer to RCX3 user's manual "Option board related parameters".

Explanation Outputs the value to the SOW port specified by "m".

The output range is 0 (&H0000) to 65535 (&HFFFF).

Note that if a negative value is output, the low-order word information will be output after being converted to hexadecimal.

Example: SOW(2)=-255

The contents of -255 (&HFFFFFF01) are assigned to SOW (2).

-255 is a negative value, so the low-order word information (&HFF01) is assigned.

MEMO

- The information is handled as unsigned word data.
- If a serial port does not actually exist, the information is not output externally.
- If a value exceeding the output range is assigned, the low-order 2-byte information is output.

Sample	Description
SOW(2)=&H0001Outputs &H0001 to SOW(2).
SOW(3)=255Outputs 255(&H00FF) to SOW(3).
SOW(15)=A%The contents of variable A% are assigned in SOW (15). If the variable A% value exceeds the output range, the low-order word information will be assigned.

Functions**Format**

```
LET expression = SOW(m)
```

Explanation Acquires the SOW port output status specified by "m".

Sample	Description
A%=SOW(2)The output status of SOW (2) is assigned to variable A%.

Related commands SOD

Format

SPEED [*robot number*] *expression*

Value**Range***Robot Number*

1 to 4 (If not input, robot 1 is specified.)

Expression

1 to 100 (units: %)

Explanation

Changes the program movement speed to the value indicated by <expression>.

This speed change applies to all robot axes and auxiliary axes of the specified robot.

The operation speed is determined by multiplying the automatic movement speed (specified from the programming box and by the ASPEED command), by the program movement speed (specified by SPEED command).

Operation speed = automatic movement speed × program movement speed

Example:

Automatic movement speed ... 80%

Program movement speed ... 50%

Movement speed = 40% (80% × 50%)

**NOTE**

- Automatic movement speed
Specified by programming box operation or by the ASPEED command
- Program movement speed
Specified by SPEED commands or MOVE, DRIVE speed options.

Sample**Description**

ASPEED 100Changes the Automatic movement speed of robot 1 to 100%.
SPEED 70Changes the Program movement speed of robot 1 to 70%.
MOVE P,P0Moves robot 1 from current position to P0 at a speed of 70% (=100 × 70).
SPEED 50Changes the Program movement speed of robot 1 to 50%.
MOVE P,P1Moves robot 1 from current position to P1 at a speed of 50% (=100 × 50).
MOVE P,P2,S=10Moves robot 1 from current position to P2 at a speed of 10% (=100 × 10).
HALT	

Related commands

ASPEED

FormatSQR (*expression*)**Value***Expression***Range**

0 or positive number.

Explanation

Gives the square root of the *<expression>* value. An error occurs if the *<expression>* value is a negative number.

SampleA=SQR(X²+Y²)**Description**

.....The square root of X²+Y² is assigned to variable A.

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Format

START	<program name> PGm	, Tn, p
-------	-----------------------	---------

Notation	Value	Range
m	Program Number	1 to 100
n	Task Number	1 to 16
p	Task priority ranking	1 to 64

Explanation Starts task "n" specified by the program with the "p" priority ranking.
The program name must be enclosed in < > (angle brackets).

Priority ranking

The smaller the priority number, the higher the priority (high priority: 1 to low priority: 64).
If a priority ranking is not specified, "32" is adopted as the priority ranking for this task.

If task number "n" is omitted:

The task with the smallest number among the tasks yet to be started is automatically specified.

If a higher ranked task is RUNNING:

All tasks with lower priority also remain in READY status.

Sample	Description
START <SUB _ PGM>,T2 *ST: MOVE P,P0,P1 GOTO *ST HALT	...Registers the task program SUB _ PGM in task No. 2 and starts it. ...Defines Main program *ST
`SUBTASK ROUTINE *SUBTASK: P100 = WHERE IF LOC3(P100) > 10000 THEN DO(20) = 1 ELSE DO(20) = 0 ENDIF GOTO *SUBTASK EXIT TASK	Program name:SUB _ PGM (Comment) Subtask routine ...Defines Task program *SUBTASK
	...Exits the task program SUB _ PGM

Related commands CUT, EXIT TASK, RESTART, SUSPEND, CHGPRI

Converts a numeric value to a character string

Format

STR\$(*expression*)

Explanation Converts the value specified by the <*expression*> to a character string. The <*expression*> specifies an integer or real value.

Sample

B\$=STR\$(10.01)

Related commands VAL

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Format

```
SUB label (dummy argument, dummy argument...)
    command block
END SUB
```

Explanation Defines a sub-procedure.

The sub-procedure can be executed by a CALL statement. When the END SUB statement is executed, the program jumps to the next command after the CALL statement that was called. Definitions are as follows.

- 1: All variables declared within the sub-procedure are local variables, and these are valid only within the sub-procedure. Local variables are initialized each time the sub-procedure is called up.
- 2: Use a SHARED statement in order to use global variables (program level).
- 3: Use a <dummy argument> when variables are to be passed on. If two or more dummy arguments are used, separate them by a comma (,).
- 4: A valid <dummy argument> consists of a name of variable and an entire array (array name followed by parentheses). An error will occur if array elements (a <subscript> following the array name) are specified.

MEMO

- Sub-procedures cannot be defined within a sub-procedure.
- A label can be defined within a sub-procedure, but it cannot jump (by a GOTO or GOSUB statement) to a label outside the sub-procedure.
- Local variables cannot be used with PRINT and SEND statements.

Sample 1	Description
A=1	
CALL *TESTCalls sub-procedure *TEST
PRINT A	
HALT	
'SUB ROUTINE: TEST	(Comment: Sub-procedure name is "TEST")
SUB *TESTDefines sub-procedure *TEST (NOTE)
A=50	
END SUBEnds the definition of the sub-procedure

(NOTE) Handled as a different variable than the "A" shown above.

MEMO

In the above example, the program level variable "A" is unrelated to the variable "A" within the sub-procedure. Therefore, the value indicated in the 3rd line PRINT statement becomes "1".

Sample 2	Description
X% = 4	
Y% = 5	
CALL *COMPARE(REF X%, REF Y%)	...Calls sub-procedure *COMPARE (pass by reference)
PRINT X%,Y%	...The value of X% is changed to 5 and the value of Y% is changed to 4. (Changes value in sub-procedure => Changes value of variable)
Z% = 7	
W% = 2	
CALL *COMPARE(REF Z%, REF W%)	...Calls sub-procedure *COMPARE (pass by reference)
PRINT Z%,W%	...The value of Z% remains 7 and the value of W% remains 2 (No change in value; Comparison in sub-procedure is false and command is not executed)
HALT	
'SUB ROUTINE: COMPARE	(Comment: Sub-procedure name is "COMPARE")
SUB *COMPARE(A%, B%)	...Starts defining sub-procedure *COMPARE
IF A% < B% THEN	
TEMP% = A%	
A% = B%	
B% = TEMP%	
ENDIF	
END SUB	...Finishes defining sub-procedure

 MEMO

In the above example, different variables are passed along as arguments to call the sub-procedure 2 times.

Related commands CALL, EXIT SUB, SHARED

SUSPEND

Temporarily stops another task which is being executed

Format

SUSPEND	Tn <i><program name></i> PGm	
---------	--	--

Notation	Value	Range
n	Task Number	1 to 16
m	Program Number	1 to 100

Explanation Temporarily stops (suspends) another task which is being executed.

- A task can be specified by the name or the number of a program in execution.
- This statement can also be used for tasks with a higher priority ranking than this task itself.
- The program name must be enclosed in < > (angle brackets).

MEMO

If a task (program) not active is specified for the execution, an error occurs.

Sample	Description
<pre>START <SUB _ PGM>,T2 SUSFLG=0 *L0: MOVE P,P0 MOVE P,P1 WAIT SUSFLG=1 SUSPEND T2 SUSFLG=0 GOTO *L0 HALT</pre>	<p>Main Task</p> <p>.....Registers SUB _ PGM in Task 2 and starts it</p> <p>.....Turns OFF SUSFLG</p> <p>.....Waits until SUSFLG turns ON</p> <p>.....Pauses Task 2</p> <p>.....Turns OFF SUSFLG</p>
<pre>'SUBTASK ROUTINE *SUBTASK: WAIT SUSFLG=0 DO2(0)=1 DELAY 1000 DO2(0)=0 DELAY 1000 SUSFLG=1 GOTO *SUBTASK EXIT TASK</pre>	<p>Sub Task (Program name: SUB _ PGM)</p> <p>.....Waits until SUSFLG turns OFF</p> <p>.....Turns ON SUSFLG</p> <p>.....Jumps to *SUBTASK</p> <p>.....Exits Task 2 (own task: *SUBTASK)</p>

Related commands CUT, EXIT TASK, RESTART, SUSPEND

Format

```
SWI <program name>
```

Explanation This statement switches from the current program to the specified program, starting from the first line.

- Although the output variable status is not changed when the program is switched, the dynamic variables and array variables are cleared.
- The program name must be enclosed in < > (angle brackets).


MEMO

If the program specified as the switching target does not exist, a "3.203: Program doesn't exist" (code: &H0003 &H00CB) error occurs and operation stops.

Sample**Description**

```
MOVE P,P1
SWI <TEST2>
```

.....Switches the execution program to TEST 2.



Acquires the tangent value for a specified value

FormatTAN(*expression*)**Value***Expression***Contents**

Angle (units: radians)

ExplanationGives a tangent value for the <*expression*> value.An error will occur if the <*expression*> value is a negative number.**Sample****Description**

A(0)=B-TAN(C)

.....The difference between the tangent values of variable B and variable C is assigned to array A (0).

A(1)=TAN(DEGRAD(20))

.....The 20.0° tangent value is assigned to array A (1).

Related commands

ATN, COS, DEGRAD, RADDEG, SIN

Format

TCOUNTER

Explanation Outputs count-up values at 1ms intervals starting from the point when the TCOUNTER variable is reset. After counting up to 2,147,483,647, the count is reset to 0.

Sample	Description
<pre> MOVE P,P0 WAIT ARM RESET TCOUNTER MOVE P,P1 WAIT ARM A = TCOUNTER PRINT TCOUNTER </pre>	<p>.....Displays the P0 to P1 movement time until the axis enters the tolerance range on the programming box.</p>

Related commands RESET

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Format

TIME\$

Explanation Acquires the current time in an hh:mm:ss format character string.
 ("hh" is the hour, "mm" is the minutes, and "ss" is the seconds.)
 The clock can be set in the SYSTEM mode's initial processing.

Sample**Description**

Sample	Description
A\$=TIME\$Assigns the current time to the character type variable A\$ as a character string in the format of hh: mm: ss.
PRINT TIME\$Displays the current time on the programming box etc. in the format of hh: mm: ss

Related commands

DATE\$, TIMER

Format

TIMER

Explanation Acquires the current time in seconds, counting from midnight. This function is used to measure a program's run time, etc.

The clock can be set in the SYSTEM mode's initial processing.

**CAUTION**

The time indicated by the internal clock may differ somewhat from the actual time.

Sample	Description
A%=TIMERAssigns the current time to the integer variable A%
FOR B=1 TO 10	in seconds from midnight
MOVE P,P0	
MOVE P,P1	
NEXT	
A%=TIMER-A%Assigns current time - A% to the variable A%
PRINT A%/60;":";A% MOD 60"A% ÷ 60: A% ÷ 60" is displayed
HALT	

Related commands

TIME\$

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Outputs a specified value to the TO port or acquires the output status

Format

1. **LET** `TOm(b, ..., b) = expression`
2. **LET** `TO (mb, ..., mb) = expression`

Notation	Value	Range
m	Port Number	0, 1
b	bit Definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).
	<i>Expression</i>	Integer value (If real number is specified, rounds to an integer.) Bits that exceed the number of bits required for the assignment destination are discarded. (If the port number is specified, the lower 8 bits are valid.) If the number of bit specified on bit definition is 1 to 8, the lower 1 to 8 bit corresponding to the bits specified on the left side are valid.)

Explanation Outputs the specified value to the TO port. The output value is the *<expression>*'s integer-converted lower bits corresponding to the bit definition specified at the left side.

The OFF/ON settings for bits which are being used in a SEQUENCE program have priority while the SEQUENCE program is running.

Sample

```
TO0() = &B00000110
```

Functions

Format

1. **LET** `expression = TOm (b, ..., b)`
2. **LET** `expression = TO (mb, ..., mb)`

Notation	Value	Range
m	Port Number	0, 1
b	bit Definition	0 to 7 (If omitted, all 8 bits are processed.) If multiple bits are specified, they are expressed from the left in descending order (high to low).

Explanation Indicates the parallel port signal status.

Sample	Description
<code>A%= TO0()</code>Output status of ports TO(07) to TO(00) is assigned to variable A%.
<code>A%= TO0(6, 5, 1)</code>Output status of TO(06), TO(05) and TO(01) is assigned to variable A%. (If all above signals are 1(ON), then A%=7.)
<code>A%=TO(17, 15, 00)</code>Output status of T0(17), TO(15) and T0(00) is assigned to variable A%. (If all above signals except T0(15) are 1 (ON), then A%=5.)

Related commands RESET, SET

Format

1. TOLE [*robot number*] *expression*
2. TOLE [*robot number*] (*axis number*) = *expression*

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	Varies according to the motor which has been specified (unit: pulse)

Explanation Change the "tolerance" parameter of the specified axis to the <*expression*> value (unit: pulse).

Format 1: The change is applied to all axes of the specified robot.

Format 2: The change is applied to only the axis specified by the <*axis number*> of the specified robot.

MEMO

.....
 This statement is executed after positioning of the specified axes is complete (within the tolerance range).

Functions**Format**

TOLE [*robot number*] (*axis number*)

Value**Range**

<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the "tolerance" parameter values for the axis specified by <*axis number*>.

Sample**Description**

```
'CYCLE WITH DECREASING TOLERANCE
DIM TOLE(5)
FOR A=200 TO 80 STEP -20
  GOSUB *CHANGE _ TOLE
  MOVE P,P0
  MOVE P,P1
NEXT A
C=TOLE(2)HALT      .....The tolerance parameter of axis 2 of robot 1 is assigned to
*CHANGE _ TOLE:    variable C.
FOR B=1 TO 4
  TOLE(B)=A
NEXT B
RETURN
```

Format

TORQUE [*robot number*] (*axis number*) = *expression*

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6
<i>Expression</i>	1 to 100 (units: %)

Explanation Changes the maximum torque command value of the specified axis to the <*expression*> value. The new value is valid when the next movement command (MOVE or DRIVE statement, etc.) is executed. The parameter value does not change.

The conditions to cancel a torque limit are as follows.

- The TORQUE command for the same axis is executed.
- The controller power turned off and then on again.
- The axis polarity parameter is changed or the parameter is initialized.
- The servo is turned off.

The maximum torque command value becomes temporarily invalid in execution below.

- Return- to-origin is in execution.
- The PUSH statement is in execution.

Only the torque value in the moving direction is changed to the value specified by the PUSH statement, the value in the opposite direction is hold and not changed.

After these movements, the value backs to the maximum torque command value when a next movement command (MOVE statement, for example) is executed.

**CAUTION**

- If the specified torque limit is too small, the axis may not move. Never enter within the robot movement range to avoid danger even though the robot is in stop status. In this case, press the emergency stop button before proceeding with the operation.
- If the specified value is less than the rated torque, an error may not occur even if the robot strikes an obstacle.

**MEMO**

- TORQUE statement limits the torque in the both (rotation and opposite) direction of axis.
- PUSH statement limits the torque in its rotation direction only.

Functions

Format

TORQUE [*robot number*] (*axis number*)

Value	Range
<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)
<i>Axis Number</i>	1 to 6

Explanation Acquires the maximum torque command value for the axis specified by *<axis number>*.

Sample	Description
TORQUE (1) = 50Changes the max. torque of axis 1 of robot 1 to 50%.
DRIVE (1,P1)Moves the axis 1 of robot 1 from its current position to the point specified by P1. (Changes the max. torque at the same time with the start of the movement.)
WAIT ARMWaits for the completion of an operation of axis 1 of robot 1.Returns the max. torque of axis 1 of robot 1 to the original value (100%).
TORQUE (1) = 100Moves the robot 1 from its current position to the point specified with P0.
MOVE P,P0	(Returns the max. torque of axis 1 to the original value (100%) at the same time with the start of a movement.)

Related commands CURTRQ, PUSH

TSKPGM

Acquires the program number which is registered in a specified task number

Format

TSKPGM (*task number*)

Value

Task Number

Meaning

Task number which acquires the program number

Explanation Acquires the program number which is registered in the task specified by the <*task number*>.

Sample**Description**

A=TSKPGM(1)Assigns a program number registered in task 1 to variable A.

Related commands

PGMTSK, PGN

Format

VAL (*character string expression*)

Explanation Converts the numeric value of the character string specified in the <character string expression> into an actual numeric value.

- The value may be expressed in integer format (binary, decimal, hexadecimal), or real number format (decimal point format, exponential format).
- The VAL value becomes "0" if the first character of the character string is "+", "-", "&" or anything other than a numeric character.
- If there are non-numeric characters or spaces elsewhere in the character string, all subsequent characters are ignored by this function.
However, for hexadecimal expressions, "A" to "F" are considered numeric characters.

[Integer] Hexadecimal format: &Hnnnn
 Decimal format: nnnn
 Binary format: &Bnnnn

[Real number] Decimal point format: nnn.nnn
 Exponential format: nnEmm

Sample

A=VAL("&B100001")

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Format

WAIT *conditional expression* , *expression*

Value

conditional expression

Range/Description

Specify with Input/Output signals or variables

Expression

0 to 2147483647 (units: ms)

Explanation

Waits until the <conditional expression> is met.

Set the time-out period (unit: ms) in the <expression>.

- This command will terminate if the time-out period elapses before the WAIT condition is met.
- The minimum wait time is 1ms but changes depending on the execution status of other tasks.

**CAUTION**

If the time-out setting is omitted, robot will stop without alarm unless you stop the program from the outside (by an interlock or an emergency stop, etc.) while the conditional expression is not met.

**MEMO**

When the conditional expression is a numeric expression, an expression value other than "0" indicates TRUE status, and "0" indicates FALSE status.

Sample**Description**

WAIT A=10Wait status continues until variable A becomes 10.
WAIT DI2()=&B01010110Waits until DI(21),(22),(24),(26) are turned on, and DI(20),(23),(25),(27) is turned off.
WAIT DI2(4,3,2)=&B101Waits until DI(22) and DI(24) are turned on, and DI(23) is turned off.
WAIT DI(31)=1 OR DO(21)=1Wait status continues until either DI (31) or DO(21) turns ON.
WAIT DI(20)=1,1000Wait status continues until DI(20) turns ON. If DI(20) fails to turn ON within 1 second, the command is terminated.
WAIT END _ SENSOR = 1IO Name* Waits until "END _ SEMSOR" is turned on.

* IO Name: Users can name specific bits of DI and DO as they desire.

**MEMO**

IO Name can be added and edited on the support software only (not with a programming box)

Related commands

DRIVE, DRIVEI, MOVE, MOVEI, MOVET

Waits until the robot axis operation is completed

Format

WAIT ARM [*robot number*] (*axis number*)

Value**Range***Robot Number*

1 to 4 (If not input, robot 1 is specified.)

Axis Number

1 to 6 (• Multiple axes not specifiable • If not input, all axes are specified.)

Explanation

Establishes "wait" status until the axis movement is completed (is positioned within the tolerance range).

Sample**Description**

WAIT ARM

.....Waits for the movement completion of robot 1.

WAIT ARM2

.....Waits for the movement completion of axis 2 of robot 2.

Related commands

DRIVE, DRIVEI, MOVE, MOVEI, MOVET, PMOVE

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

Format

WEIGHT [*robot number*] *expression*

Value**Range**

Robot Number

1 to 4 (If not input, robot 1 is specified.)

Expression

The range varies according to the robot which has been specified.

Explanation Changes the "tip weight (kg)" parameter of the robot to the *<expression>* value. This change does not apply to auxiliary axes.

Functions**Format**

WEIGHT [*robot number*]

Value**Range**

Robot Number

1 to 4 (If not input, robot 1 is specified.)

Explanation Acquires the "tip weight (kg)" parameter value of the robot specified by *<robot number>*.

Sample**Description**

A=5

B=2

C=WEIGHTThe tip weight(kg) parameter of robot 1 is assigned to variable C.

WEIGHT AThe tip weight(kg) parameter of robot 1 is changed to value (5) of variable A.

MOVE P,P0

WEIGHT BThe tip weight(kg) parameter of robot 1 is changed to value (2) of variable B.

MOVE P,P1

WEIGHT CThe tip weight(kg) parameter of robot 1 is replaced to the origin value (the value of variable C).

D=WEIGHTThe tip weight(kg) parameter of robot 1 is assigned to variable D.

HALT

MEMO

If both of Tip weight parameters; *<WEIGHT>* and *<WEIGHTG>* are set, a total value will be set.

Related commands

WEIGHTG

Format

WEIGHTG [*robot number*] *expression*

Value**Range**

Robot Number

1 to 4 (If not input, robot 1 is specified.)

Expression

The range varies according to the robot which has been specified.

Explanation

Changes the "tip weight (g)" parameter of the robot to the <expression> value.
This change does not apply to auxiliary axes.

Functions**Format**

WEIGHTG [*robot number*]

Value**Range**

Robot Number

1 to 4 (If not input, robot 1 is specified.)

Explanation

Acquires the "tip weight (g)" parameter value of the robot specified by <robot number>.

Sample**Description**

A=5

B=2

C=WEIGHTGThe tip weight(g) parameter of robot 1 is assigned to variable C.

WEIGHTG AThe tip weight(g) parameter of robot 1 is changed to value (5) of variable A.

MOVE P,P0

WEIGHTG BThe tip weight(g) parameter of robot 1 is changed to value (2) of variable B.

MOVE P,P1

WEIGHTG CThe tip weight(g) parameter of robot 1 is replaced to the origin value (the value of variable C).

D=WEIGHTGThe tip weight(g) parameter of robot 1 is assigned to variable D.

HALT

MEMO

If both of Tip weight parameters; <WEIGHT> and <WEIGHTG> are set, a total value will be set.

Related commands

WEIGHT

Format

```

WHILE conditional expression
    command block
WEND

```

Explanation Ends the command block which begins with the WHILE statement. A WEND statement must always be paired with a WHILE statement.

Jumping out of the WHILE to WEND loop is possible by using the GOTO statement, etc.

Sample	Description
<pre> A=0 WHILE DI3(0)=0 A=A+1 MOVE P,P0 MOVE P,P1 PRINT "COUNTER=";A WEND HALT </pre>	<p>.....Repeats between WHILE and WEND while DI3(0) is OFF</p> <p>.....Ends the command block of WHILE statement</p>

Related commands **WHILE**

Acquires the arm's current position (pulse coordinates)

FormatWHERE [*robot number*]**Value***Robot Number***Range**

1 to 4 (If not input, robot 1 is specified.)

Explanation Acquires the arm's current position in the joint coordinates.**Sample**

P10=WHERE

Description

.....The current position's pulse coordinate value of robot 1 is assigned to P10.

Related commands

WHRXY

Format

```

WHILE conditional expression
    command block
WEND

```

Explanation Executes the command block between the WHILE and WEND statements when the condition specified by the *<conditional expression>* is met, and then returns to the WHILE statement to repeat the same operation.

When the *<conditional expression>* condition is no longer met (becomes false), the program jumps to the next command after the WEND statement.

If the *<conditional expression>* condition is not met from the beginning (false), the command block between the WHILE and WEND statements is not executed, and a jump occurs to the next statement after the WEND statement.

Jumping out of the WHILE to WEND loop is possible by using the GOTO statement, etc.

MEMO

When the conditional expression is a numeric expression, an expression value other than "0" indicates TRUE status, and "0" indicates FALSE status.

Sample 1**Description**

```

A=0
WHILE DI3(0)=0          .....Repeats between WHILE and WEND while DI3(0) is OFF
    A=A+1
    MOVE P,P0
    MOVE P,P1
    PRINT "COUNTER=";A
WEND                    .....Ends the command block of WHILE statement
HALT

```

Sample 2**Description**

```

A=0
WHILE -1          .....Becomes an endless loop because the conditional expression is always
                  TRUE (other than 0).
    A=A+1
    MOVE P,P0
    IF DI3(0)=1 THEN *END
    MOVE P,P1
    PRINT "COUNTER=";A
    IF DI3(0)=1 THEN *END
WEND              .....Ends the command block of WHILE statement
*END
HALT

```


FormatWHRXY [*robot number*]**Value** **Range***Robot Number* 1 to 4 (If not input, robot 1 is specified.)**Explanation** Acquires the arm's current position in the Cartesian coordinates. **MEMO**

For YK-TW robot, the first and the second arm rotation information is also acquired.

Sample 1 **Description**

P10=WHRXY The current position Cartesian coordinate value of robot 1 is assigned to P10.

Sample 2 **Description**

LOC3(P10)=LOC3(WHRXY)The current position data of the third axis is assigned to the third axis at P10 in the cartesian coordinate system.

Related commands WHERE

WRKDEF

Defines the work data (creates the work data of the specified number)

Format**Statement for Definition:**

```
WRKDEF Wn = X-coordinate Offset  Y-coordinate Offset
           Z-coordinate Offset  R-coordinate Offset
```

Statement for Selection:

```
CHGWRK [robot number]
```

Notation	Value	Range	Unit
	<i>Robot Number</i>	1 to 4 (If not input, robot 1 is specified.)	
n	<i>Work Number</i>	0 to 39	
	<i>X-coordinate Offset</i>		mm
	<i>Y-coordinate Offset</i>	Numeric value consisting of an integer portion of up to 4 digits and having 3 or less places below the decimal point	mm
	<i>Z-coordinate Offset</i>		mm
	<i>R-coordinate Offset</i>		degree

Explanation WRKDEF statement defines the work data.

Note that this command executes the definition only.
Use the CHGWRK statement to actually switch the work data.

Reference "CHGWRK", User's Manual "Work definitions"

MEMO

"9.708: Work data destroyed" error may occur if the power of controller is turned off during the execution of WRKDEF.

● Parameter Value

X-coordinate Offset : The offset amount from the robot tip (the tool tip; in use of the hand data) of the work "n" on X-coordinates is specified in real number.

Y-coordinate Offset : The offset amount from the robot tip (the tool tip; in use of the hand data) of the work "n" on Y-coordinates is specified in real number.

Z-coordinate Offset : The offset amount from the robot tip (the tool tip; in use of the hand data) of the work "n" on Z-coordinates is specified in real number.


R-coordinate Offset : The angle of + X direction and the work "n" in the Cartesian coordinates is specified in real number when the current position of the robot tip (the tool tip; in use of the hand data) is "0.000" on R-coordinates.

Enter positive value in counterclockwise.

Related commands CHGWRK, CREWRK

Sample	Description
CHANGE H1Changes the hand data of the robot 1 to hand 1.
MOVE P,P1Moves the hand 1 tip of the robot 1 to P1.
WRKDEF W1 = 115.000 -50.000 0.000 30.000	
CHGWRK W1Changes the work data of the robot 1 to work 1.
MOVE P,P2Moves the work 1 tip of the robot 1 to P2.
HALT	

SAMPLE: WRKDEF



- N
- O
- P
- Q
- R
- S
- T
- U
- V
- W**
- X
- Y
- Z

XYTOJ

Converts the Cartesian coordinate data ("mm") to joint coordinate data ("pulse")

Format

XYTOJ [*robot number*] (*point expression*)

Value

Robot Number

Range

1 to 4 (If not input, robot 1 is specified.)

Explanation

This function converts the Cartesian coordinate data (unit: mm, deg.) of <point expression> to the joint coordinate data (unit: pulse).

The data is converted based on the shift (offset) format that is already set; standard coordinates, shift coordinates and hand definition.

- On SCARA robots, the converted result differs depending on whether right-handed or left-handed is specified.
- On the YK-TW series, the result varies, depending on the first arm and the second arm rotation information settings.
- To convert joint coordinate data to Cartesian coordinate data, use the JTOXY statement.

Sample

P10=XYTOJ(P10)

Description

.....P10 is converted to joint coordinate data of robot 1.

Chapter 9

PATH Statements

1	Overview	9-1
2	Features	9-1
3	How to use.....	9-1
4	Cautions when using this function	9-2

This function moves the robot at a specified speed along a path composed of linear and circular segments. Because speed fluctuations during movement are minimal, the PATH function is ideal for applications such as sealing, etc.

- Moves the robot at a constant speed along the entire movement path (except during acceleration from a stop, and during deceleration just prior to the operation end).
- Permits easy point teaching because the robot speed is not affected by the point teaching positions' level of precision.
- Permits movement speed changes for the entire movement path, or speed changes for only one portion of the path (using the speed option).
- Using the DO option permits signal outputs to a specified port at any desired position during movement.

The following robot language commands must be used as a set in order to use the PATH function.

- PATH SET Starts path setting.
- PATH (PATH L, PATCH C) Specifies the path to be used.
- PATH END Ends path setting.
- PATH START Starts actual movement along the path.

As shown below, the motion path is specified between the PATH SET and PATH END statements.

Simply specifying a path, however, does not begin robot motion.

Robot motion only occurs when the PATH START statement is executed after the path setting procedure has been completed.

Sample	Description
MOVE P, P0, Z=0Start of robot 1's path setting
PATH SET	
PATH L, P1, DO(20)=1@10.0	
PATH L, P2	
:	
:	
:	
PATH C, P12, P13	
PATH L, P14, DO(20)=0@20.0	
PATH ENDEnd of robot 1's path setting
MOVE P, P1, Z=0	
:	
:	
:	
MOVE P, P0, Z=0	
PATH STARTExecutiong Path motion of robot 1
HALT	


- Paths may comprise no more than 1000 points (total) linear and circular segments. 1 point forms 1 linear segment by PATH L command and 2 points form 1 circular segment by PATH C command.

$$\text{Number of points specified by PATH L} + \frac{\text{Number of points specified by PATH C}}{2} \leq 1000$$

- The robot must be positioned at the path start point when PATH motion is executed (by PATH START statement).
- At points where circular and linear segments connect, the motion direction of the two connecting segments should be a close match (as close as possible). An excessive difference in their motion directions could cause vibration and robot errors.


Circular and linear segment connection point:

if there is a large difference between the motion directions of the connecting segments



- Where a linear segment connects to another linear segment, the motion path passes to the inner side of the connection point. Moreover, as shown in fig. (1) below, the faster the speed, the further to the inner side the path becomes. To prevent significant speed-related path shifts, add more points as shown in fig. (2). Note also, that in some cases, the speed may have to be reduced in order to prevent errors from occurring.

Linear segments connection point: Prevents a deviation



- If an error occurs due the robot's inability to move at the specified speed:
- Robot acceleration/deceleration occurs if the speed setting is changed when PATH motion begins, stops, or at some point along the path. At such times, an error may occur before motion begins if the distance between points is too short for the specified speed to be reached. In such cases, a slower speed must be specified. If the error still occurs after the speed is lowered, adjust the PATH points to increase the length of the linear or circular segments which contain acceleration or deceleration zones.
- The hand system used during PATH motion must be the same as the hand system used at the path's start point. The same applies if the path is to pass through points where hand flags are set. Differing hand systems will cause an error and disable motion.
- The first arm and second arm rotation information during PATH movement must be the same as the first arm and second arm rotation information at the PATH movement's START point. If the two are different, an error will occur and movement will be disabled.
- If the robot is stopped by a stop signal, etc., during PATH motion, this is interpreted as an execution termination, and the remaining path motion will not be completed even if a restart is executed.
- Only the X, Y and Z coordinate values among the specified points are valid for PATH motion. Any other coordinates use the coordinate values at the START point of the PATH motion; R-axis can not be moved to the specified point even if it is used.

Chapter 10

Data file description

1	Overview	10-1
2	Program file	10-3
3	Point file	10-5
4	Point comment file	10-8
5	Point name file	10-10
6	Parameter file.....	10-12
7	Shift coordinate definition file.....	10-16
8	Hand definition file	10-18
9	Work definition file	10-20
10	Pallet definition file	10-22
11	General Ethernet port file.....	10-26
12	Input/output name file	10-28
13	Area check output file	10-32
14	Real time output file	10-34
15	All file	10-38
16	Program directory file	10-40
17	Parameter directory file	10-42
18	Machine reference file	10-43

19 Accumulated data file.....	10-45
20 System configuration information file	10-46
21 Version information file	10-47
22 Option board file	10-48
23 Self check file	10-49
24 Alarm history file	10-50
25 Remaining memory size file	10-52
26 Variable file	10-53
27 Constant file	10-59
28 Array variable file	10-60
29 DI file	10-62
30 DO file	10-64
31 MO file	10-66
32 LO file	10-68
33 TO file	10-70
34 SI file.....	10-72
35 SO file.....	10-74
36 SIW file	10-76
37 SOW file	10-78
38 EOF file	10-80
39 Serial port communication file.....	10-81
40 Ethernet port communication file	10-82

1.1 Data file types

This section explains data files used with a SEND statement and READ/WRITE online commands.

Type	File Name	Definition Format		Read-out	Write	
		All	Individual File			
User	All file	ALL	_____	✓	✓	
	Program	PGM	<bbbbbbb> PGn	✓	✓	
	Point	PNT	Pn	✓	✓	
	Point comment	PCM	PCn	✓	✓	
	Point name	PNM	PNn	✓	✓	
	Parameter	PRM	/ccccccc/ #ccccccc# \ccccccc\	✓	✓	
	Shift coordinate definition	SFT	Sn	✓	✓	
	Hand definition	HND	Hn	✓	✓	
	Work definition	WRKDEF	Wn	✓	✓	
	Pallet definition	PLT	PLn	✓	✓	
	General Ethernet Port	GEP	GPn	✓	✓	
	Input/output name	ION	iNm(n)	✓	✓	
	Area check output	ACO	ACn	✓	✓	
Real time output	RTO	RTn	✓	✓		
Variable, Constant	Variable	VAR	ab...by	✓	✓	
	Array variable	ARY	ab...by(x)	✓	✓	
	Constant	_____	"cc...c"	✓	-	
Status	Program directory	DIR	<<bbbbbbb>>	✓	-	
	Parameter directory	DPM	_____	✓	-	
	Machine reference	sensor, stroke-end	MRF	_____	✓	-
		mark	ARP	_____	✓	-
	Accumulated data (*)	ACD	_____	✓ (*)	-	
	System configuration information	CFG	_____	✓	-	
	Version information	VER	_____	✓	-	
	Option board	OPT	_____	✓	-	
	Self check	SCK	_____	✓	-	
	Alarm history	LOG	_____	✓	-	
Remaining memory size	MEM	_____	✓	-		
Device	DI port	DI()	DIn()	✓	-	
	DO port	DO()	DOn()	✓	✓	
	MO port	MO()	MOn()	✓	✓	
	TO port	TO()	TOn()	✓	✓	
	LO port	LO()	LOn()	✓	✓	
	SI port	SI()	SIn()	✓	-	
	SO port	SO()	SOn()	✓	✓	
	SIW port	SIW()	SIWn()	✓	-	
	SOW port	SOW()	SOWn()	✓	✓	
	RS-232C	CMU	_____	✓	✓	
	Ethernet	ETH	_____	✓	✓	
Other	File END code	EOF	_____	✓	-	

n: Number a: Alphabetic character b: Alphanumeric character or underscore (_)
 c: Alphanumeric character or special symbol x: Expression (array argument) y: Variable type
 i: Input/output type

✓: Permitted -: Not Permitted

*) While Accumulated data files is supported with software Ver. 1.73 or later,
 Read-out of Accumulated data files is only supported with Ver. 2.04 or later.

1.2 Cautions

Observe the following cautions when handling data files.

- Only one-byte characters can be used.
- All data is handled as character strings conforming to ASCII character codes.
- Only upper-case alphabetic characters may be used in command statements (lower case characters are prohibited).
- Line lengths must not exceed 255 characters.
- A [cr/lf] data format designation indicates CR code (0Dh) + LF code (0Ah).
- The terms "reading out" and "writing" used in this manual indicate the following data flow;
Reading out: Controller → external communication device
Writing: External communication device → controller

2.1 All programs

Read-out	✓	When used as a read-out file, all programs currently stored are read out.
Write	✓	Write files are registered at the controller under the program name indicated at the "NAME = <i>program name</i> " line.

Format

PGM

Meaning

- Expresses all programs.
- If there is a specification of a program number in the case of a write file, the new program overwrites.
- If the program number is omitted in the case of a write file, the assignment is made to the smallest free number.
If there are programs with the same name and with different program numbers, the older program is deleted.

Data Format

```
NAME = program name [cr/lf]
PGN=mmm [cr/lf]
aaaaa ...aaaaaaaaaaaaa [cr/lf]
      :
aaaaa ...aaaaaaaaaaaaa [cr/lf]
      :
NAME = program name [cr/lf]
PGN=mmm [cr/lf]
aaaaa ...aaaaaaaaaaaaa [cr/lf]
      :
aaaaa ...aaaaaaaaaaaaa [cr/lf]
[cr/lf]
```

Notation	Value	Range
a	Character code	0 to 7, 10 to 17, 20 to 27
mmm	Program number	1 to 100

- *Program names* are shown with 32 characters or less consisting of alphanumeric characters and _ (underscore).
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND PGM TO CMUOutputs all programs from the communication port. SEND CMU TO PGMInputs all programs from the communication port.	
Response: RUN [cr/lf] NAME=TEST[cr/lf] PGN=1 [cr/lf] PGN=1 A=1 [cr/lf] RESET DO2 () [cr/lf] : HALT [cr/lf] [cr/lf] END [cr/lf]	

2.2 Each program

Read-out	✓
Write	✓

Format

1. <program name>
2. PGNmmm

Meaning

- Expresses a specified program.
- "mmm" represents a number from 1 to 100.
- *Program names* are shown with 32 characters or less consisting of alphanumeric characters and _ (underscore), and must be enclosed in < > (angle brackets).
- If a program name is omitted and written as <> in format 1, the current program is specified.
- In the case of write file, an error occurs if the specified program name (<program name>) differs from one on the data (NAME=program name).

Data Format

```
NAME=program name [cr/lf]
PGN=mmm
aaaaa ...aaaaaaaaaaaaa [cr/lf]
:
aaaaa ...aaaaaaaaaaaaa [cr/lf]
[cr/lf]
```

Notation	Value	Range
a	Character code	0 to 7, 10 to 17, 20 to 27
mmm	Program number	1 to 100
	<i>Program name</i>	32 characters or less consisting of alphanumeric characters and _ (underscore)

MEMO

- At program writing operations, be sure to specify the program name after NAME=.
Program writing cannot occur if the program name is not specified.
 - When there is a program number with the different program, the older one will be overwritten.
 - When there is no program number specified, the smallest free number will be specified automatically.
 - Writing into the currently selected program is not possible.
 - When a sequence program is being executed, writing into the program name "SEQUENCE" is not possible.
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample

Description

```
SEND <TEST1> TO CMU      .....Outputs program TEST1 from the communication port.
SEND CMU TO <TEST1>     .....Inputs program TEST1 from the communication port.

Response:
RUN [cr/lf]
NAME=TEST1 [cr/lf]
PGN=1 [cr/lf]
A=1 [cr/lf]
RESET DO2() [cr/lf]
:
HALT [cr/lf]
[cr/lf]
```

3.1 All points

Read-out	✓	When used as a read-out file, all points currently stored are read out.
Write	✓	When used as a write file, writing is performed with a point number.

Format

PNT

Meaning Expresses all point data.**Data Format**

```
Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbb t xr yr [cr/lf]
Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbb t xr yr [cr/lf]
:
Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbb t xr yr [cr/lf]
Pmmmm= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbb t xr yr [cr/lf]
[cr/lf]
```

**NOTE**

- Integer point data is recognized in "pulse" units, and real number point data is recognized in "mm" units.
- When a dot is included, this is treated as point data in "mm" units.
- Each piece of data is separated by one or more spaces.

Notation	Value	Range / Meaning
mmmm	Point number	0 to 29999
f	Coordinate sign	+ / - / space
xxxxx/./bbbbb	Numeric value of 8 digits or less	
t	Extended hand system flag setting for SCARA robots	1: RIGHT / 2:LEFT
xr	The first arm rotation information for YK-TW series robot	0: The "mm → pulse" converted pulse data x (*1) range -180.00° < x <= 180.00°. 1: The "mm → pulse" converted pulse data x (*1) range 180.00° < x <= 540.00°. -1: The "mm → pulse" converted pulse data x (*1) range -540.00° < x <= -180.00°.
yr	The second arm rotation information for YK-TW series robot	0: The "mm → pulse" converted pulse data x (*1) range -180.00° < y <= 180.00°. 1: The "mm → pulse" converted pulse data x (*1) range 180.00° < y <= 540.00°. -1: The "mm → pulse" converted pulse data x (*1) range -540.00° < y <= -180.00°.

*1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.

- Hand system flags are valid only for SCARA robots, with the coordinate data specified in "mm" units.
- If a number other than "1" or "2" is specified for a hand system flag, or if no number is specified, this is interpreted as "0" setting (no hand system flag).
- The first arm and the second arm rotation information settings are available only on the YK-TW series robot model where a "mm"-unit coordinate system has been set.
- The first arm and the second arm rotation information is processed as "0" if a numeral other than 0, 1, -1 has been specified, or if no numeral has been specified.

Point file

A line containing only [cr/lf] is added at the end of the file to indicate the end of the file.

Sample	Description
SEND PNT TO CMUOutputs all points from the communication port.
Response:	
RUN [cr/lf]	
P0 =	1 2 3 4 5 6 [cr/lf]
P1 =	426.200 -160.770 0.001 337.210 0.000 0.000 0 1 0 [cr/lf]
P2 =	-27.570 -377.840 0.360 193.220 0.000 0.000 0 -1 0 [cr/lf]
:	
P29999=	-251.660 -419.510 0.000 -127.790 0.000 0.000 2 -1 -1 [cr/lf]
[cr/lf]	
END [cr/lf]	

3.2 One point data

Read-out	✓
Write	✓

Format
Pmmmm

Meaning Expresses a specified point data.

Data Format
Pmmmm= fxxxxxx fyyyyyy fzzzzz frrrrr faaaaa fbbbbb t xr yr [cr/lf]



NOTE

- Integer point data is recognized in "pulse" units, and real number point data is recognized in "mm" units.
- When a dot is included, this is treated as point data in "mm" units.
- Each piece of data is separated by one or more spaces.

Notation	Value	Range / Meaning
mmmm	Point number	0 to 29999
f	Coordinate sign	+ / - / space
xxxxx/./	Numeric value of 8 digits or less	
t	Extended hand system flag setting for SCARA robots	1: RIGHT / 2:LEFT
xr	The first arm rotation information for YK-TW series robot	0: The "mm → pulse" converted pulse data x (*1) range -180.00° < x <= 180.00°. 1: The "mm → pulse" converted pulse data x (*1) range 180.00° < x <= 540.00°. -1: The "mm → pulse" converted pulse data x (*1) range -540.00° < x < = -180.00°.
yr	The second arm rotation information for YK-TW series robot	0: The "mm → pulse" converted pulse data y (*1) range -180.00° < x <= 180.00°. 1: The "mm → pulse" converted pulse data y (*1) range 180.00° < x <= 540.00°. -1: The "mm → pulse" converted pulse data y (*1) range -540.00° < x < = -180.00°.

*1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.

- Hand system flags are valid only for SCARA robots, with the coordinate data specified in "mm" units.
- If a number other than "1" or "2" is specified for a hand system flag, or if no number is specified, this is interpreted as "0" setting (no hand system flag).
- The first arm and the second arm rotation information settings are available only on the YK500TW robot model where a "mm" units coordinate system has been set.
- The first arm and the second arm rotation information is processed as "0" if a numeral other than 0, 1, -1 has been specified, or if no numeral has been specified.
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND P100 TO CMU	Outputs the specified point data from the communication port.
SEND CMU TO P100	Inputs the specified point data from the communication port.
Response:	
RUN [cr/lf]	
P100= 1.000 2.000 3.000 4.000 5.000 6.000 0 1 0 [cr/lf]	
END [cr/lf]	

4 Point comment file

4.1 All point comments

Read-out	✓	When used as a read-out file, all point comments currently stored are read out.
Write	✓	When used as a write file, writing is performed with a point comment number.

Format

PCM

Meaning Expresses all point comments.

Data Format

```
PCmmmm= sssssssssssss [cr/lf]
PCmmmm= sssssssssssss [cr/lf]
      :
PCmmmm= sssssssssssss [cr/lf]
PCmmmm= sssssssssssss [cr/lf]
[cr/lf]
```

Notation	Value	Range
mmmm	Point comment number	0 to 29999
ss...ss	Comment data	This value can be up to 16 one-byte characters. If comment data exceeds 16 characters, then the 17th character onward will be deleted.

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND PCM TO CMU SEND CMU TO PCM	Outputs all point comments from the communication port. Inputs all point comments from the communication port.
Response: RUN [cr/lf] PC1 = ORIGIN POS [cr/lf] PC3 = WAIT POS [cr/lf] : PC3999 = WORK100 [cr/lf] [cr/lf] END [cr/lf]	

4.2 One point comment

Read-out	✓
Write	✓

Format
PCmmmm

Meaning Expresses a specified point comment.

Data Format
PCmmmm= sssssssssssssss [cr/lf]

Notation	Value	Range
mmmm	Point comment number	0 to 29999
ss...ss	Comment data	This value can be up to 16 one-byte characters. If comment data exceeds 16 characters, then the 17th character onward will be deleted.

Sample	Description
SEND PC1 TO CMU	Outputs the specified point comment from the communication port.
SEND CMU TO PC1	Inputs the specified point comment from communication port.
Response:	
RUN [cr/lf]	
PC1 = ORIGIN POS [cr/lf]	
END [cr/lf]	

5.1 All point names

Read-out	✓	When used as a read-out file, all point names currently stored are read out.
Write	✓	When used as a write file, writing is performed with a point name number.

Format

PNM

Meaning

Expresses all point names.

Data Format

```
PNmmmm= assssssss [cr/lf]
PNmmmm= assssssss [cr/lf]
      :
PNmmmm= assssssss [cr/lf]
PNmmmm= assssssss [cr/lf]
[cr/lf]
```

Notation	Value	Range
mmmm	Point comment number	0 to 29999
a	Name data (the first character)	Use only one-byte alphabetic character. Otherwise, "4.202: Input format error" occurs.
ss...ss	Name data (the second character onward)	Use one-byte alphanumeric characters and _ (underscore). Otherwise, "4.202: Input format error" occurs. If name data exceeds 16 characters, then the 17th character onward will be deleted.

MEMO

Name data must not be duplicate. If name data were duplicate, delete the name data with the earlier point name number and save the name data to newly specified point name number.

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND PNM TO CMU	Outputs all point names from the communication port.
SEND CMU TO PNM	Inputs all point names from the communication port.
Response:	
RUN [cr/lf]	
PN1=ORIGIN_POS [cr/lf]	
PN3=WAIT_POS [cr/lf]	
:	
PN 3999=WORK 100 [cr/lf]	
[cr/lf]	
END [cr/lf]	

5.2 One point name

Read-out	✓
Write	✓

Format

PNmmmm

Meaning Expresses a specified point name.

Data Format

PNmmmm= aaaaaaaaaaaaaaaaaa [cr/lf]

Notation	Value	Range
mmmm	Point comment number	0 to 29999
a	Name data (the first character)	Use only one-byte alphabetic character. Otherwise, "4.202: Input format error" occurs.
ss...ss	Name data (the second character onward)	Use one-byte alphanumeric characters and _ (underscore). Otherwise, "4.202: Input format error" occurs. If name data exceeds 16 characters, then the 17th character onward will be deleted.

Sample Description

SEND PN1 TO CMU Outputs the specified point name from the communication port.
 SEND CMU TO PN1 Inputs the specified point name from the communication port.

Response:
 RUN [cr/lf]
 PN1=ORIGIN_POS [cr/lf]
 END [cr/lf]

6.1 All parameters

Read-out	✓	When used as a read-out file, all parameters currently stored are read out.
Write	✓	When used as a write file, only the parameters specified by labels are written.

Format

PRM

Meaning

Expresses all parameters.

Data Format

```

/parameter label/ [cr/lf]
RC=xxxxxxx [cr/lf]
/parameter label/ [cr/lf]
R?=xxxxxxx [cr/lf]
/parameter label/ [cr/lf]
R?A=xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx [cr/lf]
\parameter label\ [cr/lf]
C?=xxxxxxx [cr/lf]
\parameter label\ [cr/lf]
R?=xxxxxxx [cr/lf]
\parameter label\ [cr/lf]
R?A=xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx [cr/lf]
#parameter label# [cr/lf]
R?=xxxxxxx [cr/lf]
#parameter label# [cr/lf]
R?A=xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx [cr/lf]
/parameter label/ [cr/lf]
C?O=xxxxxxx,xxxxxxx,xxxxxxx,xxxxxxx [cr/lf]
:
[cr/lf]

```

Notation	Value	Remarks
RC	Entire controller	
R?	Robot setting	
?	Robot number	
C?	Controller setting	
?	Controller number	
A	Axis parameter	Each data is separated by a comma.
O	Option board parameter	Each data is separated by a comma.

- Parameter labels are shown with 8 alphabetic characters.
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

MEMO

- When writing parameter data, be sure that the servo is off.
- Parameters are already compatible with upper versions. However, parameters might not always be compatible with lower versions (upward compatibility).
- When you attempt to load a parameter file of new version into a controller of an earlier version, "10.214: Undefined parameter found" error may occur. In this case, you may load the parameter by setting the "PRM SKIP" parameter to "VALID".
- As parameters whose labels are enclosed in "\" are controller configuration parameters, take care when editing them.
- As parameters whose labels are enclosed in "#" affect robot control, take care when editing them.
- "\" symbols may be displayed as "¥" depending on the computer environment.

Sample	Description
SEND PRM TO CMU	Outputs all parameters from the communication port.
SEND CMU TO PRM	Inputs all parameters from the communication port.
Response:	
RUN [cr/lf]	
` V1.22,R0191-V1.000-V1.09,R0015/V1.09,R0015 [cr/lf]	
` Gripper,V0.32/Gripper,V0.32/// [cr/lf]	
` PRM(0) [cr/lf]	
\CNTTYP\ [cr/lf]	
C1=340 [cr/lf]	
\YCEADR\ [cr/lf]	
C1=0 [cr/lf]	
\DRVASGN\ [cr/lf]	
R1A=101,102,103,104,0,0 [cr/lf]	
R2A=0,0,0,0,0,0 [cr/lf]	
R3A=0,0,0,0,0,0 [cr/lf]	
R4A=0,0,0,0,0,0 [cr/lf]	
\RBTNUM\ [cr/lf]	
R1=2203 [cr/lf]	
:	
[cr/lf]	
END [cr/lf]	

6.2 One parameter

Read-out	✓	When used as a read-out file, only the parameter specified by a label is read out.
Write	✓	When used as a write file, only the parameter specified by a label is written.

Format

/parameter label/, \parameter label\, #parameter label#

Meaning

Parameter labels are shown with 8 alphabetic characters.

Data Format 1

```
/parameter label/ [cr/lf]
RC= xxxxxx [cr/lf]
[cr/lf]
```

Data Format 2

```
/parameter label/ [cr/lf]
R?= xxxxxx [cr/lf]
[cr/lf]
```

Data Format 3

```
/parameter label/ [cr/lf]
R?A=xxxxxxx, xxxxxx, xxxxxx, xxxxxx, xxxxxx, xxxxxx [cr/lf]
[cr/lf]
```

Data Format 4

```
\parameter label\ [cr/lf]
C?=xxxxxxx [cr/lf]
[cr/lf]
```

Data Format 5

```
\parameter label\ [cr/lf]
R?=xxxxxxx [cr/lf]
[cr/lf]
```

Data Format 6

```
\parameter label\ [cr/lf]
R?A=xxxxxxx, xxxxxx, xxxxxx, xxxxxx, xxxxxx, xxxxxx [cr/lf]
[cr/lf]
```

Data Format 7

```
#parameter label# [cr/lf]
R?=xxxxxxx [cr/lf]
[cr/lf]
```


Data Format 8

```
#parameter label# [cr/lf]
R?A=xxxxxx,xxxxxx,xxxxxx,xxxxxx,xxxxxx,xxxxxx [cr/lf]
[cr/lf]
```

Data Format 9

```
/parameter label/ [cr/lf]
C?O=xxxxxx,xxxxxx,xxxxxx,xxxxxx [cr/lf]
[cr/lf]
```

Notation	Value	Remarks
RC	Entire controller	
R?	Robot setting	
?	Robot number	
C?	Controller setting	
?	Controller number	
A	Axis parameter	Each data is separated by a comma.
O	Option board parameter	Each data is separated by a comma.

- Parameter labels are shown with 8 alphabetic characters.
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

MEMO

- When writing parameter data, be sure that the servo is off.
- Parameters are already compatible with upper versions. However, parameters might not always be compatible with lower versions (upward compatibility).
- When you attempt to load a parameter file of new version into a controller of an earlier version, "10.214: Undefined parameter found" error may occur. In this case, you may load the parameter by setting the "PRM SKIP" to "VALID". (For detail, refer to RCX3 user's manual.
- As parameters whose labels are enclosed in "\" are controller configuration parameters, take care when editing them.
- As parameters whose labels are enclosed in "#" affect robot control, take care when editing them.
- "\" symbols may be displayed as "¥" depending on the computer environment.

Sample	Description
SEND /ACCEL / TO CMU	Outputs the acceleration parameter from the communication port.
SEND CMU TO /ACCEL /	Inputs the acceleration parameter from the communication port.
Response:	
RUN [cr/lf]	
/ACCEL / [cr/lf]	
R1A=100, 100, 100, 100 [cr/lf]	
[cr/lf]	
END [cr/lf]	

7 Shift coordinate definition file

7.1 All shift coordinate data

Read-out	✓	When used as a read-out file, all shift coordinate data currently stored are read out.
Write	✓	When used as a write file, writing is performed with a shift number.

Format

SFT

Meaning Expresses all shift coordinate data.

Data Format

```
Sm = fxxxxxx fyxxxxx fzxxxxx frxxxxx [cr/lf]
SPm = fxxxxxx fyxxxxx fzxxxxx frxxxxx [cr/lf]
SMm = fxxxxxx fyxxxxx fzxxxxx frxxxxx [cr/lf]
:
Sm = fxxxxxx fyxxxxx fzxxxxx frxxxxx [cr/lf]
SPm = fxxxxxx fyxxxxx fzxxxxx frxxxxx [cr/lf]
SMm = fxxxxxx fyxxxxx fzxxxxx frxxxxx [cr/lf]
[cr/lf]
```

Notation	Value	Range
m	Shift number	0 to 39
f	Coordinate sign	+ / - / space

xxxxx/yyyyy/./rrrrr Represent a numeric value of 7 digits or less, having 3 or less places below the decimal point.

- The SPm and SMm inputs are optional in writing files.
 - SPm: shift coordinate range plus-side
 - SMm: shift coordinate range minus-side
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND SFT TO CMU	Outputs all coordinate shift data from the communication port.
SEND CMU TO SFT	Inputs all shift coordinate data from the communication port.
Response:	
RUN [cr/lf]	
S0 = 0.000 0.000 0.000 0.000 [cr/lf]	
SP0= 0.000 0.000 0.000 0.000 [cr/lf]	
SM0= 0.000 0.000 0.000 0.000 [cr/lf]	
S1 = 1.000 1.000 1.000 1.000 [cr/lf]	
:	
SM39= 9.000 9.000 9.000 9.000 [cr/lf]	
[cr/lf]	
END [cr/lf]	

7.2 One shift definition

Read-out	✓
Write	✓

Format

Sm

Meaning Expresses a specified shift definition.

Data Format

Sm = fxxxxxx fyyyyyy fzzzzzz frrrrrr[cr/lf]

Notation	Value	Range
m	Shift number	0 to 39
f	Coordinate sign	+ / - / space

xxxxx/yyyyy/./rrrrr	Represent a numeric value of 7 digits or less, having 3 or less places below the decimal point.
---------------------	---

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND S0 TO CMU	Outputs the specified shift coordinate data from the communication port.
SEND CMU TO S0	Inputs the specified shift coordinate data from the communication port.
Response:	
RUN [cr/lf]	
S0 = 0.000 0.000 0.000 0.000 [cr/lf]	
SP0= 0.000 0.000 0.000 0.000 [cr/lf]	
SM0= 0.000 0.000 0.000 0.000 [cr/lf]	
[cr/lf]	
END [cr/lf]	

8.1 All hand data

Read-out	✓	When used as a read-out file, all hand data currently stored are read out.
Write	✓	When used as a write file, writing is performed with a hand number.

Format

HND

Meaning Expresses all hand data.**Data Format**

```
Hm = n, fxxxxxx, fyyyyyy, fzzzzzz , {R} [cr/lf]
:
Hm = n, fxxxxxx, fyyyyyy, fzzzzzz , {R} [cr/lf]
[cr/lf]
```

Notation	Value	Range
m	Hand number	0 to 31
n	Robot number	1 to 4
f	Coordinate sign	+ / - / space
{R}	Whether a hand is attached to the R-axis.	
xxxxx/yyyyy/zzzzz	Represent a real numeric value of 7 digits or less, having 3 or less places below the decimal point, or an integer of 7 digits or less. (This numeric format depends on the robot type setting and hand definition type.)	

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND HND TO CMU	Outputs all hand data from the communication port.
SEND CMU TO HND	Intputs all hand data from the communication port.
Response:	
RUN [cr/lf]	
H0 = 1, 0.000, 0.000, 0.000 [cr/lf]	
H1 = 1, 1.000, 1.000, 1.000 [cr/lf]	
H2 = 2, 2.000, 2.000, 2.000 [cr/lf]	
H3 = 2, 3.000, 3.000, 3.000 [cr/lf]	
H4 = 3, 4.000, 4.000, 4.000 [cr/lf]	
H5 = 3, 5.000, 5.000, 5.000 [cr/lf]	
H6 = 4, 6.000, 6.000, 6.000 [cr/lf]	
H7 = 4, 7.000, 7.000, 7.000 [cr/lf]	
[cr/lf]	
END [cr/lf]	

8.2 One hand definition

Read-out	✓
Write	✓

Format

Hm

Meaning Expresses a specified hand definition.

Data Format

Hm = n, fxxxxxx, fyyyyyy, fzzzzzz , {R} [cr/lf]

Notation	Value	Range
m	Hand number	0 to 31
n	Robot number	1 to 4
f	Coordinate sign	+ / - / space
{R}	Whether a hand is attached to the R-axis.	
xxxxx/yyyyy/zzzzz	Represent a real numeric value of 7 digits or less, having 3 or less places below the decimal point, or an integer of 7 digits or less. (This numeric format depends on the robot type setting and hand definition type.)	

Sample	Description
--------	-------------

SEND H3 TO CMU Outputs the specified hand definition data from the communication port. SEND CMU TO H3 Inputs the specified hand definition data from communication port.	
Response: RUN [cr/lf] H3=2, 3.000, 3.000, 3.000, R [cr/lf] END [cr/lf]	

9.1 All work data

Read-out	✓	When used as a read-out file, all work data currently stored are read out.
Write	✓	When used as a write file, writing is performed with a work number.

Format
WRKDEF

Meaning Expresses all work data.

Data Format
<pre>Wm = fxxxx.xxx fyxxx.yy fzxxx.zzz frxxx.rrr [cr/lf] : Wm = fxxxx.xxx fyxxx.yy fzxxx.zzz frxxx.rrr [cr/lf] [cr/lf]</pre>

Notation	Value	Range
m	Work number	0 to 39
f	Coordinate sign	+ / - / space
xxxx.xxx/yyyy.yy zzzz.zzz/rrrr.rrr	Numeric value consisting of an integer portion of up to 4 digits and having 3 or less places below the decimal point [Unit] xxxx.xxx/yyyy.yy/zzzz.zzz: mm rrrr.rrr: degree	

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND WRKDEF TO CMU	Outputs all work data from the communication port.
SEND CMU TO WRKDEF.....	Intputs all work data from the communication port.
Response:	
RUN [cr/lf]	
W0 = 0.000, 0.000, 0.000, 0.000 [cr/lf]	
W1 = 1.000, 1.000, 1.000, 1.000 [cr/lf]	
W2 = 2.000, 2.000, 2.000, 2.000 [cr/lf]	
W3 = 3.000, 3.000, 3.000, 3.000 [cr/lf]	
W4 = 4.000, 4.000, 4.000, 4.000 [cr/lf]	
W5 = 5.000, 5.000, 5.000, 5.000 [cr/lf]	
[cr/lf]	
END [cr/lf]	

9.2 One work definition

Read-out	✓
Write	✓

Format

Wm

Meaning Expresses a specified work definition.

Data Format

Wm = fxxxx.xxx fyyyy.yyy fzzzz.zzz frrrr.rrr [cr/lf]

Notation	Value	Range
m	Work number	0 to 39
f	Coordinate sign	+ / - / space
xxxx.xxx/yyyy.yy zzzz.zzz/rrrr.rrr	Numeric value consisting of an integer portion of up to 4 digits and having 3 or less places below the decimal point [Unit] xxxx.xxx/yyyy.yy/zzzz.zzz: mm rrrr.rrr: degree	

Sample Description

SEND W3 TO CMU Outputs the specified work data from the communication port.
SEND CMU TO W3 Inputs the specified work data from communication port.

Response:
RUN [cr/lf]
W3= 3.000, 3.000, 3.000, 3.000 [cr/lf]
END [cr/lf]

10.1 All pallet definitions

Read-out	✓	When used as a read-out file, all pallet definitions currently stored are read out.
Write	✓	When used as a write file, writing is performed with a pallet number.

Format

PLT

Meaning Expresses all pallet definitions.

Data Format

```
PLm [cr/lf]
PLN = XY [cr/lf]
NX = nnn [cr/lf]
NY = nnn [cr/lf]
NZ = nnn [cr/lf]
PLP = ppppp [cr/lf]
P[1] = fxxxxx fyyyyy fzzzzz frrrrr faaaaa fbbbbb t xr yr[cr/lf]
      :
P[5] = fxxxxx fyyyyy fzzzzz frrrrr faaaaa fbbbbb t xr yr[cr/lf]
PLm [cr/lf]
      :
[cr/lf]
```

Notation	Value	Range / Meaning
m	Pallet number	0 to 39
XY	Coordinate plane setting	XY Coordinate plane
nnn	Number of points for each axis	Positive integer
ppppp	Point number for pallet definition	Continuous 5 points starting with the specified point are used.
f	Coordinate sign	+ / - / space
xxxxxx/ yyyyyy/./ bbbbbb	Numeric value of 8 digits or less (*2)	
t	Extended hand system flag setting for SCARA robots	1: RIGHT / 2:LEFT
xr	The first arm rotation information for YK-TW series robot	0: The "mm → pulse" converted pulse data x (*1) range -180.00° < x <= 180.00°. 1: The "mm → pulse" converted pulse data x (*1) range 180.00° < x <= 540.00°. -1: The "mm → pulse" converted pulse data x (*1) range -540.00° < x <= -180.00°.
yr	The second arm rotation information for YK-TW series robot	0: The "mm → pulse" converted pulse data y (*1) range -180.00° < x <= 180.00°. 1: The "mm → pulse" converted pulse data y (*1) range 180.00° < x <= 540.00°. -1: The "mm → pulse" converted pulse data y (*1) range -540.00° < x <= -180.00°.

*1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.

*2: Integers indicate point data in "pulse" units, and real numbers in "mm" units.

When a dot is included, this is treated as point data in "mm" units.

Each piece of data is separated by one or more spaces.

Pallet definition file

- Hand system flags are enabled only when specifying the coordinate data in "mm" units for SCARA robots.
- Hand system flags and the first arm and the second arm rotation information are ignored during movement where pallet definitions are used.
- If a number other than 1 or 2 is set, or if no number is designated, then 0 will be set to indicate that there is no hand system flag.
- The first arm and the second arm rotation information settings are available only on the YK-TW series robot model where a "mm" units coordinate system has been set.
- If a value other than "0", "1", "-1" is specified at the first arm and the second arm rotation information, or if no value is specified, this will be processed as "0".
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND PLT TO CMU	Outputs all pallet definitions from the communication port.
SEND CMU TO PLT	Inputs all pallet definitions from the communication port.
Response:	
RUN [cr/lf]	
PL0 [cr/lf]	
PLN=XY [cr/lf]	
NX = 3 [cr/lf]	
NY = 4 [cr/lf]	
NZ = 2 [cr/lf]	
PLP= 3996 [cr/lf]	
P[1]= 0.000 0.000 0.000 0.000 0.000 0.000 [cr/lf]	
P[2]= 100.000 0.000 0.000 0.000 0.000 0.000 [cr/lf]	
P[3]= 0.000 100.000 0.000 0.000 0.000 0.000 [cr/lf]	
P[4]= 100.000 100.000 0.000 0.000 0.000 0.000 [cr/lf]	
P[5]= 0.000 0.000 50.000 0.000 0.000 0.000 [cr/lf]	
PL1 [cr/lf]	
PLN= XY [cr/lf]	
NX = 3 [cr/lf]	
NY = 4 [cr/lf]	
NZ = 2 [cr/lf]	
PLP= 3991 [cr/lf]	
P[1]= 0.000 0.000 0.000 0.000 0.000 0.000 [cr/lf]	
P[2]= 100.000 100.000 0.000 0.000 0.000 0.000 [cr/lf]	
P[3]= 0.000 200.000 0.000 0.000 0.000 0.000 [cr/lf]	
P[4]= 100.000 200.000 0.000 0.000 0.000 0.000 [cr/lf]	
P[5]= 0.000 0.000 100.000 0.000 0.000 0.000 [cr/lf]	
[cr/lf]	
END [cr/lf]	

10.2 One pallet definition

Read-out	✓
Write	✓

Format

PLm

Meaning Expresses a specified pallet definition.

Data Format

```

PLm [cr/lf]
PLN = XY [cr/lf]
PLP = ppppp [cr/lf]
NX = nnn [cr/lf]
NY = nnn [cr/lf]
NZ = nnn [cr/lf]
P[1] = fxxxxx fyyyyy fzxxxx frrrrr faaaaa fbbbbb t xr yr[cr/lf]
      :
P[5] = fxxxxx fyyyyy fzxxxx frrrrr faaaaa fbbbbb t xr yr[cr/lf]
[cr/lf]
    
```

Notation	Value	Range / Meaning
m	Pallet number	0 to 39
XY	Coordinate plane setting	XY Coordinate plane
nnn	Number of points for each axis	Positive integer
ppppp	Point number for pallet definition	Continuous 5 points starting with the specified point are used.
f	Coordinate sign	+ / - / space
xxxxxx/ yyyyyy/./ bbbbbb	Numeric value of 8 digits or less (*2)	
t	Extended hand system flag setting for SCARA robots	1: RIGHT / 2:LEFT
xr	The first arm rotation information for YK-TW series robot	0: The "mm → pulse" converted pulse data x (*1) range -180.00° < x <= 180.00°. 1: The "mm → pulse" converted pulse data x (*1) range 180.00° < x <= 540.00°. -1: The "mm → pulse" converted pulse data x (*1) range -540.00° < x <= -180.00°.
yr	The second arm rotation information for YK-TW series robot	0: The "mm → pulse" converted pulse data y (*1) range -180.00° < x <= 180.00°. 1: The "mm → pulse" converted pulse data y (*1) range 180.00° < x <= 540.00°. -1: The "mm → pulse" converted pulse data y (*1) range -540.00° < x <= -180.00°.

*1: The joint-coordinates-converted pulse data represents each arm's distance (converted to angular data) from its mechanical origin point.

*2: Integers indicate point data in "pulse" units, and real numbers in "mm" units.

When a dot is included, this is treated as point data in "mm" units.

Each piece of data is separated by one or more spaces.

Pallet definition file

- Hand system flags are enabled only when specifying the coordinate data in "mm" units for SCARA robots.
- Hand system flags and the first arm and the second arm rotation information are ignored during movement where pallet definitions are used.
- If a number other than 1 or 2 is set, or if no number is designated, then 0 will be set to indicate that there is no hand system flag.
- The first arm and the second arm rotation information settings are available only on the YK-TW series robot model where a "mm" units coordinate system has been set.
- If a value other than "0", "1", "-1" is specified at the first arm and the second arm rotation information, or if no value is specified, this will be processed as "0".
- A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND PL2 TO CMU	Outputs the specified pallet definition from the communication port as shown below.
SEND CMU TO PL2	Inputs the specified pallet definition from the communication port as shown below.
Response:	
RUN [cr/lf]	
PL2 [cr/lf]	
PLN=XY [cr/lf]	
NX= 3 [cr/lf]	
NY= 3 [cr/lf]	
NZ= 2 [cr/lf]	
PLP= 3986 [cr/lf]	
P[1]= 100.000 100.000 50.000 90.000 0.000 0.000 [cr/lf]	
P[2]= 200.000 100.000 50.000 90.000 0.000 0.000 [cr/lf]	
P[3]= 100.000 200.000 50.000 90.000 0.000 0.000 [cr/lf]	
P[4]= 200.000 200.000 50.000 90.000 0.000 0.000 [cr/lf]	
P[5]= 100.000 10.000 100.000 90.000 0.000 0.000 [cr/lf]	
[cr/lf]	
END [cr/lf]	

Read-out	✓	When used as a read-out file, all general Ethernet port definitions are read out.
Write	✓	When used as a write file, writing is performed with a general Ethernet port number.

Format

GEP

Meaning Expresses all general Ethernet port definitions.

Data Format

```
GpM [cr/lf]
MODE=n [cr/lf]
IPADRS= aaa.aaa.aaa.aaa [cr/lf]
PORT=ppppp [cr/lf]
EOL=e [cr/lf]
TYPE=t [cr/lf]
:
TYPE=t [cr/lf]
[cr/lf]
```

Notation	Value	Range / Meaning
m	General Ethernet port number	0 to 7
n	Mode	0: Server / 1: Client
aaa	IP address	0 to 255
ppppp	Port number	0 to 65535
e	Termination character code	0: CRLF / 1: CR
t	Port type	0: TCP

MEMO

When Client mode is selected in the write file,

- IP address and port number: Set the IP address and port number of the connection destination server.

When Server mode is selected in the write file,

- IP address: IP address already set on the controller is used to communicate, so IP address setting is unnecessary.
- Port number: Set a port number which differs from the one on the controller.

General Ethernet port definition file

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND GEP TO CMU	Outputs all files of the general Ethernet port from the communication port.
SEND CMU TO GEP	Inputs all files of the general Ethernet port from the communication port.
Response:	
RUN [cr/lf]	
GP0 [cr/lf]	
MODE=1 [cr/lf]	
IPADRS=192.168.0.1 [cr/lf]	
PORT=100 [cr/lf]	
EOL=0 [cr/lf]	
TYPE=0 [cr/lf]	
GP1 [cr/lf]	
MODE=1 [cr/lf]	
IPADRS=192.168.0.100 [cr/lf]	
PORT=200 [cr/lf]	
EOL=0 [cr/lf]	
TYPE=0 [cr/lf]	
[cr/lf]	
END [cr/lf]	

12.1 All input/output name data

Read-out	✓	When used as a read-out file, all input/output data currently stored are read out.
Write	✓	When used as a write file, writing is performed with a input/output number.

Format
ION

Meaning Expresses all input/output name data.

Data Format

```
ioNMpp(b)=asssssssssssss [cr/lf]
ioNMpp(b)=asssssssssssss [cr/lf]
:
ioNMpp(b)=asssssssssssss [cr/lf]
ioNMpp(b)=asssssssssssss [cr/lf]
[cr/lf]
```

Notation	Value	Range
io	Input/output type	DI / DO / SI / SO
pp	Port number	2 to 7 / 10 to 15
b	Bit number	0 to 7
a	Name data (the first character)	Use only one-byte alphabetic character. Otherwise, "4.202: Input format error" occurs.
ss...ss	Name data (the second character onward)	Use one-byte alphanumeric characters and _ (underscore). Otherwise, "4.202: Input format error" occurs. If name data exceeds 16 characters, then the 17th character onward will be deleted.

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND ION TO CMU	Outputs all input/output name data from the communication port.
SEND CMU TO ION	Inputs all input/output name data from the communication port.
Response: RUN [cr/lf] DONM2(0)=DO_PORT2_0 [cr/lf] DONM2(1)=DO_PORT2_1 [cr/lf] : SINM15(6)=SI_PORT15_6 [cr/lf] SINM15(7)=SI_PORT15_7 [cr/lf] [cr/lf] END [cr/lf]	

MEMO

Name data must not be duplicate. When duplicate name data is saved, delete the name data with the earlier point number and save the name data to the point number which is specified as the new destination to save to.

12.2 One input/output type

Read-out	✓
Write	✓ Restricted*

Format

ioNM()

Meaning Expresses a specified input/output type.

Data Format

```
ioNMpp(b)=asoooooooooooo [cr/lf]
:
ioNMpp(b)=asoooooooooooo [cr/lf]
[cr/lf]
```

Notation	Value	Range
io	Input/output type	DI / DO / SI / SO
pp	Port number	2 to 7 / 10 to 15 *Readable input/output type and Port number DI: Up to Port14 / DO: Up to Port 10 / SI, SO: Up to Port 15
b	Bit number	0 to 7
a	Name data (the first character)	Use only one-byte alphabetic character. Otherwise, "4.202: Input format error" occurs.
ss...ss	Name data (the second character onward)	Use one-byte alphanumeric characters and _ (underscore). Otherwise, "4.202: Input format error" occurs. If name data exceeds 16 characters, then the 17th character onward will be deleted.

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
<pre>SEND DONM() TO CMU Response: RUN [cr/lf] DONM2(0)=DO_PORT2_0 [cr/lf] DONM2(1)=DO_PORT2_1 [cr/lf] : DONM10(6)=DO_PORT10_6 [cr/lf] DONM10(7)=DO_PORT10_7 [cr/lf] [cr/lf] END [cr/lf]</pre>	<p>Outputs the specified input/output name data from the communication port.</p>

12.3 One input/output port

Read-out	✓
Write	✓ Restricted*

Format

```
ioNMpp()
```

Meaning Expresses a specified input/output type and port number.

Data Format

```
ioNMpp(b)=asaaaaaaaaaaaaaa [cr/lf]
      :
ioNMpp(b)=asaaaaaaaaaaaaaa [cr/lf]
[cr/lf]
```

Notation	Value	Range
io	Input/output type	DI / DO / SI / SO
pp	Port number	2 to 7 / 10 to 15 *Readable input/output type and Port number DI: Up to Port14 / DO: Up to Port 10 / SI, SO: Up to Port 15
b	Bit number	0 to 7
a	Name data (the first character)	Use only one-byte alphabetic character. Otherwise, "4.202: Input format error" occurs.
ss...ss	Name data (the second character onward)	Use one-byte alphanumeric characters and _ (underscore). Otherwise, "4.202: Input format error" occurs. If name data exceeds 16 characters, then the 17th character onward will be deleted.

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
<pre>SEND DONM2() TO CMU Response: RUN [cr/lf] DONM2(0)=DO_PORT2_0 [cr/lf] DONM2(1)=DO_PORT2_1 [cr/lf] : DONM10(6)=DO_PORT10_6 [cr/lf] DONM10(7)=DO_PORT10_7 [cr/lf] [cr/lf] END [cr/lf]</pre>	<p>Outputs the specified input/output name data from the communication port.</p>

12.4 One input/output bit

Read-out	✓
Write	✓ Restricted*

Format

ioNMpp(b)

Meaning

Expresses a specified input/output type and bit number.

Data Format

```
ioNMpp(b)=asaaaaaaaaaaaaaa [cr/lf]
[cr/lf]
```

Notation	Value	Range
io	Input/output type	DI / DO / SI / SO
pp	Port number	2 to 7 / 10 to 15 *Readable input/output type and Port number DI: Up to Port14 / DO: Up to Port 10 / SI, SO: Up to Port 15
b	Bit number	0 to 7
a	Name data (the first character)	Use only one-byte alphabetic character. Otherwise, "4.202: Input format error" occurs.
ss...ss	Name data (the second character onward)	Use one-byte alphanumeric characters and _ (underscore). Otherwise, "4.202: Input format error" occurs. If name data exceeds 16 characters, then the 17th character onward will be deleted.

Sample

Description

SEND DONM2(0) TO CMU Outputs the specified input/output name data from the communication port.

Response:

RUN [cr/lf]

DONM2(0)=DO_PORT2_0 [cr/lf]

END [cr/lf]

13.1 All area check output data

Read-out	✓	When used as a read-out file, all area check output data currently stored are read out.
Write	✓	When used as a write file, writing is performed with an area check output number.

Format

ACO

Meaning Expresses all area check output data.

Data Format

```
ACm=r,p1,p2,t,n,l [cr/lf]
ACm=r,p1,p2,t,n,l [cr/lf]
:
ACm=r,p1,p2,t,n,l [cr/lf]
ACm=r,p1,p2,t,n,l [cr/lf]
[cr/lf]
```

Notation	Value	Range / Meaning
m	Area check output number	0 to 31
r	Robot number	0 to 4 (0: Invalid)
p1	Comparison point number 1	0 to 29999
p2	Comparison point number 2	0 to 29999
t	Port type	0: DO/SO 1: DO 2: SO 3: MO
n	Port number	20 to 277
l	Logic	0: OFF / 1: ON

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND ACO TO CMU	Outputs all area check output data from the communication port.
SEND CMU TO ACO	Inputs all area check output data from the communication port.
Response:	
RUN [cr/lf]	
AC0=1,0,1,0,20,0 [cr/lf]	
AC1=2,100,110,0,50,0 [cr/lf]	
:	
AC30=1,20,21,0,20,0 [cr/lf]	
AC31=1,50,51,0,100,0 [cr/lf]	
[cr/lf]	
END [cr/lf]	

13.2 One area check output definition

Read-out	✓	
Write	✓	When used as a write file, writing is performed with an area check output number.

Format

ACm

Meaning

Expresses a specified area check output definition.

Data Format

ACm=r,p1,p2,t,n,l [cr/lf]

Notation	Value	Range / Meaning
m	Area check output number	0 to 31
r	Robot number	0 to 4 (0: Invalid)
p1	Comparison point number 1	0 to 29999
p2	Comparison point number 2	0 to 29999
t	Port type	0: DO/SO 1: DO 2: SO 3: MO
n	Port number	20 to 277
l	Logic	0: OFF / 1: ON

Sample	Description
SEND AC0 TO CMU	Outputs specified area check output data from the communication port.
SEND CMU TO AC0	Inputs specified area check output data from the communication port.
Response:	
RUN [cr/lf]	
AC0=1,0,1,0,20,0 [cr/lf]	
END[cr/lf]	

14 Real time output file

Real time output files is supported with software Ver. 1.73 or later.

14.1 All real time output setting

Read-out	✓	When used as a read-out file, all real time output setting currently stored are read out.
Write	✓	When used as a write file, writing is performed with an real time output number.

Format

RTO

Meaning Expresses all real time output setting.

Data Format

```
RTz = n, o, p [cr/lf]
:
RTz = n, o, p [cr/lf]
[cr/lf]
```

Notation	Value	Range / Meaning
z	Port number for Real time output	24 to 127
n	Output string	
o	Option 1	Reference "14.3 Real time output setting list"
p	Option 2	

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
<pre>SEND RTO TO CMU Response: RUN [cr/lf] RT24=UCURPLS,1,1 [cr/lf] RT25=LCURPLS,1,1 [cr/lf] : RT127=LPWRONCNT [cr/lf] [cr/lf] END [cr/lf]</pre>	<p>Outputs all real time output data from the communication port.</p>

14.2 One real time output setting

Read-out	✓
Write	✓

Format
RTz

Meaning Expresses a specified real time output setting.

Data Format
RTz = n, o, p [cr/lf] [cr/lf]

Notation	Value	Range / Meaning
z	Port number for Real time output	24 to 127
n	Output string	
o	Option 1	Reference "14.3 Real time output setting list"
p	Option 2	

Sample	Description
SEND RT24 TO ETH Response: RUN [cr/lf] RT24=UCURPLS,1,1[cr/lf] [cr/lf] END [cr/lf]	Outputs the specified real time output data from the communication port.

14.3 Real time output setting list

No. (m)	Output string (n)	Output item	Unit	Data type	Option 1 (o)		Option 2 (p)	
					Target	Range	Target	Range
1	UCURPLS	Current Pulse (upper)	pulse	high order LONG	Robot	1 to 4	Axis	1 to 6
2	LCURPLS	Current Pulse (lower)	pulse	low order LONG	Robot	1 to 4	Axis	1 to 6
3	UREFPLS	Reference Pulse (upper)	pulse	high order LONG	Robot	1 to 4	Axis	1 to 6
4	LREFPLS	Reference Pulse (lower)	pulse	low order LONG	Robot	1 to 4	Axis	1 to 6
5	UCURVEL	Current Speed (upper)	pulse/10ms	high order LONG	Robot	1 to 4	Axis	1 to 6
6	LCURVEL	Current Speed (lower)	pulse/10ms	low order LONG	Robot	1 to 4	Axis	1 to 6
7	UREFVEL	Reference Speed (upper)	pulse/10ms	high order LONG	Robot	1 to 4	Axis	1 to 6
8	LREFVEL	Reference Speed (lower)	pulse/10ms	low order LONG	Robot	1 to 4	Axis	1 to 6
9	FDBCUR	Feedback Current	0.01Arms	SHORT	Robot	1 to 4	Axis	1 to 6
10	REFCUR	Reference Current	0.01Arms	SHORT	Robot	1 to 4	Axis	1 to 6
11	INPOS	Tolerance (1)	–	USHORT	Robot	1 to 4	Axis	1 to 6
12	OUTPOS	Out Valid Position (1)	–	USHORT	Robot	1 to 4	Axis	1 to 6
13	MTRDUTY	Motor Duty	%	USHORT	Robot	1 to 4	Axis	1 to 6
14	DRVDUTY	Driver Duty	%	USHORT	Robot	1 to 4	Axis	1 to 6
15	DRVMOD	Driver Mode (2)	–	USHORT	Robot	1 to 4	Axis	1 to 6
16	GRPPLS	Gripper Current Pulse	pulse	LONG	Gripper	1 to 4	–	–
17	UGRPPOS	Gripper Current Position (upper)	0.00001mm	high order LONG	Gripper	1 to 4	–	–
18	LGRPPOS	Gripper Current Position (lower)	0.00001mm	low order LONG	Gripper	1 to 4	–	–
19	GRPSTS	Gripper Status (3)	–	USHORT	Gripper	1 to 4	–	–
20	USGI	SGL (upper)	–	high order LONG	SGL	0 to 31	–	–
21	LSGI	SGL (lower)	–	low order LONG	SGL	0 to 31	–	–
22	USGR	SGR (upper)	0.001	high order LONG	SGR	0 to 31	–	–
23	LSGR	SGR (lower)	0.001	low order LONG	SGR	0 to 31	–	–
24	TEMP	Temperature	°C	USHORT	–	–	–	–
25	TASK	Taks Number	–	USHORT	–	–	–	–
26	STEP	Step Number	–	USHORT	Task	1 to 16	–	–
27	TSKSTS	Task Status (4)	–	USHORT	Task	1 to 16	–	–
28	ALRMGRP	Alarm Group	–	USHORT	–	–	–	–
29	ALRMCTG	Alarm Category	–	USHORT	–	–	–	–
30	UCCORPOS	Current Cartesian Coordinates Position (upper)	0.001mm or deg	high order LONG	Robot	1 to 4	Axis	1 to 6
31	LCCORPOS	Current Cartesian Coordinates Position (lower)	0.001mm or deg	low order LONG	Robot	1 to 4	Axis	1 to 6
32	UCCORSPD	Current Cartesian Coordinates Speed (upper)	mm/s	high order LONG	Robot	1 to 4	Axis	1 to 6
33	LCCORSPD	Current Cartesian Coordinates Speed (lower)	mm/s	low order LONG	Robot	1 to 4	Axis	1 to 6
34	UMOVDIS	Moving Distance (upper)	m or 1000 deg	high order ULONG	Robot	1 to 4	Axis	1 to 6
35	LMOVDIS	Moving Distance (lower)	m or 1000 deg	low order ULONG	Robot	1 to 4	Axis	1 to 6
36	UPWRONCNT	Power On Count (upper)	Times	high order ULONG	–	–	–	–
37	LPWRONCNT	Power On Count (lower)	Times	low order ULONG	–	–	–	–
38	UMTRONCNT	Motor Power On Count (upper)	Times	high order ULONG	–	–	–	–
39	LMTRONCNT	Motor Power On Count (lower)	Times	low order ULONG	–	–	–	–
40	USRVONCNT	Servo On Count (upper)	Times	high order ULONG	Robot	1 to 4	Axis	1 to 6
41	LSRVONCNT	Servo On Count (lower)	Times	low order ULONG	Robot	1 to 4	Axis	1 to 6
42	USRVONTIM	Servo On Time (upper)	s	high order ULONG	Robot	1 to 4	Axis	1 to 6
43	LSRVONTIM	Servo On Time (lower)	s	low order ULONG	Robot	1 to 4	Axis	1 to 6
44	UOPRTIM	Total Operating Time (upper)	s	high order ULONG	–	–	–	–
45	LOPRTIM	Total Operating Time (lower)	s	low order ULONG	–	–	–	–

Accumulated motor data (Servo ON Count, Servo ON Time, Moving Distance), accumulated controller data (Power ON Count, Motor Power ON Count, Total Operating Time) are initialized at the first boot in Ver.1.73 of RCX3 controller host CPU. Thereafter, the value is retained and accumulated even if the power is turned off. The Motor and the Controller Accumulated Data can be reset by remote commands, respectively.

Reference Field Network manual "Remote command"

The table below shows the allocation of values for each state.

(1) INPOS (Tolerance) / OUTPOS (Out Valid Position)

Output item	State of specified axis when movement command is executed	Value	
		0	1
Tolerance	Whether the axis is within the tolerance range for the target position	Out of range	Within range
OUT-Position	Whether the axis is within the tolerance range for the OUT-position		

(2) DRVMOD (Driver Mode)

Driver mode	Value (*)
Servo HOLD	0x0030
Servo OFF	0x0031
Servo FREE	0x0032
in Operation	0x0033
	0x0034
	0x0035
Return-to-Origin Operation	0x0036
Servo BRAKING	0x0037
Analysis Mode	0x0038
Speed control Mode	0x0039
Severe Alarm	0x0050
	0x0051
Magnetic pole estimation	0x0052

* Values are in hexadecimal notation.

(3) GRPSTS (Gripper Status)

Bit	Signal Name	Value	
		0	1
7	Servo Status	OFF	ON
6	Origin (Home return) Status	Uncompleted	Completed
5	Unused	–	–
4	READY signal	in Preparation	Normal
3	ZON signal	Out of range	Within range
2	HOLD signal	Open	Gripping
1	INPOS signal	Out of range	Within range
0	BUSY signal	Completed	in Operation

(4) TSKSTS (Task Status)

Task status	Value (*)
Unregistered	0x0000
RUN	0x0002
WAIT	0x0004
SUSPEND	0x0008
STOP	0x0010

* Values are in hexadecimal notation.

15.1 All file

Read-out	✓
Write	✓

Format
ALL

Meaning Expresses the minimum number of data files required to operate the robot system.



NOTE For details of each file, refer to that file's explanation.

Data Format
<pre>[PGM] All program format NAME=< program name> PGN=mmm aaaa ... aaaaaaaaa [cr/lf] : aaaa ... aaaaaaaaa [cr/lf] [cr/lf] [PNT] All point format Pmmmm=fxxxxxx fyyyyyy fzzzzzz faaaaaa fbbbbb t [cr/lf] : Pmmmm=fxxxxxx fyyyyyy fzzzzzz faaaaaa fbbbbb t [cr/lf] [cr/lf] [PCM] All point comment format PCmmmm= ssssssssssssss [cr/lf] : PCmmmm= ssssssssssssss [cr/lf] [cr/lf] [PNM] All point name format PNmmmm= assssssssssssss [cr/lf] : PNmmmm= assssssssssssss [cr/lf] [cr/lf] [PRM] All parameter format /parameter label/ [cr/lf] RC=xxxxxx [cr/lf] : #parameter label# [cr/lf] R?=xxxxxx [cr/lf] [cr/lf] [SFT] All shift format</pre>

Data Format

```

Sm= fxxxxxx fyyyyyy fzzzzzz frrrrrr [cr/lf]
:
SMm= fxxxxxx fyyyyyy fzzzzzz frrrrrr [cr/lf]
[cr/lf]

[HND] .....All hand format

Hm= n, fxxxxxx, fyyyyyy, fzzzzzz ,{R} [cr/lf]
:
Hm= n, fxxxxxx, fyyyyyy, fzzzzzz ,{R} [cr/lf]
[cr/lf]

[PLT] .....All pallet format

PLm [cr/lf]
:
P[5]= fxxxxxx fyyyyyy fzzzzzz frrrrrr faaaaaa fbbbbb t [cr/lf]
[cr/lf]

[GEP] ..... All general Ethernet port format

MODE=n [cr/lf]
:
TYPE=t [cr/lf]
[cr/lf]

[ION] ..... All input/output name format

ioNMpp(b)=asoooooooooooo [cr/lf]
:
ioNMpp(b)=asoooooooooooo [cr/lf]
[cr/lf]

[ACO] ..... All area check output format

ACm=r,p1,p2,t,n,l [cr/lf]
:
ACm=r,p1,p2,t,n,l [cr/lf]
[cr/lf]

[END] .....All file end

```

MEMO

- In readout files, only items whose data is saved in the controller is readout.
- In writing files, [xxx] determines the data file's format, and this format is saved at the controller.
Example: [HND]...All text data up the next [xxx] is saved at the controller as "all hand" format data.

Sample	Description
SEND ALL TO CMU	Outputs all files of the entire system from the communication port.
SEND CMU TO ALL	Inputs all files of the entire system from the communication port.

16.1 Entire program directory

Read-out	✓	When used as a read-out file, information on entire program directory is read out.
Write	-	This file cannot be used as a write file.

Format
DIR

Meaning Expresses entire program directory.

Data Format
nnn, yy/mm/dd, hh:mm, bbbbbbb, llll, xx, ff, ssss...ssssssss [cr/lf]
:
nnn, yy/mm/dd, hh:mm, bbbbbbb, llll, xx, ff, ssss...ssssssss [cr/lf]
[cr/lf]

Notation	Value	Range / Meaning
nnn	Program number	0 to 100
yy/mm/dd	Date of update	
hh:mm	Time of update	
bbbbbb	Byte size of program (7 digits)	
xx	File attribute	RW: Readable/writable RO: Not writable (read only) H: Hidden file
ff	Flag	m: Main program c: Current program s: Sequence program
sss...sssss	Program name	32 characters or less consisting of alphanumeric characters and _ (underscore).

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND DIR TO CMU	Outputs information on all program directory from the communication port.
Response:	
RUN [cr/lf]	
1, 15/01/10,10:14,100,24,RW,m,SAMPLE1 [cr/lf]	
2, 15/01/18,18:00,50,18,RO,,SAMPLE2 [cr/lf]	
3, 15/02/11,20:15,200,58,RW,c,SAMPLE3 [cr/lf]	
4, 15/02/11,19:03,28,15,H,,SAMPLE4 [cr/lf]	
10, 15/03/02, 20:21,592,288,RW,,SAMPLE10 [cr/lf]	
24, 15/01/18,13:19,10,3,RW,,SAMPLE24 [cr/lf]	
[cr/lf]	
END [cr/lf]	

16.2 One program directory

Read-out	✓
Write	-

Format

<<program name>>

Meaning

- Expresses information on one program.
- The program name is enclosed in << >> (double brackets).

Data Format

nnn, yy/mm/dd, hh:mm, bbbbbbb, llll, xx, ff, sssss...sssssssss [cr/lf]

Notation	Value	Range / Meaning
nnn	Program number	0 to 100
yy/mm/dd	Date of update	
hh:mm	Time of update	
bbbbbb	Byte size of program (7 digits)	
xx	File attribute	RW: Readable/writable RO: Not writable (read only) H: Hidden file
ff	Flag	m: Main program c: Current program s: Sequence program
sss...ssssss	Program name	32 characters or less consisting of alphanumeric characters and _ (underscore).

Sample	Description
SEND <<SAMPLE1>> TO CMU	Outputs information on the specified program from the communication port.
Response:	
RUN [cr/lf]	
1, 15/01/10,10:14,100,24,RW,m,SAMPLE1 [cr/lf]	
END [cr/lf]	

17.1 Entire parameter directory

Read-out	✓	When used as a read-out file, information on entire parameter directory is read out.
Write	-	This file cannot be used as a write file.

Format

DPM

Meaning Expresses entire parameter directory.

Data Format

```
\mmmmmmmm\ a m n1 n2 n3 ... n10 n11 n12 uuuuuu [cr/lf]
/mmmmmmmm/ a m n1 n2 n3 ... n10 n11 n12 uuuuuu [cr/lf]
#mmmmmmmm# a m n1 n2 n3 ... n10 n11 n12 uuuuuu [cr/lf]
[cr/lf]
```

Notation	Value	Range / Meaning
mmmmmmmm	Parameter label	8 characters or less having some symbols
a	Attribute	
m	Input method (*)	0: Direct input / 1 to 12: Selective input
n	Input range (*)	n1: Minimum value / n2: Maximum value
uuuuuu	Units	
* m: 0	n: n1 (Minimum value) / n2 (Maximum value)	
m: 1 to 12	n: Enumerate all options input at "m" (Ex) "m" and "n" when "m" is 4: 4 0 1 2 3	

MEMO

- As parameters whose labels are enclosed in "\" are controller configuration parameters, take care when editing them.
- As parameters whose labels are enclosed in "#" affect robot control, take care when editing them.
- "\" symbols may be displayed as "¥" depending on the computer environment.

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND DPM TO CMU	Outputs information on all parameter directory from the communication port.
Response:	
RUN [cr/lf]	
\PRM(0) [cr/lf]	
\CNTTYP\ 16460 0 0 2147493647 [cr/lf]	
\YCEADR\ 16396 0 0 99 [cr/lf]	
\DRVASGN\ 16398 0 0 9906 [cr/lf]	
:	
/ARMTYP/ 0 3 0 1 2 [cr/lf]	
#CPVMAX# 16 0 1 32767 mm/s [cr/lf]	
:	
/IOORGOUT/ 2052 0 0 27 [cr/lf]	
/IOSRVOUT/ 2052 0 0 27 [cr/lf]	
/GRPORGIN/ 2052 0 0 27 [cr/lf]	
[cr/lf]	
END [cr/lf]	

18.1 Machine reference (axes: sensor method, stroke-end method)

Read-out	✓
Write	-

Format

MRF

Meaning

Expresses all machine reference values of axes whose return-to-origin method is set as "Sensor" or "Stroke-end".

Data Format

```
RnA=mmm, mmm, mmm, mmm, mmm, mmm [cr/lf]
      :
RnA= mmm, mmm, mmm, mmm, mmm, mmm [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Robot number	1 to 4
mmm	Machine reference value	0 to 100

MEMO

This file reads out the machine reference values of the axes set to the robots.

Example: When the 1st through 6th axes of the robot 1 and 1st and 3rd axes of the robot 2 are connected, the data is shown as follows.

```
R1A = mmm, mmm, mmm, mmm, mmm, mmm
```

```
R2A = mmm, mmm
```

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND MRF TO CMU	Outputs all machine reference data from the communication port.
Response:	
RUN[cr/lf]	
R1A=53,47,58,25,55,59 [cr/lf]	
:	
R4A=52,58,41,38,61,50 [cr/lf]	
[cr/lf]	
END[cr/lf]	

18.2 Machine reference (axes: mark method)

Read-out	✓
Write	-

Format

ARP

Meaning Expresses all machine reference values of axes whose return-to-origin method is set as "Mark".

Data Format

RnA=mmm, mmm, mmm, mmm, mmm, mmm [cr/lf]

:

RnA= mmm, mmm, mmm, mmm, mmm, mmm [cr/lf]
[cr/lf]

Notation	Value	Range
n	Robot number	1 to 4
mmm	Machine reference value	0 to 100

MEMO

This file reads out the machine reference values of the axes set to the robots.

Example: When the 1st through 6th axes of the robot 1 and 1st and 3rd axes of the robot 2 are connected, the data is shown as follows.

R1A = mmm, mmm, mmm, mmm, mmm, mmm

R2A = mmm, mmm

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND ARP TO CMU	Outputs all machine reference data from the communication port.
Response:	
RUN[cr/lf]	
R1A=53,47,58,25,55,59 [cr/lf]	
:	
R4A=52,58,41,38,61,50 [cr/lf]	
[cr/lf]	
END[cr/lf]	

Read-out	✓ (*)
Write	-

Format
ACD

Meaning Expresses all accumulated data.

The accumulated data is the accumulated value such as the number of times the controller power is turned on, the number of times the motor servo is turned on, the distance traveled and so on since the controller was first turned on. For details, refer to "14.3 Real time output setting list" in this chapter and "Real time output" in Field Network Manual.

Data Format
/PWRONCNT/[cr/lf] RC=xxxxxxxxxxxx [cr/lf] /MPWRONCNT/[cr/lf] RC=xxxxxxxxxxxx [cr/lf] /OPTIME/[cr/lf] RC=xxxxxxxxxxxx [cr/lf] /SRVONCNT/[cr/lf] R?A=xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx [cr/lf] /SRVONTIME/[cr/lf] R?A=xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx [cr/lf] /DISTTRVLD/[cr/lf] R?A=xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx,xxxxxxxxxxxx [cr/lf] [cr/lf]

Notation	Value	Range / Meaning
RC	Entire controller	
R?	Specifying robot	
?	Robot number	1 to 4
A	All axes	
xxxxxxxxxx	Numerical value	0 ≤ xxxxxxxxxxx ≤ 4294967295

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND ACD TO CMU Outputs all accumulated data from the communication port.
Response :	
RUN [cr/lf]	
/PWRONCNT/[cr/lf] Count of times the controller power is turned on
RC=1 [cr/lf]	
/MPWRONCNT/[cr/lf] Count of times the controller motor power is turned on
RC=0 [cr/lf]	
/OPTIME/[cr/lf] Total operating time of the controller
RC=2500 [cr/lf]	
/SRVONCNT/[cr/lf] Count of times of Servo ON for all axes of Robot 1
R1A=0,0,0,0 [cr/lf]	
/SRVONTIME/[cr/lf] Total servo ON time for all axes of Robot 1
R1A=0,0,0,0 [cr/lf]	
/DISTTRVLD/[cr/lf] Total travel distance of all axes of robot 1
R1A=0,0,0,0 [cr/lf]	
[cr/lf]	
END [cr/lf]	

* While Accumulated data files is supported with software Ver. 1.73 or later, Read-out of Accumulated data files is only supported with Ver. 2.04 or later.

Read-out	✓
Write	-

Format

CFG

Meaning Expresses all system configuration information.

Data Format

```
Cm:nnnn, s, b, kkkkk, ff-ff-ff-ff-ff-ff [cr/lf]
Cm:nnnn, s, b, kkkkk, ff-ff-ff-ff-ff-ff [cr/lf]
:
Rr:aaaa, hhhhhh [cr/lf]
Rr:aaaa, hhhhhh [cr/lf]
[cr/lf]
```

Notation	Value	Range / Meaning
m	Controller number	1 onward
nnn	Controller ID number	
s	Specification	G: CE / L: Normal
b	Brake power	I: Internal / E: External
kkkkkk	Memory size	
ff	MAC address	
r	Robot number	1 to 4
aaaa	Robot ID number	
hhhhh	Connected axis number	

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND CFG TO CMU	Outputs all the system configuration file from the communication port.
Response:	
RUN [cr/lf]	
C1:340,L,I,2.1MB,00-04-C6-FF-83-12 [cr/lf]	
R1:MULTI,1234 [cr/lf]	
[cr/lf]	
END [cr/lf]	

Read-out	✓
Write	-

Format

VER

Meaning Expresses version information.

Data Format

```
Cm:cv, cr-mv-dv1, dr1/dv2, dr2 [cr/lf]
:
Cm:cv, cr-mv-dv1, dr1/dv2, dr2 [cr/lf]
[cr/lf]
```

Notation	Value	Range
m	Controller number	1 onward
cv	Host version	
cr	Host revision (Rxxxx)	
mv	PLD version (Vx.xx)	
dv?	Driver version (Vx.xx)	?: 1,2
dr?	Driver revision (Rxxx)	?: 1,2

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND VER TO CMU	Outputs all files of the version information from the communication port.
Response:	
RUN [cr/lf]	
C1:V1.22,R0191-V1.000-V1.09,R0015/V1.09,R0015	[cr/lf]
C2:V1.22,R0191-V1.000-V1.09,R0015/V1.09,R0015	[cr/lf]
C3:V1.22,R0191-V1.000-V1.09,R0015/V1.09,R0015	[cr/lf]
C4:V1.22,R0191-V1.000-V1.09,R0015/V1.09,R0015	[cr/lf]
[cr/lf]	
END [cr/lf]	

Read-out	✓
Write	-

Format

OPT

Meaning Expresses all option boards.

Data Format

```
CmOn:aaaaaa,Vb.bb [cr/lf]
CmOn:aaaaaa,Vb.bb [cr/lf]
:
CmOn:aaaaaa,Vb.bb [cr/lf]
CmOn:aaaaaa,Vb.bb [cr/lf]
[cr/lf]
```

Notation	Value	Range
m	Controller number	1 onward
n	Option board number inside the controller	Slot number: 1 to 4
aaaaaa	Option board name	
b.bb	Option board version	

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
<pre>SEND OPT TO CMU Response: RUN [cr/lf] C101:Gripper,V0.32 [cr/lf] C102:Gripper,V0.32 [cr/lf] [cr/lf] END [cr/lf]</pre>	<p>Outputs all files of the option boards from the communication port.</p>

Read-out	✓
Write	-

Format
SCK

Meaning Expresses self check file.

Data Format
gg.bbb:mmm [cr/lf]
gg.bbb:mmm [cr/lf]
:
gg.bbb:mmm [cr/lf]
gg.bbb:mmm [cr/lf]
[cr/lf]

Notation	Value	Meaning
gg	Alarm group number	
bbb	Alarm classification number	
mmm	Alarm occurrence location	RC: Entire controller R?: Robot (? : Robot number) C?: Controller (? : Controller number) A?: Axis (? : Axis number) M?: Driver (? : Driver number) R?: Option board (? : Option board number inside the controller) T?: Task (? : Task number) ETH: Ethernet CMU: RS-232C

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND SCK TO CMU	Outputs all files of the self check information from the communication port.
Response:	
RUN [cr/lf]	
12.600:C1M1 [cr/lf]	
12.600:C1M2 [cr/lf]	
12.600:C1M3 [cr/lf]	
12.600:C1M4 [cr/lf]	
[cr/lf]	
END [cr/lf]	

Read-out	✓
Write	-

Format

LOG

Meaning Expresses all alarm history.

Data Format

```

nnn:yy/mm/dd, hh:mm:ss, gg.bbb : aaaa,c, eee : ffff,
iiii, jjjjjjjj, kkkkkkkk, llllllll, ooooooooo, pppppppp,
pppppppp, pppppppp, pppppppp, pppppppp, pppppppp, q [cr/lf]
nnn:yy/mm/dd, hh:mm:ss, gg.bbb : aaaa,c, eee : ffff,
iiii, jjjjjjjj, kkkkkkkk, llllllll, ooooooooo, pppppppp,
pppppppp, pppppppp, pppppppp, pppppppp, pppppppp, q [cr/lf]
:
nnn:yy/mm/dd, hh:mm:ss, gg.bbb : aaaa,c, eee : ffff,
iiii, jjjjjjjj, kkkkkkkk, llllllll, ooooooooo, pppppppp,
pppppppp, pppppppp, pppppppp, pppppppp, pppppppp, q [cr/lf]
[cr/lf]

```

Alarm history file

Notation	Value	Range / Meaning
nnn	Alarm history number	1 to 500
yy/mm/dd	Date of alarm occurrence	
hh:mm:ss	Time of alarm occurrence	
gg	Alarm group number	
bbb	Alarm classification number	
aaaa	Alarm occurrence location	RC: Entire controller R?: Robot (? : Robot number) C?: Controller (? : Controller number) A?: Axis (? : Axis number) M?: Driver (? : Driver number) R?: Option board (? : Option board number inside the controller) T?: Task (? : Task number) ETH: Ethernet CMU: RS-232C
c	Operation mode	I: Illegal M: Manual mode A: Automatic mode (with programming box) O: Automatic mode (with other devices)
eee	Program number	
fff	Program execution line	
iiii	Point number	
jjjjjj	Parallel input	Port 0 to 3 (hexadecimal)
kkkkkkkk	Parallel output	Port 0 to 3 (hexadecimal)
lllllll	Serial input	Port 0 to 3 (hexadecimal)
oooooo	Serial output	Port 0 to 3 (hexadecimal)
pppppppp	Alarm occurrence location	A1 to A6
q	Hand system	0: NONE / 1: RIGHT / 2: LEFT

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND LOG TO CMU.....	Outputs all files of the alarm history from the communication port.
Response:	
RUN [cr/lf]	
1:15/03/30,08:23:05,1.100:RC,O,:,0,00000000,00000012,00000000,00000112,,,,,, [cr/lf]	
2:15/03/30,08:23:05,5.288: RC,O,:,0,00000000,00000010,00000000,00000110,,,,,, [cr/lf]	
:	
500:15/03/18,10:23:04,5.228:T01,O,17:3,,00000000,00000010,00000000,00000110,40119,100000,99996,39375,0,0,0 [cr/lf]	
[cr/lf]	
END [cr/lf]	

Read-out	✓
Write	-

Format

MEM

Meaning Expresses remaining memory size

Data Format

```
PGM+PNT AREA=mmmmmmm/nnnnnnnn [cr/lf]
VAR AREA=xxxxx/yyyyy [cr/lf]
[cr/lf]
```

Notation	Value
mmmmmmm	Remaining memory size of program and point area
nnnnnnn	Total memory size of program and point area
xxxxx	Remaining memory size of variable area
yyyyy	Total memory size of variable area

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND MEM TO CMU Response: RUN [cr/lf] PGM+PNT AREA=2088547 / 2100000 [cr/lf] VAR AREA=23220 / 24000 [cr/lf] [cr/lf] END [cr/lf]	Outputs all files of the remaining memory size from the communication port.

26.1 Dynamic variables

26.1.1 All dynamic variables

Read-out	✓	When used as a read-out file, all dynamic variables currently stored are read out.
Write	✓	When used as a write file, a specified dynamic variable is written.

Format
VAR

Meaning Expresses all dynamic variables.

Data Format
<pre>variable name t = xxxxxxx [cr/lf] variable name t = xxxxxxx [cr/lf] : variable name t = xxxxxxx [cr/lf] [cr/lf]</pre>

Notation	Value	Range / Meaning
<i>Variable name</i>	Global variable defined in the program	Variable name is shown with 32 characters or less consisting of alphanumeric characters and _ (underscore).
t	Type of variable	!: Real number / %: Integer / \$: Character string
xxxxxx	Value of variable	Integer type: Integer of -2147483647 to 2147483647 Real type: Real number of 7 digits or less including decimal fractions Character type: Character string of 255 characters or less

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
<pre>SEND VAR TO CMUOutputs all global variables from the communication port. SEND CMU TO VARInputs all global variables from the communication port. Response: RUN [cr/lf] A%=150 [cr/lf] B!=1.0234E1 [cr/lf] C1\$="SAMPLE1" [cr/lf] C2\$="SAMPLE2" [cr/lf] [cr/lf] END [cr/lf]C1\$="CNS_1" [cr/lf] C2\$="CNS_2" [cr/lf] [cr/lf] END [cr/lf]</pre>	

26.1.2 One dynamic variable

Read-out	✓
Write	✓

Format

`variable name t`

Meaning Expresses one dynamic variable.

Data Format

`xxxxxx [cr/lf]`

Notation	Value	Range / Meaning
<i>Variable name</i>	Global variable defined in the program	Variable name is shown with 32 characters or less consisting of alphanumeric characters and _ (underscore).
<i>t</i>	Type of variable	!: Real number / %: Integer / \$: Character string
<code>xxxxxx</code>	Value of variable	Integer type: Integer of -2147483647 to 2147483647 Real type: Real number of 7 digits or less including decimal fractions Character type: Character string of 255 characters or less

 **MEMO**

Dynamic global variables are registered during program execution.
Variables cannot be referred to unless they are registered.

Sample 1	Description
<pre>SEND A% TO CMU [cr/lf] Response: 150 [cr/lf]</pre>	Outputs the specified variable A% from the communication port.

Sample 2	Description
<pre>SEND CMU TO A% [cr/lf] Response: 300 [cr/lf] OK [cr/lf]</pre>	<p>Inputs the specified variable A% from the communication port.</p> <p>Data input to the controller.</p> <p>Result output from the controller.</p>

26.2 Static variables

26.2.1 Integer type static variables (SGI)

26.2.1.1 All integer type static variables

Read-out	✓	When used as a read-out file, all integer type static variables currently stored are read out.
Write	✓	When used as a write file, a specified integer type static variable is written.

Format

SGI

Meaning Expresses all integer static variables.

Data Format

```
SGIn=xxxxxx [cr/lf]
SGIn=xxxxxx [cr/lf]
:
SGIn=xxxxxx [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Integer type static variable number	0 to 31
xxxxxx	Integer	-2147483647 to 2147483647

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND SGI TO CMU	Outputs all integer type static variables from the communication port.
SEND CMU TO SGI	Inputs all integer type static variables from the communication port.
Response:	
RUN [cr/lf]	
SGR0=0 [cr/lf]	
SGR1=0 [cr/lf]	
:	
SGR31=0 [cr/lf]	
[cr/lf]	
END [cr/lf]	

26.2.1.2 One integer type static variables

Read-out	✓
Write	✓

Format

SGIn

Meaning Expresses a specified integer type static variable.

Data Format

xxxxxx [cr/lf]

Notation	Value	Range
n	Integer type static variable number	0 to 31
xxxxxx	Integer	-2147483647 to 2147483647

Sample	Description
SEND SGI1 TO CMU	Outputs the specified integer type static variables (SGI1) from the communication port.
SEND CMU TO SGI1	Inputs the specified integer type static variables (SGI1) from the communication port.
Response:	
RUN [cr/lf]	
0 [cr/lf]	
END [cr/lf]	

26.2.2 Real type static variables (SGR)

26.2.2.1 All real type static variables

Read-out	✓	When used as a read-out file, all real type static variables currently stored are read out.
Write	✓	When used as a write file, a specified real type static variable is written.

Format

SGR

Meaning

Expresses all real type static variables.

Data Format

```
SGRn=xxxxxxx [cr/lf]
SGRn=xxxxxxx [cr/lf]
:
SGRn=xxxxxxx [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Real type static variable number	0 to 31
xxxxxx	Real number	7 digits or less including decimal fractions

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND SGR TO CMU	Outputs all real type static variables from the communication port.
SEND CMU TO SGR	Inputs all real type static variables from the communication port.
Response:	
RUN [cr/lf]	
SGI0=0 [cr/lf]	
SGI1=0 [cr/lf]	
:	
SGI31=0 [cr/lf]	
[cr/lf]	
END [cr/lf]	

26.2.2.2 One real type static variables

Read-out	✓
Write	✓

Format

SGRn

Meaning Expresses a specified real type static variable.

Data Format

xxxxxx [cr/lf]

Notation	Value	Range
n	Real type static variable number	0 to 31
xxxxxx	Real number	7 digits or less including decimal fractions

Sample	Description
SEND SGR1 TO CMU	Outputs the specified real type static variables (SGR1) from the communication port.
SEND CMU TO SGR1	Inputs the specified real type static variables (SGR1) from the communication port.
Response:	
RUN [cr/lf]	
0 [cr/lf]	
END [cr/lf]	

27.1 One character string

Read-out	✓	When used as a read-out file, the specified character string is read out.
Write	-	This file cannot be used as a write file.

Format

"character string"

Meaning Expresses a specified character string.

Data Format

sssss...sssss [cr/lf]

Notation	Value	Range
sssss...sssss	Character string	255 characters or less

Output of " symbol (double quotation) is shown with successive " symbol.

Sample	Description
SEND ""YAMAHA ROBOT"" TO CMU	Outputs the specified character string from the communication port.
Response:	
"YAMAHA ROBOT" [cr/lf]	

28.1 All array variables

Read-out	✓	When used as a read-out file, all array variables are read out.
Write	✓	When used as a write file, a specified array variable is written.

Format

ARY

Meaning Expresses all array variables.**Data Format**

```
variable name t(l{,m{,n}}) = xxxxxxx [cr/lf]
variable name t(l{,m{,n}}) = xxxxxxx [cr/lf]
      :
variable name t(l{,m{,n}}) = xxxxxxx [cr/lf]
[cr/lf]
```

Notation	Value	Range / Meaning
<i>Variable name</i>	Global variable defined in the DIM statement	Variable name is shown with 32 characters or less consisting of alphanumeric characters and _ (underscore).
t	Type of variable	!: Real number / %: Integer / \$: Character string
l, m, n	Array arguments	
xxxxxx	Value of variable	Integer type: Integer of -2147483647 to 2147483647 Real type: Real number of 7 digits or less including decimal fractions Character type: Character string of 255 characters or less

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND ARY TO CMU SEND CMU TO ARY	Outputs all global array variables from the communication port. Inputs all global array variables from the communication port.
Response: RUN [cr/lf] A!(0)=0 [cr/lf] A!(1)=1.E2 [cr/lf] A!(2)=2.E2 [cr/lf] B%(0,0)=0 [cr/lf] B%(0,1)=1111 [cr/lf] B%(1,0)=2222 [cr/lf] B%(1,0)=3333 [cr/lf] C\$(0,0,0)= "ARY1" [cr/lf] C\$(0,0,1)= "ARY2" [cr/lf] C\$(0,1,0)= "ARY3" [cr/lf] C\$(0,1,1)= "ARY4" [cr/lf] C\$(1,0,0)= "ARY5" [cr/lf] C\$(1,0,1)= "ARY6" [cr/lf] C\$(1,1,0)= "ARY7" [cr/lf] C\$(1,1,1)= "ARY8" [cr/lf] [cr/lf] END [cr/lf]	

28.2 One array variable

Read-out	✓
Write	✓

Format

```
variable name t(l {,m {,n }})
```

Meaning Expresses one array variable.

Data Format

```
xxxxxx [cr/lf]
```

Notation	Value	Range / Meaning
<i>Variable name</i>	Global variable defined in the DIM statement	Variable name is shown with 32 characters or less consisting of alphanumeric characters and _ (underscore).
t	Type of variable	!: Real number / %: Integer / \$: Character string
l, m, n	Array arguments	
xxxxxx	Value of variable	Integer type: Integer of -2147483647 to 2147483647 Real type: Real number of 7 digits or less including decimal fractions Character type: Character string of 255 characters or less

MEMO

Array variables defined by the DIM statement are registered during compiling. Array variables cannot be referred to unless they are registered.

Sample 1	Description
SEND C1\$(2) TO CMU Response: YAMAHA ROBOT [cr/lf]	Outputs the specified array variable C1\$(2) from the communication port.
Sample 2	Description
SEND CMU TO C1\$(2) Response: OK [cr/lf]	Inputs the specified array variable C1\$(2) from the communication port.

29.1 All DI information

Read-out	✓	When used as a read-out file, all DI information is read out.
Write	-	This file cannot be used as a write file.

Format
DI ()

Meaning Expresses all DI (parallel input variable) information.

Data Format
<pre>DI0()=&Bnnnnnnnn [cr/lf] DI1()=&Bnnnnnnnn [cr/lf] : DI27()=&Bnnnnnnnn [cr/lf] [cr/lf]</pre>

Notation	Value	Range
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
<pre>SEND DI () TO CMU Outputs all DI information from the communication port. Response: DI0()=&B10001001 [cr/lf] DI1()=&B00000010 [cr/lf] DI2()=&B00000000 [cr/lf] : DI7()=&B00000000 [cr/lf] DI10()=&B00000000 [cr/lf] DI11()=&B00000000 [cr/lf] DI12()=&B00000000 [cr/lf] : DI17()=&B00000000 [cr/lf] DI20()=&B00000000 [cr/lf] : DI26()=&B00000000 [cr/lf] DI27()=&B00000000 [cr/lf] [cr/lf] END [cr/lf]</pre>	

29.2 One DI port

Read-out	✓	When used as a read-out file, the specified DI port status is read out.
Write	-	This file cannot be used as a write file.

Format

DI m ()

Meaning Expresses the status of one DI port.

Data Format

DI m () = &Bnnnnnnnn [cr/lf]

Notation	Value	Range
m	Port number	0 to 7 / 10 to 17 / 20 to 27
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ..., m0, reading from the left ("m": port No.).

Sample	Description
SEND DI5 () TO CMU Response: RUN [cr/lf] DI15 () = &B00000000 [cr/lf] END [cr/lf]	Outputs the DI5 port status from the communication port.

30.1 All DO information

Read-out	✓	When used as a read-out file, all DO information is read out.
Write	✓ Restricted*	When used as a write file, the value is written to the specified DO port. *Writing to DO0() and DO1() is prohibited.

Format

DO ()

Meaning

Expresses all DO (parallel output variable) information.

Data Format

```
DO0()=&Bnnnnnnnn [cr/lf]
DO1()=&Bnnnnnnnn [cr/lf]
:
DO27()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
<pre>SEND DO() TO CMU Response: RUN [cr/lf] DO0()=&B10001001 [cr/lf] DO1()=&B00000010 [cr/lf] DO2()=&B00000000 [cr/lf] : DO7()=&B00000000 [cr/lf] DO10()=&B00000000 [cr/lf] DO11()=&B00000000 [cr/lf] DO12()=&B00000000 [cr/lf] : DO17()=&B00000000 [cr/lf] DO20()=&B00000000 [cr/lf] : DO26()=&B00000000 [cr/lf] DO27()=&B00000000 [cr/lf] [cr/lf] END [cr/lf]</pre>	Outputs all DO information from the communication port.

30.2 One DO port

Read-out	✓	When used as a read-out file, the specified DO port status is read out.
Write	✓ Restricted*	When used as a write file, the value is written to the specified DO port. *Writing to DO0() and DO1() is prohibited.

Format

DOm ()

Meaning

Expresses the status of one DO port.

MEMO

Writing to DO0() and DO1() is prohibited. Only referencing is permitted.

Readout file

Data Format

DOm () =&Bnnnnnnnn [cr/lf]

Write file

Data Format

&Bnnnnnnnn [cr/lf] or k [cr/lf]

Notation	Value	Range
m	Port number	0 to 7 / 10 to 17 / 20 to 27
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ..., m0, reading from the left ("m": port No.).
k	Port status (Decimal counting)	Integer from 0 to 255

Sample 1	Description
SEND DO5 () TO CMU Response: RUN [cr/lf] DO5 () =&B00000000 [cr/lf] END [cr/lf]	Outputs the DO5 port status from the communication port.

Sample 2	Description
SEND CMU TO DO5 () &B00000111 Response: OK [cr/lf]	Inputs the DO5 port status from the communication port.

31.1 All MO information

Read-out	✓	When used as a read-out file, all MO information is read out.
Write	✓ Restricted*	When used as a write file, the value is written to the specified MO port. *Writing to MO30() and DO37() is prohibited.

Format

MO ()

Meaning

Expresses all MO (internal output variable) information.

Data Format

```
MO0()=&Bnnnnnnnn [cr/lf]
MO1()=&Bnnnnnnnn [cr/lf]
:
MO37()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Notation**Value****Range**

n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).
---	----------------------------------	---

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample**Description**

```
SEND MO() TO CMU ..... Outputs all MO information from the communication port.

Response:
RUN [cr/lf]
MO0()=&B10001001 [cr/lf]
MO1()=&B00000010 [cr/lf]
MO2()=&B00000000 [cr/lf]
:
MO7()=&B00000000 [cr/lf]
MO10()=&B00000000 [cr/lf]
MO11()=&B00000000 [cr/lf]
MO12()=&B00000000 [cr/lf]
:
MO17()=&B00000000 [cr/lf]
MO20()=&B00000000 [cr/lf]
:
MO27()=&B00000000 [cr/lf]
MO30()=&B00000000 [cr/lf]
:
MO36()=&B00000000 [cr/lf]
MO37()=&B00000000 [cr/lf]
[cr/lf]
END [cr/lf]
```

31.2 One MO port

Read-out	✓	When used as a read-out file, the specified MO port status is read out.
Write	✓ Restricted*	When used as a write file, the value is written to the specified MO port. *Writing to MO30() to MO37() is prohibited.

Format

MOm ()

Meaning Expresses the status of one MO port.

MEMO

Writing to MO30() to MO37() is prohibited. Only referencing is permitted.

Readout file

Data Format

MOm () =&Bnnnnnnnn [cr/lf]

Write file

Data Format

&Bnnnnnnnn [cr/lf] or k [cr/lf]

Notation	Value	Range
m	Port number	0 to 7 / 10 to 17 / 20 to 27 / 30 to 37
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ..., m0, reading from the left ("m": port No.).
k	Port status (Decimal counting)	Integer from 0 to 255

Sample 1

Description

```
SEND MO5 ( ) TO CMU ..... Outputs the MO5 port status from the communication port.
Response:
RUN [cr/lf]
MO5 ( ) =&B00000000 [cr/lf]
END [cr/lf]
```

Sample 2

Description

```
SEND CMU TO MO5 ( ) ..... Inputs the MO5 port status from the communication port.
&B00000111

Response:
OK [cr/lf]
```

32.1 All LO information

Read-out	✓	When used as a read-out file, all LO information is read out.
Write	✓	When used as a write file, the value is written to the specified LO port.

Format

LO ()

Meaning Expresses all LO (internal output variable) information.

Data Format

```
LO0()=&Bnnnnnnnn [cr/lf]
LO1()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND LO() TO CMU	Outputs all LO status from the communication port.
Response:	
RUN [cr/lf]	
LO0()=&B10001001 [cr/lf]	
LO1()=&B00100100 [cr/lf]	
[cr/lf]	
END [cr/lf]	

32.2 One LO port

Read-out	✓	When used as a read-out file, the specified LO port status is read out.
Write	✓	When used as a write file, the value is written to the specified LO port.

Format

LOm ()

Meaning Expresses the status of one LO port.

Readout file

Data Format

LOm () = &Bnnnnnnnn [cr/lf]

Write file

Data Format

&Bnnnnnnnn [cr/lf] or k [cr/lf]

Notation	Value	Range
m	Port number	0, 1
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ..., m0, reading from the left ("m": port No.).
k	Port status (Decimal counting)	Integer from 0 to 255

Sample 1	Description
SEND LO0 () TO CMU Response: RUN [cr/lf] LO0 () = &B00000000 [cr/lf] END [cr/lf]	Outputs the LO0 port status from the communication port.

Sample 2	Description
SEND CMU TO LO0 () &B00000111 Response: OK [cr/lf]	Inputs the LO0 port status from the communication port.

33.1 All TO information

Read-out	✓	When used as a read-out file, all TO information is read out.
Write	✓	When used as a write file, the value is written to the specified TO port.

Format

TO ()

Meaning Expresses all TO (timer output variable) information.

Data Format

```
TO0()=&Bnnnnnnnn [cr/lf]
TO1()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND TO() TO CMU	Outputs all TO status from the communication port.
SEND CMU TO TO()	Inputs all TO status from the communication port.
Response:	
RUN [cr/lf]	
TO0()=&B10001001 [cr/lf]	
TO1()=&B10001001 [cr/lf]	
[cr/lf]	
END [cr/lf]	

33.2 One TO port

Read-out	✓	When used as a read-out file, the specified TO port status is read out.
Write	✓	When used as a write file, the value is written to the specified TO port.

Format

TOm ()

Meaning Expresses the status of one TO port.

Readout file

Data Format

TOm () =&Bnnnnnnnn [cr/lf]

Write file

Data Format

&Bnnnnnnnn [cr/lf] or k [cr/lf]

Notation	Value	Range
m	Port number	0, 1
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).
k	Port status (Decimal counting)	Integer from 0 to 255

Sample 1	Description
SEND TO0 () TO CMU Response: RUN [cr/lf] TO0 () =&B00000000 [cr/lf] END [cr/lf]	Outputs the TO0 port status from the communication port.

Sample 2	Description
SEND CMU TO TO0 () &B00000111 Response: OK [cr/lf]	Inputs the TO0 port status from the communication port.

34.1 All SI information

Read-out	✓	When used as a read-out file, all SI information is read out.
Write	-	This file cannot be used as a write file.

Format

SI ()

Meaning Expresses all SI (serial input variable) information.

Data Format

```
SI0()=&Bnnnnnnnn [cr/lf]
SI1()=&Bnnnnnnnn [cr/lf]
:
SI27()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
<pre>SEND SI () TO CMU Response: RUN [cr/lf] SI0()=&B10001001 [cr/lf] SI1()=&B00000010 [cr/lf] SI2()=&B00000000 [cr/lf] : SI7()=&B00000000 [cr/lf] SI10()=&B00000000 [cr/lf] SI11()=&B00000000 [cr/lf] SI12()=&B00000000 [cr/lf] : SI17()=&B00000000 [cr/lf] SI20()=&B00000000 [cr/lf] : SI26()=&B00000000 [cr/lf] SI27()=&B00000000 [cr/lf] [cr/lf] END [cr/lf]</pre>	<p>Outputs all SI status from the communication port.</p>

34.2 One SI port

Read-out	✓	When used as a read-out file, the specified SI port status is read out.
Write	-	This file cannot be used as a write file.

Format

SIm()

Meaning Expresses the status of one SI port.

Data Format

SIm()=&Bnnnnnnnn[cr/lf]

Notation	Value	Range
m	Port number	0 to 7/ 10 to 17/ 20 to 27
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).

Sample	Description
SEND SI5() TO CMU Response: RUN [cr/lf] SI5()=&B00000000 [cr/lf] END [cr/lf]	Outputs the SI5 port status from the communication port.

35.1 All SO information

Read-out	✓	When used as a read-out file, all SO information is read out.
Write	✓ Restricted*	When used as a write file, the value is written to the specified SO port. *Writing to SO0() and SO1() is prohibited.

Format

SO ()

Meaning Expresses all SO (serial output variable) information.

Data Format

```
SO0()=&Bnnnnnnnn [cr/lf]
SO1()=&Bnnnnnnnn [cr/lf]
:
SO27()=&Bnnnnnnnn [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND SO () TO CMU Response: RUN [cr/lf] SO0()=&B10001001 [cr/lf] SO1()=&B00000010 [cr/lf] SO2()=&B00000000 [cr/lf] : SO7()=&B00000000 [cr/lf] SO10()=&B00000000 [cr/lf] SO11()=&B00000000 [cr/lf] SO12()=&B00000000 [cr/lf] : SO17()=&B00000000 [cr/lf] SO20()=&B00000000 [cr/lf] : SO26()=&B00000000 [cr/lf] SO27()=&B00000000 [cr/lf] [cr/lf] END [cr/lf]	Outputs all SO status from the communication port.

35.2 One SO port

Read-out	✓	When used as a read-out file, the specified SO port status is read out.
Write	✓ Restricted*	When used as a write file, the value is written to the specified SO port. *Writing to SO0() and SO1() is prohibited.

Format

SOm ()

Meaning Expresses the status of one SO port.

MEMO

Writing to SO0() and SO1() is prohibited. Only referencing is permitted.

Readout file

Data Format

SOm () =&Bnnnnnnnn [cr/lf]

Write file

Data Format

SOm () =&Bnnnnnnnn [cr/lf]

Notation	Value	Range
m	Port number	0 to 7 / 10 to 17 / 20 to 27
n	Port status (Binary counting)	"0" or "1" (total of 8 digits) Corresponds to m7, m6, ...,m0, reading from the left ("m": port No.).
k	Port status (Decimal counting)	Integer from 0 to 255

Sample 1	Description
SEND SO5 () TO CMU Response: RUN [cr/lf] SO5 () =&B00000000 [cr/lf] END [cr/lf]	Outputs the SO5 port status from the communication port.

Sample 2	Description
SEND CMU TO SO5 () &B00000111 Response: OK [cr/lf]	Inputs the SO5 port status from the communication port.

36.1 All SIW data

Read-out	✓	When used as a read-out file, all SIW information is read out in hexadecimal digit.
Write	-	This file cannot be used as a write file.

Format

SIW()

Meaning Expresses all SIW (serial word input) data.

Data Format *

```
SIW(0) =&Hnnnn [cr/lf]
SIW(1) =&Hnnnn [cr/lf]
      :
SIW(15) =&Hnnnn [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Port status (Hexadecimal counting)	0 to 9 and A to F: 4 digits (hexadecimal)

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample *	Description
SEND SIW() TO CMU	Outputs all SIW data from the communication port.
Response:	
RUN [cr/lf]	
SIW(0) =&H1001 [cr/lf]	
SIW(1) =&H0010 [cr/lf]	
SIW(2) =&H0000 [cr/lf]	
:	
SIW(15) =&H0000 [cr/lf]	
[cr/lf]	
END [cr/lf]	

* When SIOW extension is enabled, SIW(24) - SIW(127) are also read-out.
For details, refer to RCX3 user's manual "Option board related parameters".

36.2 One SIW data

Read-out	✓	When used as a read-out file, the specified SIW status is read out in hexadecimal digit.
Write	-	This file cannot be used as a write file.

Format

SIW (m)

Meaning Expresses one SIW status.

Data Format

SIW (m) = &Hnnnn [cr/lf]

Notation	Value	Range
m	Port number	2 to 15 *
n	Port status (Hexadecimal counting)	0 to 9 and A to F: 4 digits (hexadecimal)

*When SIOW extension is enabled, the range of port number is extended to 2 -15, 24 - 127.
For details, refer to RCX3 user's manual "Option board related parameters".

Sample	Description
SEND SIW(5) TO CMU Response: RUN [cr/lf] SIW(5) = &H1001 [cr/lf] END [cr/lf]	Outputs SIW(5) from the communication port.

37.1 All SOW

Read-out	✓	When used as a read-out file, all SOW information is read out in hexadecimal digit.
Write	✓ Restricted*1	When used as a write file, the value is written to the specified SOW port *1) Writing to SOW(0) and SOW(1) is prohibited.

Format

SOW ()

Meaning Expresses all SOW (serial word output) data.

Data Format *2

```
SOW(0) = &Hnnnn [cr/lf]
SOW(1) = &Hnnnn [cr/lf]
      :
SOW(15) = &Hnnnn [cr/lf]
[cr/lf]
```

Notation	Value	Range
n	Port status (Hexadecimal counting)	0 to 9 and A to F: 4 digits (hexadecimal)

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample *2	Description
SEND SOW() TO CMU Response : RUN [cr/lf] SOW(0) = &H1001 [cr/lf] SOW(1) = &H0010 [cr/lf] SOW(2) = &H0000 [cr/lf] : SOW(15) = &H0000 [cr/lf] [cr/lf] END [cr/lf]	Outputs all SOW data from the communication port.

*2) When SIOW extension is enabled, SIW(24) - SIW(127) are also read-out.
For details, refer to RCX3 user's manual "Option board related parameters".

37.2 One SOW data

Read-out	✓	When used as a read-out file, the specified SOW port status is read out in hexadecimal digit.
Write	✓ Restricted *1	When used as a write file, the value is written to the specified SOW port. *1) Writing to SOW(0) and SOW(1) is prohibited.

Format

SOW (m)

Meaning Expresses one SOW status.

Readout file

Data Format

SOW (m) = &Hnnnn [cr/lf]

Write file

Data Format

&Hnnnn

Notation	Value	Range
m	Port number	2 to 15 *2
n	Port status (Hexadecimal counting)	0 to 9 and A to F: 4 digits (hexadecimal)

*When SLOW extension is enabled, the range of port number is extended to 2 -15, 24 - 127.
For details, refer to RCX3 user's manual "Option board related parameters".

A line containing only [cr/lf] is added at the end of the file, indicating the end of the file.

Sample	Description
SEND SOW(5) TO CMU	Outputs SOW(5) from the communication port.
Response :	
RUN [cr/lf]	
SOW(5) = &H1001 [cr/lf]	
END [cr/lf]	

Read-out	✓	When used as a read-out file, ^Z (=1Ah) is read out.
Write	-	This file cannot be used as a write file.

Format

EOF

Meaning

This file is a special file consisting only of a ^Z (=1Ah) code.

When transmitting data to an external device through the communication port, the EOF data can be used to add a ^Z code at the end of file.

Data Format

^Z (=1Ah)

Sample	Description
SEND PGM TO CMU SEND EOF TO CMU	Outputs EOF data from the communication port.
NAME=TEST1 [cr/lf] A=1 [cr/lf] : HALT [cr/lf] [cr/lf] ^Z	

MEMO

A "^Z" code may be required at the end of the transmitted file, depending on the specifications of the receiving device and application.

Read-out	✓
Write	✓

Format

CMU

Meaning

- Expresses the serial communication port.
- Depends on the various data formats.

Sample

Description

Sample	Description
SEND PNT TO CMU	Outputs all point data from the communication port.
SEND CMU TO PNT	Inputs all point data from the communication port.

Read-out	✓
Write	✓

Format

ETH

Meaning

- Expresses the Ethernet port.
- Depends on the various data formats.

Sample

Description

SEND PNT TO ETH	Outputs all point data from the Ethernet port.
SEND ETH TO PNT	Inputs all point data from the Ethernet port.

Chapter 11

User program examples


1	Basic operation.....	11-1
2	Application	11-8

1.1 Directly writing point data in program

- Overview

The robot arm can be moved by PTP (point-to-point) motion by directly specifying point data in the program.

Processing flow



33C01-R7-00

Sample

MOVE P,	300.000	300.000	50.000	90.000	0.000	0.000
MOVE P,	300.000	100.000	0.000	0.000	0.000	0.000
MOVE P,	200.000	200.000	10.000	-90.000	0.000	0.000
HALT						

1.2 Using point numbers


- Overview

Coordinate data can be specified by using point numbers in a program. Coordinate data should be entered beforehand from the programming box or the support software, for example as shown below.

Reference For details, refer to RCX3 user's manual or the RCX-Studio software manual

Point Data						
P0=	0.000	0.000	0.000	0.000	0.000	0.000
P1=	100.000	0.000	150.000	30.000	0.000	0.000
P2=	0.000	100.000	50.000	0.000	0.000	0.000
P3=	300.000	300.000	0.000	0.000	0.000	0.000
P4=	300.000	100.000	100.000	90.000	0.000	0.000
P5=	200.000	200.000	0.000	0.000	0.000	0.000

Processing flow



33C02-R7-00

Sample 1

```
MOVE P, P0
MOVE P, P1
MOVE P, P2
MOVE P, P3
MOVE P, P4
MOVE P, P5
HALT
```

Sample 2

```
FOR J=0 TO 5
    MOVE P, P[J]
NEXT J
HALT
```

Although the same operation is executed by both SAMPLE 1 and SAMPLE 2, the program can be shortened by using point numbers and the FOR statement.


1.3 Using shift coordinates

- Overview

In the example shown below, after PTP movement from P3 to P5, the coordinate system is shifted +140mm along the X-axis and -100mm along the Y-axis, and the robot then moves from P3 to P5 again. The shift coordinate data is set in S1 and P3, P4, P5 are set as described in the previous section ("1.2 Using point numbers").

Shift Data				
S0=	0.000	0.000	0.000	0.000
S1=	140.000	-100.000	0.000	0.000

Shift Coordinate



33C03-R7-00

Sample	Description
SHIFT S0	Shift 0.
FOR J=3 TO 5	Repeated movement from P3 to P5.
MOVE P, P[J]	
NEXT J	
SHIFT S1	Changed to "shift 1".
FOR K=3 TO 5.....	Repeated movement occurs in the same manner from P3 to P5.
MOVE P, P[K]	
NEXT K	
HALT	

1.4 Palletizing

1.4.1 Calculating point coordinates


• Overview

Repetitive movement between a fixed work supply position P0 and each of the equally spaced points on a pallet can be performed with the following program.

In the drawing below, points N1 to N20 are on Cartesian coordinates, consisting of 5 points positioned at a 50mm pitch in the X-axis direction and 4 points at a 25mm pitch in the Y-axis direction. The robot arm moves from point to point in the order of P0-N1-P0-N2...N5-P0-N6-P0... while repeatedly moving back and forth between point P0 and each pallet.


Point Data						
Work supply position:						
P0=	0.000	0.000	0.000	0.000	0.000	0.000
X-axis pitch:						
P10=	50.000	0.000	0.000	0.000	0.000	0.000
Y-axis pitch:						
P20=	0.000	25.000	0.000	0.000	0.000	0.000
N1 position:						
P1 =	100.000	50.000	0.000	0.000	0.000	0.000

Calculating point coordinates



33C04-R7-00

Processing flow



31C05-R7-00

Sample

```
P100=P1
P200=P1
FOR J=1 TO 4
  FOR K=1 TO 5
    MOVE P,P0
    MOVE P,P100
    P100=P100+P10
  NEXT K
  P200=P200+P20
  P100=P200
NEXT J
HALT
```

7

8

9

10

11

12

13


1.4.2 Utilizing pallet movement

• Overview

Repetitive movement between a fixed work supply position P0 and each of the equally spaced points on a pallet can be performed with the following program. In the drawing below, points N1 to N24 are on Cartesian coordinates, consisting of 3 points positioned at a 50mm pitch in the X-axis direction, 4 points at a 50mm pitch in the Y-axis direction, and 2 points at 100mm pitch in the Z-axis direction. The robot arm moves from point to point in the order of P0-N1-P0-N2....-N5-P0-N6... while repeatedly moving back and forth between point P0 and each pallet.


Point Data						
Work supply position:						
P0=	0.000	0.000	200.000	0.000	0.000	0.000
Pallet definition:						
PL0						
NX=	3					
NY=	4					
NZ=	2					
PLP=3996 (P3996 to P4000 are used)						
P[1]=	100.000	50.000	200.000	0.000	0.000	0.000
P[2]=	200.000	50.000	200.000	0.000	0.000	0.000
P[3]=	100.000	200.000	200.000	0.000	0.000	0.000
P[4]=	200.000	200.000	200.000	0.000	0.000	0.000
P[5]=	100.000	50.000	100.000	0.000	0.000	0.000

Utilizing pallet movement



33C06-R9-00

Processing flow



33C07-R7-00


Sample	Description
FOR I=1 TO 24	Repeated for I = 1 to 24.
MOVE P,P0,Z=0.000	Movement of robot 1 to supply position.
PMOVE (0,I),Z=0.000	Movement of robot 1 to pallet point.
NEXT I	
MOVE P,P0,Z=0.000	
HALT	

1.5 DI/DO (digital input and output) operation

• Overview

The following example shows input/ output signal operations through the general-purpose input/ output device.

Processing flow



33C08-R7-00


Sample	Description
WAIT DI2()=0	Waits until DI20 to DI27 become "0".
DO2()=&B11111111	DO20 to DO27 become "1".
DELAY 1000	
WAIT DI2(0)=1	Waits until DI20 becomes "1".
N=1	
*LOOP1:	
IF DI2(1)=1 THEN *PROGEND	Jumps to *PROGEND if DI21 = 1.
IF N>20 THEN *ALLEND	Ended in N > 20 (jumps to *ALLEND).
DO2()=0	DO20 to DO27 become "0".
DELAY 500	
N=N+1	
GOTO *LOOP1	Loop is repeated.
'END ROUTINE	
*PROGEND:	End processing.
DO2(7,6,1,0)=&B1111	Sets DO27, 26, 21, 20 to "1".
DELAY 2000	Waits 2 seconds.
DO2()=0	Sets DO20 to "0".
*ALLEND:	
HALT	

2.1 Pick and place between 2 points

• Overview

The following is an example for picking up a part at point A and placing it at point B.

Pick and place between 2 points



33C09-R7-00

• Precondition

1. Set the robot movement path.
 - Movement path: P3→P1→P3→P4→P2→P4
 - Locate P3 and P4 respectively at a position 50mm above P1 and P2 and set the P1 and P2 positions by teaching.
2. I/O signal

DO (20)	Chuck (gripper) open/close	0: open, 1: close
---------	----------------------------	-------------------

A 0.1 second wait time is set during chuck open and close.

When calculating to find P3 and P4

Sample	Description
P3=P1	P1 coordinates are assigned to P3.
P4=P2	P2 coordinates are assigned to P4.
LOC3 (P3)=LOC3 (P3) -50.000	Axis 3 data of P3 is shifted 50mm in upper direction.
LOC3 (P4)=LOC3 (P4) -50.000	Axis 3 data of P4 is shifted 50mm in upper direction.
MOVE P, P3	
GOSUB *OPEN	
MOVE P, P1	
GOSUB *CLOSE	
MOVE P, P3	
MOVE P, P4	
MOVE P, P2	
GOSUB *OPEN	
MOVE P, P4	
HALT	
*OPEN:	Chuck OPEN routine.
DO2 (0) =0	
DELAY 100	
RETURN	
*CLOSE:	Chuck CLOSE routine.
DO2 (0) =1	
DELAY 100	
RETURN	

When using arch motion

Sample	Description
P4=P2	P2 coordinates are assigned to P4.
LOC3 (P4)=LOC3 (P4) -50.000	Axis 3 data of P4 is shifted 50mm in upper direction.
GOSUB *OPEN	
MOVE P,P1,A3=30.000	Arch motion at A3 = 30mm.
GOSUB *CLOSE	
MOVE P,P2,A3=30.000	Arch motion at A3 = 30mm.
GOSUB *OPEN	
MOVE P,P4	
HALT	
*OPEN:	Chuck OPEN routine.
DO2 (0) =0	
DELAY 100	
RETURN	
*CLOSE:	Chuck CLOSE routine.
DO2 (0) =1	
DELAY 100	
RETURN	

7

8

9

10

11

12


13

2.2 Palletizing

- Overview

The following is an example for picking up parts supplied from the parts feeder and placing them on a pallet on the conveyor. The pallet is ejected when full.

Palletizing



33C10-R7-00

- Precondition

1. I/O signal

DI (30)	Component detection sensor	1: Parts are supplied
DI (31)	Pallet sensor	1: Pallet is loaded

DO (30)	Robot hand open/close	0: Open / 1: Close
DO (31)	Pallet eject	1: Eject

Robot hand open/close time is 0.1 seconds and pallet eject time is 0.5 seconds.

2. The points below should be input beforehand as point data.

P0	Part supply position
P1	Pallet reference position
P10	X direction pitch
P11	Y direction pitch

3. Vertical movement is performed to a position Z=50mm above the pallet and parts feeder.

When point is calculated

Sample	Description
<pre> WHILE -1 All repeated (-1 is always TRUE). FOR A=0 TO 2 FOR B=0 TO 2 WAIT DI(31)=1 Wait until a pallet "present" status occurs. WAIT DI(30)=1 Wait until the supplied component "present" status occurs. DO(30)=0 Robot hand OPENS. DELAY 100 MOVE P,P0,A3=50.000 Movement of robot 1 to supply position. DO(30)=1 Robot hand CLOSES. DELAY 100 P100=P1+P10*B+P11*A Next point is calculated. MOVE P,P100,A3=50.000 ... Movement of robot 1 to calculated point. DO(30)=0 Robot hand OPENS. DELAY 100 NEXT NEXT DRIVE (3,0) Only 3 axis of robot 1 moves to 0. DO(31)=1 Pallet is ejected. DELAY 500 DO(31)=0 WEND Loop is repeated. HALT </pre>	

When using the palletizing function

Sample	Description
<pre> *Precondition: define at pallet "0" All repeated. WHILE -1 FOR A=1 TO 9 WAIT DI(31)=1 Wait until a pallet "present" status occurs. WAIT DI(30)=1 Wait until the supplied component "present" status occurs. DO(30)=0 Robot hand OPENS. DELAY 100 MOVE P,P0,A3=50.000 Movement of robot 1 to supply position. DO(30)=1 Robot hand CLOSES. DELAY 100 PMOVE(0,A),A3=50.000 Movement of robot 1 to pallet point. DO(30)=0 Robot hand OPENS. DELAY 100 NEXT DRIVE(3,0) Only 3 axis of robot 1 moves to 0. DO(31)=1 Pallet is ejected. DELAY 500 DO(31)=0 WEND Loop is repeated. HALT </pre>	

2.3 Pick and place of stacked parts


• Overview

The following is an example for picking up parts stacked in a maximum of 6 layers and 3 blocks and placing them on the conveyor.

The number of parts per block may differ from others.

Parts are detected with a sensor installed on the robot hand.

Pick and place of stacked parts



33C11-R7-00

• Precondition

1. I/O signal

DI (30)	Component detection sensor	1: Parts are supplied
DI (31)	Robot hand open/close	0: Open / 1: Close


Robot hand open/close time is 0.1 seconds.

2. The points below should be input beforehand as point data.

P1	Bottom of block 1
P2	Bottom of block 2
P3	Bottom of block 3
P5	Position on conveyor

3. Movement proceeds at maximum speeds but slows down when in proximity to the part.

Processing flow



33C12-R7-00

4. Use a STOPON condition in the MOVE statement for sensor detection during movement.

Point Data

```
FOR A=1 TO 3
  SPEED 100
  GOSUB *OPEN
  P6=P[A]
  LOC3 (P6)=0.000
  MOVE P,P6,A3=0.000
  WHILE -1
    SPEED 20
    MOVE P,P[A],STOPON DI3(0)=1
    IF DI3(0)=0 THEN *L1
    'SENSOR ON
    P4=JTOXY(WHERE)
    GOSUB *CLOSE
    SPEED 100
    MOVE P,P5,A3=0.000
    GOSUB *OPEN
    MOVE P,P4,A3=0.000
  WEND
  *L1: 'SENSOR OFF
NEXT A
SPEED 100
DRIVE (3,0)
HALT
*OPEN:
DO3(0)=0
DELAY 100
RETURN
*CLOSE:
DO3(0)=1
DELAY 100
RETURN
```

7

8

9

10

11

12

13

2.4 Parts inspection (Multi-tasking example)

• Overview


One robot is used to inspect two different parts and sort them according to the OK/NG results judged by a testing device.

The robot picks up the part at point A and moves it to the testing device at point B. The testing device checks the part and sends it to point C if OK or to point D if NG.

The part at point A' is picked up and moved to the testing device at point B' in the same way. The testing device checks the part and sends it to point C' if OK or to point D' if NG.

It is assumed that 10 to 15 seconds are required for the testing device to issue the OK/NG results.

Parts inspection (Multi-tasking example)




33C13-R7-00

• Precondition

1. I/O signal

I/O signal




33C14-R7-00

*1: As the start signal, supply a 0.1 second pulse signal to the testing device.

*2: Chuck open and close time is 0.1 seconds.

*3: Each time a test is finished, the test completion signal and OK/NG signal are sent from the testing device.

After testing, the test completion signal turns ON (=1), and the OK/ NG signal turns ON (=1) when the result is OK and turns OFF (=0) when NG.




- The main task (task 1) is used to test part 1 and the subtask (task 2) is used to test part 2.
- An exclusive control flag is used to allow other tasks to run while waiting for the test completion signal from the testing device.

FLAG1	0: Task 1 standby (Task 2 execution enabled)	1: Executing Task 1 (Task 2 execution disabled)
FLAG2	0: Task 2 standby (Task 1 execution enabled)	1: Executing Task 2 (Task 1 execution disabled)

4. Flow chart Note that Task 2 (subtask) runs in the same flow.

Processing flow



33C15-R7-00

Sample

<pre> <Maintask> FLAG1=0 FLAG2=0 UPPOS=0.000 START <SUB_PGM>,T2 Subtask Start===== *L1: WAIT DI2(2)=1 Part supply standby WAIT FLAG2=0 Other tasks waiting for standby status FLAG1=1 Exclusive control flag set GOSUB *OPEN Chuck open MOVE P,P1,Z=UPPOS Move to part supply position GOSUB *CLOSE Chuck close MOVE P,P2,Z=UPPOS Move to testing device GOSUB *OPEN Chuck open DRIVEI (3,-10000) Move axis 3 upward 10,000 pulses FLAG1=0 Exclusive control flag reset DO2(0)=1 Testing device start DELAY 100 DO2(0)=0 WAIT DI2(0)=1 Test completion standby WAIT FLAG2=0 Task completion standby FLAG1=1 Exclusive control flag set MOVE P,P2,Z=UPPOS Move to testing device GOSUB *CLOSE Chuck close IF DI2(1)=1 THEN Test 'GOOD WAIT DI4(2)=0 Part movement standby MOVE P,P3,Z=UPPOS Move to OK parts position ELSE 'NG WAIT DI2(4)=0 Part movement standby MOVE P,P4,Z=UPPOS Move to NG parts position ENDIF GOSUB *OPEN Chuck open DRIVEI (3,-10000) Move axis 3 upward 10,000 pulses FLAG1=0 Exclusive control flag reset GOTO *L1 </pre>	<pre> <Subtask> Program name:SUB_PGM *S1: WAIT DI3(2)=1 WAIT FLAG1=0 FLAG2=1 GOSUB *OPEN MOVE P,P11,Z=UPPOS GOSUB *CLOSE MOVE P,P12,Z=UPPOS GOSUB *OPEN DRIVEI (3,-10000) FLAG2=0 DO3(0)=1 DELAY 100 DO3(0)=0 WAIT DI3(0)=1 WAIT FLAG1=0 FLAG2=1 MOVE P,P12,Z=UPPOS GOSUB *CLOSE IF DI3(1)=1 THEN 'GOOD WAIT DI3(3)=0 MOVE P,P13,Z=UPPOS ELSE 'NG WAIT DI3(4)=0 MOVE P,P14,Z=UPPOS ENDIF GOSUB *OPEN DRIVEI (3,-10000) FLAG2=0 GOTO *S1 </pre>
--	---

```

<common routine>
Program name:COMMON
*OPEN:
DO2(1)=0
DELAY 100
RETURN
*CLOSE:
DO2(1)=1
DELAY 100
RETURN


```

2.5 Sealing

- Overview

The following is an example for sealing a part.

Sealing



33C11-R9-00

- Precondition

1. I/O signal

DO (20)	Valve open/close	1: Open / 0: Close
---------	------------------	--------------------

2. Positions of P0 to P7 are set by teaching.

Sample	Description
MOVE P, P0, Z=0	
SPEED 40	
PATH SETStarts setting path
PATH L, P1, DO(20)=1@10.000Starts sealing at the point of 10mm
PATH L, P2	
PATH C, P3, P4	
PATH L, P5	
PATH L, P6, S=30	
PATH L, P7, DO(20)=0@20.000Ends sealing at the point of 20mm
PATH ENDEnds setting path
PATH STARTExecutes Path motion (Robot 1 starts moving from P0 and stops at P7).
HALT	

Setting the motion path (Robot doesn't move)

2.6 Connection to an external device through RS-232C (example 1)

- **Overview**

Point data can be written in a program by using an external device connected to the controller via the RS-232C port.

- **Precondition**

1. Input to the external device from the controller

SDATA/X/Y [cr/lf]



NOTE

(cr/lf) indicates CR code (=0Dh) + LF code (=0Ah).

2. Output to the controller from the external device

Point Data							
P10=	156.420	243.910	0.000	0.000	0.000	0.000	[cr/lf]

Sample	Description
' INIT VCMD\$="SDATA/X/Y" P0=0.000 0.000 0.000 0.000 0.000 0.000.....	A request for the position to move An initial position
' MAIN ROUTINE MOVE P, P0	Moves to the initial position.
*ST: SEND VCMD\$ TO CMU SEND CMU TO P10 MOVE P, P10	Sends the command. Receives the destination point. Moves to the reception position.
GOTO *ST	

MEMO

- "SEND xxx TO CMU" outputs the contents specified by "xxx" through the RS-232C.
- "SEND CMU TO xxx" sends data into the files specified by "xxx" through the RS-232C.

2.7 Connection to an external device through RS-232C (example 2)

• Overview

Point data can be created from the desired character strings and written in a program by using an external device connected to the controller via the RS-232C port.

• Precondition

1. Input to the external device from the controller
SDATA/X/Y [cr/lf]
2. Output to the controller from the external device
X=156.420, Y=243.910 [cr/lf]



NOTE
(cr/lf) indicates CR code (=0Dh) + LF code (=0Ah).

MEMO

- "SEND xxx TO CMU" outputs the contents specified by "xxx" through the RS-232C.
- "SEND CMU TO xxx" sends data into the files specified by "xxx" through the RS-232C.
- The LEN () function obtains the length of the character string.
- The MID\$ () function obtains the specified character string from among the character strings.
- The VAL () function obtains the value from the character string.

Sample	Description
<pre>' INIT VCMD\$="SDATA/X/Y" P0= 0.000 0.000 0.000 0.000 0.000 0.000 ... P11=100.000 100.000 0.000 0.000 0.000 0.000 ... 'MAIN ROUTINE MOVE P,P0 *ST: SEND VCMD\$ TO CMU SEND CMU TO VIN\$ FOR I%=1 TO LEN(VIN\$)-2 IF MID\$(VIN\$,I%,2)="X=" THEN EXIT FOR NEXT I% LOC1(P11)=VAL(MID\$(VIN\$,I%+2)) FOR I%=1 TO LEN(VIN\$)-2 IF MID\$(VIN\$,I%,2)="Y=" THEN EXIT FOR NEXT I% LOC2(P11)=VAL(MID\$(VIN\$,I%+2)) MOVE P,P11 GOTO *ST</pre>	<p>A request for the position to move</p> <p>...An initial position</p> <p>...A reception position</p> <p>Moves to the initial position.</p> <p>Sends the command.</p> <p>Receives the Response: "X=156.420,Y=243.910".</p> <p>If "X=", then exits from the loop.</p> <p>Converts "X=" downward to the numeric value and assigns to axis 1 of P11.</p> <p>If "Y=", then exits from the loop.</p> <p>Converts "Y=" downward to numeric value and assigns to axis 2 of P11.</p> <p>Moves to the reception position.</p>

Sample

```

' INT
  VCMD$="SDATA/X/Y"
  VIN$=""
  VX$=""
  VY$=""
  P0=    0.000  0.000  0.000  0.000  0.000  0.000
  P11=   100.000100.0000.000  0.000  0.000  0.000
' MAIN ROUTINE
  MOVE P, P0
*ST:
  SEND VCMD$ TO CMU
  SEND CMU TO VIN$
  I=1
  VMAX=LEN(VIN$)
*LOOP:
  IF I>VMAX THEN GOTO *E_LOOP
  C$=MID$(VIN$, I ,1)
  IF C$="X" THEN
    I=I+2
    J=I
*X_LOOP:
    C$=MID$(VIN$, J, 1)
    IF C$="," THEN
*X1_LP:
        L=J-I
        VX$=MID$(VIN$, I, L)
        I=J+1
        GOTO *LOOP
    ENDIF
    J=J+1
    IF J>VMAX THEN GOTO *X1_LP
    GOTO *X_LOOP
  ENDIF
  IF C$="Y" THEN
    I=I+2
    J=I
*Y_LOOP:
    C$=MID$(VIN$, J, 1)
    IF C$="," THEN
*Y1_LP:
        L=J-I
        VY$=MID$(VIN$, I, L)
        I=J+1
        GOTO *LOOP
    ENDIF
    J=J+1
    IF J>VMAX THEN GOTO *Y1_LP
    GOTO *Y_LOOP
  END IF
  I=I+1
  GOTO *LOOP
*E_LOOP:
  WX=VAL(VX$)
  WY=VAL(VY$)
  LOC1(P11)=WX
  LOC2(P11)=WY
  MOVE P, P11
GOTO *ST
HALT

```

Chapter 12

Online commands

1	Online Command List.....	12-1
2	Operation and setting commands	12-5
3	Reference commands.....	12-21
4	Operation commands	12-37
5	Data file operation commands.....	12-41
6	Utility commands.....	12-51
7	Individual execution of robot language	12-53
8	Control codes	12-55

Online commands can be used to operate the controller via an RS-232C interface or via an Ethernet. This Chapter explains the online commands which can be used. For details regarding the RS-232C and Ethernet connection methods, refer to the user's manual.

1.1 About termination codes

During data transmission, the controller adds the following codes to the end of a line of transmission data.

RS-232C

- CR (0Dh) and LF (0Ah) are added to the end of the line when the "Termination code" parameter of communication parameters is set to "CRLF".
- CR (0Dh) is added to the end of the line when the "Termination code" parameter of communication parameters is set to "CR".

Ethernet

CR (0Dh) and LF (0Ah) are added to the end of the line.

When data is received, then the data up to CR (0Dh) is treated as one line regardless of the "Termination code" parameter setting, so LF (0Ah) is ignored.

The termination code is expressed as [cr/lf] in the detailed description of each online command stated in "2 Operation and setting commands" onwards in this Chapter.

1.2 Key operation

(*) Conditions: 1. Always executable.

2. Not executable during inputs from the programming box.

3. Not executable during inputs from the programming box, and while the program is running.

4. Not executable during inputs from the programming box, while the program is running, and when specific restrictions apply.

Operation type		Command	Option	Condition
	Register program in the task	LOAD	<program name> PGm (m: 1-100, n: 1-16, p: 1-64)	2 (*)
Program	Reset program Execute program Stop program	RESET RUN STOP	Tn <program name> PGm (m: 1-100, n: 1-16)	2
Program	Execute one line Skip one line Execute to next line	STEP SKIP NEXT	Tn <program name> PGm (m: 1-100, n: 1-16)	2
Program	Execute before specified line Skip before specified line	RUNTO SKIPTO	Tn <program name> PGm (m: 1-100, n: 1-16, k: 1-9999)	2
	Set break point	BREAK	<program name> PGm 0 (m: 1-100, n: 1-9999, k: 0 / 1)	2

Operation type	Command	Option	Condition
Change manual movement speed	MSPEED	[robot number] k (robot number: 1-4, k: 1-100)	2
Move to absolute reset position	ABSADJ	[robot number] k, f (robot number: 1-4, k: 1-6, f: 0/1)	3
Absolute reset	MRKSET	[robot number] k (robot number: 1-4, k: 1-6)	3
Return-to-origin	ORGRTN	[robot number] k (robot number: 1-4, k: 1-6)	3
Change inching movement amount	IDIST	[robot number] k (robot number: 1-4, k: 1-10000)	2
Manual movement (inching)	INCH INCHXY INCHT	[robot number] km (robot number: 1-4, k: 1-6, m: +/-)	3
Manual movement (jog)	JOG JOGXY JOGT	[robot number] km (robot number: 1-4, k: 1-6, m: +/-)	3
Point data teaching	TEACH TCHXY	[robot number] m (robot number: 1-4, m: 0-29999)	2

1.3 Utility

Operation type	Command	Option	Condition
Copy program	COPY	<program name1> PGm (m : 1-100) TO <program name2>	2 (*Refer to previous page)
Copy points "m - n" to point "k"		Pm-Pn TO Pk (m : 0-29999, n : 0-29999, k : 0-29999)	
Copy point comments "m - n" to point comment "k"		PCm-PCn TO PCK (m : 0-29999, n : 0-29999, k : 0-29999)	
Delete program	ERA	<program name> PGm (m : 1-100)	2
Delete points "m - n"		Pm-Pn (m : 0-29999, n : 0-29999)	
Delete point comments "m - n"		PCm-PCn (m : 0-29999, n : 0-29999)	
Delete point names "m - n"		PNm-PNn (m : 0-29999, n : 0-29999)	
Delete pallet "m"		PLm (m : 0-39)	
Delete general Ethernet port "m"		GPm (m : 0-15)	
Delete real time output "m - n"		RTm-RTn (m : 24-127, n : 24-127)	
Rename "program 1" to "program 2"		REN	
Check program syntax	SYNCHK	<program name> PGm , k (m : 1-100, k : 1-100)	2
Compile sequence program	SEQCMPL		2
Change program attribute	ATTR	<program name> PGm TO s (m : 1-100, s: RW / RO / H)	2
Setting main program	MAINPG	m (m : 1-100)	2

Operation type		Command	Option	Condition
Initialize data	Program Point Point comment Point name Shift coordinate Hand Work Pallet General Ethernet port Input/output name Area check output Real time output All data except parameters Parameter All data (MEM+PRM)	INIT	PGM PNT PCM PNM SFT HND WRKDEF PLT GEP ION ACO RTO MEM PRM ALL	3
Initialize data	Communication parameter	INIT	CMU ETH	3
Initialize data	Alarm history	INIT	LOG	3
Setting	Input data	INPUT	SET d CAN CLR (d: input data)	2
Buffer clear	Output message	MSGCLR		2
Change access level		ACCESS	k , ppppppp (k: 0/1, p: alphanumeric characters of 8 characters or less)	2
Setting	password	SETPW		2
Setting	Sequence execution flag	SEQUENCE	k (k: 0 / 1 / 3)	2
Reset alarm		ALMRST		2
Check or set date		DATE	yy / mm / dd (yy: 00-99, mm: 01-12, dd: 00-31)	2
Check or set time		TIME	hh : mm : ss (hh: 00-23, mm: 00-59, ss: 00-59)	2

1.4 Data handling

Operation type		Command	Option	Condition
Acquiring status	Access level	?	ACCESS k , ppppppp (k: 0/1, p: alphanumeric characters of 8 characters or less)	1
	Alarm status		ALM	
	Break point status		BREAK <program name> PGm (m : 1-100)	
	Last (Current) point number reference		CURPNT	
	Emergency stop status		EMG	
	Selected hand status		HAND [robot number] (robot number: 1-4)	
	Hand data		HND [hand number] (hand number: 0-31)	
	Inching movement amount status		IDIST [robot number] (robot number: 1-4)	
	Input data		INPUT	
	Online/offline status		LINEMODE ETH CMU	
	Main program number		MAINPG	
	Remaining memory capacity		MEM	
	Mode status		MODE	

Operation type	Command	Option	Condition
Motor power status		MOTOR	
Output message		MSG	
Manual movement speed		MSPEED [<i>robot number</i>] (robot number: 1-4)	
Return-to-origin status		ORIGIN [<i>robot number</i>] (robot number: 1-4)	
Work status		RBTWRK [<i>robot number</i>] (robot number: 1-4)	
Sequence program compilation status		SEQCMPSTS	
Sequence program execution status		SEQUENCE	
Servo status		SERVO [<i>robot number</i>] (robot number: 1-4)	
Selected shift status		SHIFT [<i>robot number</i>] (robot number: 1-4)	
Acquire task in RUN or SUSPEND status		TASKS	
Task end condition		TSKECD Tk (k : 1-16)	
Task operation status		TSKMON Tk (k : 1-16)	
Version information		VER	
Work data		WRKDEF [<i>work number</i>] (work number: 0-39)	
Numerical data		<i>numerical expression</i>	
Character string data		<i>character string expression</i>	
Point data		<i>point expression</i>	
Shift coordinate data		<i>shift expression</i>	
Read-out data	READ	<i>read-out file</i>	2
Write data	WRITE	<i>write file</i>	2

1.5 Robot language independent execution

The Robot languages executable independently are the commands/functions with "✓" at "Online" column in Chapter 8 "robot language table".

1.6 Control code

Operation type	Command	Option	Condition
Execution language interruption	^C(=03H)		1

- Conditions:
1. Always executable.
 2. Not executable during inputs from the programming box.
 3. Not executable during inputs from the programming box, and while the program is running.
 4. Not executable during inputs from the programming box, while the program is running, and when specific restrictions apply.

2.1 Program operations

2.1.1 Register task

Command Format		
@LOAD	<program name> PGm	,Tn, p [cr/lf]

Response Format
OK[cr/lf]

Notation	Value	Range
m	Program number	1 to 100
n	Task number	1 to 16
p	Task priority ranking	1 to 64

Meaning Registers the specified program into "task n" with "priority p".
The registered program enters the STOP status.

[When "task number n" is omitted] The task with the smallest number of those that have not been started is specified automatically.

[When "task priority p" is omitted] "32" is specified.

[Task priority ranking] The smaller value, the higher priority. The larger value, the lower priority (high 1 to low 64).
When the task with a high task priority is in the RUNNING status, the task with a low task priority still remains in the READY status.

	Sample	Description
Command	@LOAD <PG_MAIN>, T1[cr/lf]	Registers the program to task 1.
Response	OK[cr/lf]	

2.1.2 Reset program

Command Format 1

@RESET [cr/lf]

Command Format 2

@RESET	Tn <program name> PGm	[cr/lf]
--------	-----------------------------	---------

Response Format

OK [cr/lf]

Notation	Value	Range
n	Task number	1 to 16
m	Program number	1 to 100

Meaning Resets the program.

[Command Format 1] Resets all programs.

When restarting the program, the main program or the program that has been executed last in task 1 is executed from its beginning.

[Command Format 2] Resets only the specified program.

When restarting the program that has been reset, this program is executed from its beginning.

	Sample 1	Description
Command	@RESET [cr/lf]	Resets all programs.
Response	OK [cr/lf]	
	Sample 2	Description
Command	@RESET T3 [cr/lf]	Resets only the program that is executed in T3.
Response	OK [cr/lf]	

2.1.3 Program execution

Command Format 1		
@RUN [cr/lf]		
Command Format 2		
@RUN	Tn <program name> PGm	[cr/lf]
Response Format		
OK [cr/lf]		

Notation	Value	Range
n	Task number	1 to 16
m	Program number	1 to 100

- Meaning** Executes the current program.
 [Command Format 1] Executes all programs in the STOP status.
 [Command Format 2] Executes only the specified program in the STOP status.

	Sample 1	Description
Command	@RUN [cr/lf]	Executes all programs in the STOP status.
Response	OK [cr/lf]	
	Sample 2	Description
Command	@RUN T3 [cr/lf]	Executes only the program in the STOP status that is registered in T3.
Response	OK [cr/lf]	

2.1.4 Stop program

Command Format 1

@STOP [cr/lf]

Command Format 2

@STOP	Tn <program name> PGm	[cr/lf]
-------	-----------------------------	---------

Notation	Value	Range
n	Task number	1 to 16
m	Program number	1 to 100

- Meaning** Stops the program.
 [Command Format 1] Stops all programs.
 [Command Format 2] Stops only the specified program.

	Sample 1	Description
Command	@STOP [cr/lf]	Stops all programs.
Response	OK [cr/lf]	
	Sample 2	Description
Command	@STOP T3 [cr/lf]	Stops only the program that is executed in T3.
Response	OK [cr/lf]	

2.1.5 Execute one program line

Command Format		
@STEP	Tn <program name> PGm	[cr/lf]

Response Format
OK[cr/lf]

Notation	Value	Range
n	Task number	1 to 16
m	Program number	1 to 100

Meaning Executes one line of the specified program.
When executing one line of the GOSUB statement or CALL statement, the program operation enters the subroutine or sub-procedure.

	Sample	Description
Command	@STEP T3 [cr/lf]	Executes one line of the program that is executed in T3.
Response	OK [cr/lf]	

2.1.6 Execute program to the next line

Command Format		
@NEXT	Tn <program name> PGm	[cr/lf]

Response Format		
OK[cr/lf]		

Notation	Value	Range
n	Task number	1 to 16
m	Program number	1 to 100

Meaning Executes the specified program to the next line. Executing @NEXT on the line in the GOSUB or in the CALL statement make the program execute and return through the sub-procedure processing, then stop at the next line.

MEMO

This is a same processing as setting the breakpoint on the next line in the program currently suspended and executing the program (@RUN).

@STEP stops the program at the beginning line of the sub-procedure called by GOSUB or CALL statement.

	Sample	Description
Command	@NEXT T3[cr/lf].....	Executes the program in execution at T3 until the next line.
Response	OK[cr/lf]	

2.1.7 Execute program to line before specified line

Command Format		
RUNTO	Tn <program name> PGm	k[cr/lf]

Response Format		
OK[cr/lf]		

Notation	Value	Range
n	Task number	1 to 16
m	Program number	1 to 100
k	Specified line number	1 to 9999

Meaning Executes the specified program to the line before the specified line.

	Sample	Description
Command	@RUNTO T3, 15[cr/lf].....	Executes the program that is executed by T3 to the 14th line and stops at the 15th line.
Response	OK[cr/lf]	

2.1.8 Skip one program line

Command Format		
@SKIP	Tn <program name> PGm	[cr/lf]

Response Format
OK[cr/lf]

Notation	Value	Range
n	Task number	1 to 16
m	Program number	1 to 100

Meaning Skips one line of the specified program.

When skipping one line of the GOSUB statement or CALL statement, all subroutines or sub-procedures are skipped.

	Sample	Description
Command	@SKIP T3[cr/lf].....	Skips one line of the program that is executed by T3.
Response	OK[cr/lf]	

2.1.9 Skip program to line before specified line

Command Format		
@SKIPTO	Tn <program name> PGm	k[cr/lf]

Response Format
OK[cr/lf]

Notation	Value	Range
n	Task number	1 to 16
m	Program number	1 to 100
k	Specified line number	1 to 9999

Meaning Skips the specified program to the line before the specified line.

	Sample	Description
Command	@SKIPTO T3, 15[cr/lf].....	Skips the program that is executed by T3 to the 14th line and stops at the 15th line.
Response	OK[cr/lf]	

2.1.10 Set break point

Command Format 1

@BREAK	<program name> PGm	(n,n,n,...), k[cr/lf]
--------	-----------------------	-----------------------

Command Format 2

@BREAK	<program name> PGm	0[cr/lf]
--------	-----------------------	----------

Command Format 3

@BREAK 0[cr/lf]

Response Format

OK[cr/lf]

Notation	Value	Range / Meaning
m	Program number	1 to 100
n	Specified line number	1 to 9999
k	Set/Cancel	0: Set / 1: Cancel

Meaning Sets a break point to pause the program during program execution.

[Command Format 1] Sets or cancels a break point in the specified line of the specified program.

Multiple lines can also be specified.

[Command Format 2] Cancels all break points set in the specified program.

[Command Format 3] Cancels all break points.

	Sample	Description
Command	@BREAK PG3 (1, 3), 1[cr/lf].....	Sets a break point at the first and third lines of PG3.
Response	OK[cr/lf]	

2.1.11 Check program syntax

Command Format		
@SYNCHK	<program name> PGm	,k[cr/lf]

Response Format
<pre> RUN [cr/lf] nnnn:gg.bbb [cr/lf] nnnn:gg.bbb [cr/lf] : nnnn:gg.bbb [cr/lf] nnnn:gg.bbb [cr/lf] END [cr/lf] </pre>

Notation	Value	Range
m	Program number	1 to 100
k	Maximum number of error	1 to 100
nnnn	Line number where error occurred	1 to 9999
gg	Alarm group number	
bbb	Alarm classification number	

Meaning Checks syntax of the program specified by <program name> or program number. If there are syntax errors in the specified program, line number where error occurred, alarm group number and alarm classification number are output.

Reference For details regarding alarm group number and alarm classification number, refer to RCX3 user's manual.

	Sample	Description
Command	@SYNCHK PG1, 100 [cr/lf]	Sets a Maximum number of error at 100 and checks syntax of the program 1.
Response	<pre> RUN [cr/lf] 1:5.239 [cr/lf] 2:5.239 [cr/lf] 3:5.239 [cr/lf] 8:5.239 [cr/lf] 6:5.222 [cr/lf] END [cr/lf] </pre>	<p>Detects syntax errors "5.239: Illegal identifier" at 1th, 2nd, 3rd and 8th lines.</p> <p>Detects syntax error "5.222:IF without ENDIF" at 6th line.</p>

2.1.12 Set main program

Command Format

@MAINPG [cr/lf]

Response Format

OK [cr/lf]

Notation	Value	Range
m	Program number	1 to 100

Meaning Specifies the program which is always selected when all programs are reset. When "0" is specified at the main program number or program specified at the main program number doesn't exist, the program that has been executed last (current program) in the task 1 is selected after resetting all programs.



NOTE "Main program" corresponds conventional function "_SELECT" of RCX240, etc.

	Sample	Description
Command	@MAINPG 1 [cr/lf].....	Sets program number 1 at the main program.
Response	OK [cr/lf]	

2.1.13 Compile sequence program

Command Format

@EQCMPL [cr/lf]

Response Format

RUN [cr/lf]
END [cr/lf]

Meaning Compiles the sequence program.
When the program named "SEQUENCE" doesn't exist or syntax errors exist in the program, an error message appears.
The execution program is created after successful termination of compiling and the letter "s" appears in Flag.

Reference Chapter 7 "Sequence function"

	Sample	Description
Command	@SEQCMPL [cr/lf].....	Compiles the sequence program.
Response	RUN [cr/lf] END [cr/lf]	

2.2 MANUAL mode operation

2.2.1 Change the MANUAL mode speed

Command Format

```
@MSPEED [robot number] k[cr/lf]
```

Response Format

```
OK[cr/lf]
```

Notation	Value	Range
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
k	Manual movement speed	1 to 100

Meaning Changes the manual mode movement speed of the robot specified by the <*robot number*>.

Sample	
Command	@MAINPG 50[cr/lf]
Response	OK[cr/lf]

2.2.2 Point data teaching

Command Format

```
@TEACH [robot number] mmmm[cr/lf]
```

```
@TCHXY [robot number] mmmm[cr/lf]
```

Response Format

```
OK[cr/lf]
```

Notation	Value	Range
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
mmm	Point number for registering point data	0 to 29999

Meaning Registers the current robot position as point data for the specified point number. If point data is already registered in the specified point number, then that point data will be overwritten.

The unit of the point data may vary depending on the command.

TEACH "pulse" units
TCHXY "mm" units

Sample	
Command	@TEACH[2] 100[cr/lf]
Response	OK[cr/lf]

2.2.3 Change inching movement amount

Command Format

@IDIST [*robot number*] mmmmm[cr/lf]

Response Format

OK[cr/lf]

Notation	Value	Range
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
mmmmm	Inching movement amount	1 to 10000

Meaning Changes the inching movement amount of the robot specified by the *<robot number>*.

The unit of the movement amount may vary depending on the command.

INCH "pulse" units: 1 to 10000 pulse
INCHXY "mm" units: 0.001 to 10.000mm
INCHXT "mm" units: 0.001 to 10.000mm

Sample	
Command	@IDIST[2] 100[cr/lf]
Response	OK[cr/lf]

2.3 Alarm reset

Command Format

```
@ALMRST [cr/lf]
```

Response Format

```
RUN [cr/lf]  
END [cr/lf]
```

Meaning Resets the alarm.

However, this command cannot be used for the alarms which require the restart of system.
In this case, turn off the controller and turn it on again.

Sample	
Command	@ALMRST [cr/lf]
Response	RUN [cr/lf] OK [cr/lf]

2.4 Clearing output message buffer

Command Format

```
@MSGCLR [cr/lf]
```

Response Format

```
OK [cr/lf]
```

Values Clears the output message buffer of the controller. After the messages have been output by the PRINT statement, etc., the messages remaining in the buffer are cleared.

Sample	
Command	@MSGCLR [cr/lf]
Response	OK [cr/lf]

2.5 Setting input data

Command Format

@INPUT	SET d CAN CLR	[cr/lf]
--------	---------------------	---------

Response Format

OK[cr/lf]

Notation	Value	Meaning
d	Input data	Value that is matched to the type of the variable specified by the INPUT statement. (Character string is enclosed by " ")

Meaning Sets the input data for responding to a data request by INPUT statement of robot program. The controller parameter "INPUT/PRINT using channel" should be set a current communication channel (CMU, ETH or iVY).

SET: Sets the data which is input to the variable when INPUT statement is executed.

CAN: Cancels the data request by INPUT statement.

CLR: Clears the data specified @INPUT SET downward.

Sample	Description
<pre><Online command> @INPUT SET 10[cr/lf] @INPUT SET 5[cr/lf] OK[cr/lf] @?MSG[cr/lf] 10[cr/lf] OK[cr/lf]</pre>	<pre><Robot program> INPUT A%[cr/lf] PRINT A%[cr/lf]</pre>
<pre><Online command> @INPUT SET 10[cr/lf] OK[cr/lf] @INPUT CLR[cr/lf] OK[cr/lf] @INPUT SET 5[cr/lf] OK[cr/lf] @?MSG[cr/lf] 5[cr/lf] OK[cr/lf]</pre>	<pre><Robot program> INPUT A%[cr/lf] PRINT A%[cr/lf]</pre>

2.6 Changing access level

Command Format

```
@ACCESS k , pppppppp [cr/lf]
```

Response Format

```
OK[cr/lf]
```

Notation	Value	Range / Meaning
k	Access level	0: Maintainer level, 1: Operator level
pppppppp	Password	Alphanumeric characters of 8 characters or less

Meaning

Changes access level. If password is omitted, sets without password.

When changes access level to the maintainer level and entered password is incorrect, "6.235: Password error" will occur.

Reference

RCX3 user's manual

	Sample	Description
Command	@ACCESS 0,password[cr/lf].....	Sets "password" as password, and changes the level to "maintainer level".
Response	OK[cr/lf]	

2.7 Changing password

Command Format

```
@SETPW[cr/lf]
```

Response Format

```
READY [cr/lf]
pppppppp [cr/lf]
kkkkkkkk [cr/lf]
nnnnnnnn [cr/lf]
[cr/lf] ..... line-feed
OK[cr/lf]
```

Notation	Value	Range
pppppppp	old password (current password)	Alphanumeric characters of 8 characters or less
kkkkkkkk	new password	Alphanumeric characters of 8 characters or less
nnnnnnnn	new password (confirmation)	Alphanumeric characters of 8 characters or less

Meaning

Changes the password for the access level changing to the maintainer level.

- The current password is input for the old password, and the revised password is input for the new password and for the new password of confirmation.

In the next line of the new password (confirmation), inserts line feeds only.

- When input password as the old password is different from the current password or new password and new password (confirmation) are not same, "6.235: Password error" will occur.

Reference

RCX3 user's manual

	Sample	Description
Command	@SETPW[cr/lf]	
Response	READY [cr/lf] oldpass[cr/lf] newpass[cr/lf] newpass[cr/lf] [cr/lf] ok [cr/lf]	Inputs "oldpass" as old password. Inputs "newpass" as new password. Inputs "newpass" as new password (confirmation). line-feed

3.1 Acquiring return-to-origin status

Command Format 1

```
@?ORIGIN [cr/lf]
```

Response Format 1

```
x [cr/lf]
OK [cr/lf]
```

Command Format 2

```
@?ORIGIN robot number [cr/lf]
```

Response Format 2

```
x y{,y{,{...}}}[cr/lf]
OK [cr/lf]
```

Notation	Value	Range / Meaning
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
x	Robot return-to-origin status	0: Incomplete, 1: Complete
y	Axis return-to-origin status	Shows the status of the axis 1, axis 2, ..., axis 6 from the left. 0: Incomplete, 1: Complete (Omitted when the axis is not connected.)

Meaning Acquires return-to-origin status.

[Command Format 1] Acquires the return-to-origin status of all robots.

[Command Format 2] Acquires the status of the specified robot.

	Sample	Description
Command	@?ORIGIN 2 [cr/lf]	
Response	0 1,1,0,1 [cr/lf] OK [cr/lf]	Axis 3 of the robot 2 is in the return-to-origin incomplete status.

3.2 Acquiring servo status

Command Format

```
@?SERVO [robot number] [cr/lf]
```

Response Format

```
x y,y,y,y,y,y [cr/lf]
OK [cr/lf]
```

Notation	Value	Range / Meaning
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
x	Robot servo status	0: Servo off status, 1: Servo on status Shows the status of the axis 1, axis 2, ..., axis 6 from the left.
y	Axis servo status	0: Mechanical brake on + dynamic brake on status 1: Servo on status 2: Mechanical brake off + dynamic brake off status (Omitted when the axis is not connected.)

Meaning Acquires the servo status.

	Sample	Description
Command	@?SERVO[3] [cr/lf]	
Response	0 0,1,0,0 [cr/lf] OK [cr/lf]	Only the axis 2 of robot 3 is in the servo on status.

3.3 Acquire motor power status

Command Format

```
@?MOTOR [cr/lf]
```

Response Format

```
x [cr/lf]
OK [cr/lf]
```

Notation	Value	Range / Meaning
x	Motor power status	0: Motor power off status 1: Motor power on status 2: Motor power on + all robot servo on status

Meaning Acquires the motor power status.

	Sample	Description
Command	@?MOTOR [cr/lf]	
Response	2 [cr/lf] OK [cr/lf]	

3.4 Acquiring access level

Command Format 1
@?ACCESS [cr/lf]
Response Format 1
k [cr/lf] OK [cr/lf]

Notation	Value	Range / Meaning
k	Access level	0: Maintainer level, 1: Operator level

Meaning Acquires the access level.

Reference RCX3 user's manual

Sample	
Command	@?ACCESS [cr/lf]
Response	1 [cr/lf] OK [cr/lf]

3.5 Acquiring break point status

Command Format		
@?BREAK	<program name> PGm	[cr/lf]
Response Format		
n{n{n{...}}}[cr/lf] OK [cr/lf]		

Notation	Value	Range
n	Line number on which break point "n" is set	1 to 9999
<i>Program name</i>	Program name to delete	32 characters or less consisting of alphanumeric characters and _ (underscore).
m	Program number	1 to 100

Meaning Acquires the break point status.

Sample	
Command	@?BREAK <TEST> [cr/lf]
Response	12,35 [cr/lf] OK [cr/lf]

3.6 Acquiring mode status

Command Format

@?MODE [cr/lf]

Response Format

k [cr/lf]
OK [cr/lf]

Notation	Value	Range / Meaning
----------	-------	-----------------

k	Mode status	0: MANUAL mode 1: AUTO mode (Control source: Programming box) 2: AUTO mode (Control source release) -1: Restricted mode
---	-------------	--

Meaning Acquires the controller mode status.

	Sample
Command	@?MODE [cr/lf]
Response	1 [cr/lf] OK [cr/lf]

3.7 Acquiring communication port status

Command Format

@?LINEMODE	ETH CMU	[cr/lf]
------------	------------	---------

Response Format

k [cr/lf]
OK [cr/lf]

Notation	Value	Range / Meaning
----------	-------	-----------------

k	Communication port status	0: OFFLINE, 1: ONLINE
---	---------------------------	-----------------------

Meaning Acquires the specified communication port status.
ONLINE / OFFLINE commands allow to change a specified communication port to the "online" / "offline" mode, respectively.

	Sample
Command	@?LINEMODE ETH [cr/lf]
Response	1 [cr/lf] OK [cr/lf]

3.8 Acquiring main program number

Command Format		
@?MAINPG [cr/lf]		
Response Format		
m [cr/lf] OK [cr/lf]		
Notation	Value	Range
m	Program number	0 to 100 (If not registered in the main program, 0 is returned.)

Meaning Acquires the program number which is registered in the main program.

Sample	
Command	@?MAINPG [cr/lf]
Response	1 [cr/lf] OK [cr/lf]

3.9 Acquiring sequence program execution status

Command Format		
@?SEQUENCE [cr/lf]		
Response Format		
1, s [cr/lf] OK [cr/lf]		
3, s [cr/lf] OK [cr/lf]		
0 [cr/lf] OK [cr/lf]		
Notation	Value	Range / Meaning
s	Execution status of sequence program	1: Program execution is in progress. 0: Program execution is stopped.

Meaning Acquires the sequence program execution status.

Response output means as follows:

- 1: Enabled
- 3: Enabled and output is cleared at emergency stop
- 0: Disabled

Sample	
Command	@?SEQUENCE [cr/lf]
Response	0 [cr/lf] OK [cr/lf]

3.10 Acquiring sequence compilation status

Command Format

@?SEQCMPSTS [cr/lf]

Response Format

x [cr/lf]
OK [cr/lf]

Notation	Value	Range / Meaning
x	sequence program status being compiled	0: Incomplete, 1: Complete

Meaning Acquires the sequence program compilation status.

	Sample	Description
Command	@?SEQCMPSTS [cr/lf]	Acquires the compilation status of the sequence program.
Response	1 [cr/lf] OK [cr/lf]	The sequence program is compiled.

3.11 Acquiring the version information

Command Format

@?VER [cr/lf]

Response Format

cv, cr-mv-dv1, dr1/dv2, dr2 [cr/lf]

Notation	Value
cv	Host version number
cr	Host revision number (Rxxxx)
mv	PLO version number (Vx.xx)
dv? (? : 1, 2)	Driver version number (Vx.xx)
dr? (? : 1, 2)	Driver revision number (Rxxxx)

Meaning Acquires the version information.

	Sample
Command	@?VER [cr/lf]
Response	V8.02, R1021-V5.10-V1.01, R0001/V1.01, R0001 [cr/lf] OK [cr/lf]

3.12 Acquiring the tasks in RUN or SUSPEND status

Command Format

```
@?TASKS [cr/lf]
```

Response Format

```
n{,n{,{...}}}[cr/lf]
OK[cr/lf]
```

Notation	Value	Range
n	Task number	1 to 16 (Task currently run or suspended)

Meaning Acquires the tasks in RUN or SUSPEND status.

	Sample
Command	@?TASKS [cr/lf]
Response	1,3,4,6 [cr/lf] OK[cr/lf]

3.13 Acquiring the tasks operation status

Command Format

```
@?TSKMON Tk [cr/lf]
```

Response Format

```
m,n,f,p [cr/lf]
OK [cr/lf]
```

Notation	Value	Range / Meaning
k	Task number	1 to 16
m	Execution program number	1 to 100
n	Task execution line number	1 to 9999
f	Each task status	R: RUN, U: SUSPEND, S: STOP, W: WAIT
p	Priority level of each task	1 to 64

Meaning Acquires the status of specified task.

	Sample
Command	@?TSKMON T3 [cr/lf]
Response	5,11,R,32 [cr/lf] OK[cr/lf]

3.14 Acquiring the task end condition

Command Format

```
@?TSKECD Tk[cr/lf]
```

Response Format

```
gg.bbb[cr/lf]
OK[cr/lf]
```

Notation	Value	Range
k	Task number	1 to 16
gg	Alarm group number of the task end condition	
bbb	Alarm classification number of the task end condition	

Meaning Acquires the specified task end condition.

Reference For details about alarm group number and classification number of the task end condition, refer to RCX3 user's manual.



When the specified task ends by error, acquires this alarm number.

	Sample	Description
Command	@?TSKECD T1[cr/lf].....	Acquires the end condition of task 1.
Response	1.5[cr/lf]..... OK[cr/lf]	The end condition of task 1 is 1.5: Program ended by "HALT".

3.15 Acquiring the shift status

Command Format

```
@?SHIFT[robot number][cr/lf]
```

Response Format

```
m[cr/lf]
OK[cr/lf]
```

Notation	Value	Range / Meaning
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
m	Shift number selected for the specified robot	0 to 39 Shift not selected: -1

Meaning Acquires the shift status of the robot specified by the <robot number>.

	Sample
Command	@?SHIFT[cr/lf]
Response	1[cr/lf] OK[cr/lf]

3.16 Acquiring the hand data

Command Format		
@?HND [<i>hand number</i>] [cr/lf]		
Response Format		
m [cr/lf] OK [cr/lf]		
Notation	Value	Range / Meaning
	<i>hand number</i>	0 to 31
m	Hand data	

Meaning Acquires the hand data specified by the <*hand number*>.

Sample		
Command	@?HND[0] [cr/lf] Acquires the data of hand 0.
Response	1,0,0.000,60.000 [cr/lf] OK [cr/lf]	

3.17 Acquiring the hand status

Command Format		
@?HAND [<i>robot number</i>] [cr/lf]		
Response Format		
m [cr/lf] OK [cr/lf]		
Notation	Value	Range / Meaning
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
m	Hand number selected for the specified robot	0 to 31 Hand not selected: -1

Meaning Acquires the hand status of the robot specified by the <*robot number*>.

Sample		
Command	@?HAND [cr/lf]	
Response	1 [cr/lf] OK [cr/lf]	

3.18 Acquiring the work data

Command Format

@?WRKDEF [*work number*] [cr/lf]

Response Format

m [cr/lf]
OK [cr/lf]

Notation	Value	Range / Meaning
	<i>work number</i>	0 to 39
m	work data	

Meaning Acquires the work data specified by the <*work number*>.

	Sample	Description
Command	@?WRKDEF [0] [cr/lf] Acquires the data of work 0.
Response	0.000 0.000 0.000 0.000 [cr/lf] OK [cr/lf]	

3.19 Acquiring the work status

Command Format

@?RBTWRK [*robot number*] [cr/lf]

Response Format

m [cr/lf]
OK [cr/lf]

Notation	Value	Range / Meaning
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
m	Work number selected for the specified robot	0 to 39 Work not selected: -1

Meaning Acquires the work status of the robot specified by the <*robot number*>.

	Sample	Description
Command	@?RBTWRK [cr/lf]	
Response	1 [cr/lf] OK [cr/lf]	

3.20 Acquiring the remaining memory capacity

Command Format
@?MEM [cr/lf]

Response Format
k/m [cr/lf]

Notation	Value
k	Remaining source area (unit: bytes)
m	Remaining global identifier area (unit: bytes)

Meaning Acquires the remaining memory capacity.

	Sample
Command	@?MEM [cr/lf]
Response	102543/1342 [cr/lf] OK [cr/lf]

3.21 Acquiring the alarm status

Command Format
@?ALM [cr/lf]

Response Format
gg.bbb [cr/lf] OK [cr/lf]

Notation	Value
gg	Alarm group number
bbb	Alarm classification number

Meaning Acquires the alarm which occurs in the controller.

Reference For details regarding the alarm group number and alarm classification number, refer to RCX3 user's manual.

MEMO

The requirable alarms are number 400 or more of alarm classification number. If multiple alarms occur, the alarm with larger alarm classification number (more serious alarm) is acquired.

	Sample
Command	@?ALM [cr/lf]
Response	12.600 [cr/lf] OK [cr/lf]

3.22 Acquiring the emergency stop status

Command Format

```
@?EMG [cr/lf]
```

Response Format

```
k [cr/lf]
OK [cr/lf]
```

Notation	Value	Range / Meaning
----------	-------	-----------------

k	Emergency stop status	0: normal operation, 1: emergency stop
---	-----------------------	--

Meaning Acquires the emergency stop status by checking the internal emergency stop flag.

Sample	
Command	@?EMG [cr/lf]
Response	1 [cr/lf] OK [cr/lf]

3.23 Acquiring the manual movement speed

Command Format

```
@?MSPEED [robot number] [cr/lf]
```

Response Format

```
k [cr/lf]
OK [cr/lf]
```

Notation	Value	Range
----------	-------	-------

	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
k	manual movement speed	1 to 100 (unit: %)

Meaning Acquires the value of the manual movement speed specified by <Robot number>.

Sample	
Command	@?MSPEED [cr/lf]
Response	50 [cr/lf] OK [cr/lf]

3.24 Acquiring the inching movement amount

Command Format		
@?IDIST [<i>robot number</i>] [cr/lf]		
Response Format		
mmmmm [cr/lf] OK [cr/lf]		
Notation	Value	Range
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
mmmmm	Inching movement amount	1 to 10000

Meaning Acquires the inching movement amount specified by <Robot number>.

Sample	
Command	@?IDIST [2] [cr/lf]
Response	100 [cr/lf] OK [cr/lf]

3.25 Acquiring the last reference point number (current point number)

Command Format		
@?CURPNT [cr/lf]		
Response Format		
k [cr/lf] OK [cr/lf]		
Notation	Value	Range
k	Current point number	0 to 29999

Meaning Acquires the point number which is referred last. The current point number (the point number of last reference) is renewed by operations which uses the point data (point edit, for example).

 **MEMO**

The current point number is renewed by following operations: the point reference and the point setting movement by remote commands, the trace movement or teaching by programming box or RCX-Studio Pro, etc.

Sample	
Command	@?CURPNT [cr/lf]
Response	100 [cr/lf] OK [cr/lf]

3.26 Acquiring the output message

Command Format

```
@?MSG[cr/lf]
```

Response Format

```
sssss ..... ssssss[cr/lf]
OK[cr/lf]
```

Notation	Value
----------	-------

s	Message character string
---	--------------------------

Meaning Acquires one line of message which is input from the output message buffer of the controller by the PRINT statement, etc.

	Sample	Description
Command	@?MSG[cr/lf]	
Response	MESSAGE[cr/lf]..... OK[cr/lf]	PRINT "MESSAGE" is executed in a program.

MEMO

- For executing this command, it is required that the "INPUT/PRINT using channel" parameter is set at the port to execute command.
- When the output message buffer is empty, only "OK" is output as the response.

3.27 Acquiring the input data

Command Format

```
@?INPUT[cr/lf]
```

Response Format

```
d[cr/lf]
OK[cr/lf]
```

Notation	Value
----------	-------

d	Input data
---	------------

Meaning Acquires the input data by the INPUT statement.

	Sample
Command	@?INPUT[cr/lf]
Response	INPUT_SAMPLE[cr/lf] OK[cr/lf]

3.28 Acquiring various values

3.28.1 Acquiring the value of a numerical expression

Command Format

```
@?numerical expression[cr/lf]
```

Response Format

```
numerical value[cr/lf]  
OK[cr/lf]
```

Meaning Acquires the value of the specified numerical expression.
The numerical expression's value format is "decimal" or "real number".

Sample 1	
Command	@?SQR(100*5) [cr/lf]
Response	2.236067E01 [cr/lf] OK [cr/lf]

Sample 2	
Command	@?LOC1(WHERE) [cr/lf]
Response	102054 [cr/lf] OK [cr/lf]

3.28.2 Acquiring the value of a character string expression

Command Format

```
@?character string expression[cr/lf]
```

Response Format

```
character string[cr/lf]  
OK[cr/lf]
```

Meaning Acquires the value (character string) of the specified character string expression.

Sample: The case of A\$="ABC" and B\$="DEF".	
Command	@?A\$+B\$+"123" [cr/lf]
Response	ABCDEF123 [cr/lf] OK [cr/lf]

3.28.3 Acquiring the value of a point expression

Command Format

```
@?point expression[cr/lf]
```

Response Format

```
point data[cr/lf]  
OK[cr/lf]
```

Meaning Acquires the value (point data) of the specified point expression.

	Sample
Command	@?P1+WHRXY[cr/lf]
Response	10.410 -1.600 52.150 3.000 0.000 0.000 0 0 0[cr/lf] OK[cr/lf]

3.28.4 Acquiring the value of a shift expression

Command Format

```
@?shift expression[cr/lf]
```

Response Format

```
shift data[cr/lf]  
OK[cr/lf]
```

Meaning Acquires the value (shift coordinate data) of the specified shift expression.

	Sample
Command	@?s1[cr/lf]
Response	25.000 12.600 10.000 0.000[cr/lf] OK[cr/lf]

4.1 Absolute reset

Command Format

```
@ABSADJ [robot number] k, f [cr/lf]
@MRKSET [robot number] k [cr/lf]
```

Response Format

```
RUN [cr/lf] ..... At movement start
END [cr/lf] ..... At movement end
```

Notation	Value	Range / Meaning
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
k	Axis number	1 to 6
f	Movement direction	0: + direction, 1: - direction

Meaning Performs the absolute reset operation of the specified axis of the robot specified by *<robot number>*.

This command is available only to axes whose return-to-origin method is set as "Mark".

ABSADJ: Moves the specified robot axis to an absolute reset position.

MRKSET: Performs absolute reset on the specified robot axis.

	Sample	Description
Command	@ABSADJ 1,0 [cr/lf]	
Response	RUN [cr/lf] END [cr/lf]	Movement start Movement end

4.2 Return-to-origin operation

Command Format

```
@ORGRTN [robot number] k[cr/lf]
```

Response Format

```
RUN[cr/lf] ..... At movement start
END[cr/lf] ..... At movement end
```

Notation	Value	Range
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
k	Axis number	1 to 6

Meaning Performs the return-to-origin operation of the specified axis of the robot specified by *<robot number>*. For the axis with the semi-absolute specifications, when the return-to-origin is executed, the absolute search operation is performed.

	Sample	Description
Command	@ORGRTN 1[cr/lf]	
Response	RUN[cr/lf] Movement start END[cr/lf] Movement end	

4.3 Manual movement: inching

Command Format

```
@INCH[robot number] km[cr/lf]
@INCHXY[robot number] km[cr/lf]
@INCHT[robot number] km[cr/lf]
```

Response Format

```
RUN[cr/lf] ..... At movement start
END[cr/lf] ..... At movement end
```

Notation	Value	Range
	<i>robot number</i>	1 to 4 (If not input, robot 1 is specified.)
k	Axis number	1 to 6
m	Movement direction	+, -

Meaning Manually moves (inching motion) the specified axis of the robot specified by the *<robot number>*. The robot performs the same motion as when moved manually in inching motion with the programming box's jog keys (moves a fixed distance each time a jog key is pressed).

The unit of the movement amount and operation type by command are shown below.

- INCH: "pulse" units. Only the specified axis moves.
- INCHXY: "mm" units. According to the robot configuration, the arm tip of the robot moves in the direction of the Cartesian coordinate system.
- INCHT: "mm" units. According to the robot configuration, the hand attached to the arm tip of the robot moves.

	Sample	Description
Command	@INCH 1+[cr/lf]	
Response	RUN[cr/lf] Movement start END[cr/lf] Movement end	

4.4 Manual movement: jog

Command Format

```
@JOG[robot number] km[cr/lf]
@JOGXY[robot number] km[cr/lf]
@JOGT[robot number] km[cr/lf]
```

Response Format

```
RUN[cr/lf] ..... At movement start
END[cr/lf] ..... At movement end
```

Notation	Value	Range
	robot number	1 to 4 (If not input, robot 1 is specified.)
k	Axis number	1 to 6
m	Movement direction	+, -

Meaning Manually moves (jog motion) the specified axis of the robot specified by the <robot number>. The robot performs the same motion as when holding down the programming box's jog keys in manual mode.

To continue the operation, it is necessary for the JOG command to input the execution continue process (^V(=16H)) by the online command at intervals of 200ms. If not input, the error stop occurs.

Additionally, after the movement has started, the robot stops when any of the statues shown below arises.

- When software limit was reached.
- When stop signal was turned off.
- When STOP key on the programming box was pressed.
- When an online command (^C (=03H)) to interrupt execution was input.

The unit of the movement amount and operation type by command are shown below.

JOG : "pulse" units.

Only the specified axis moves.

JOGXY: "mm" units.

According to the robot configuration, the arm tip of the robot moves in the direction of the Cartesian coordinate system.

JOGT: "mm" units.

According to the robot configuration, the hand attached to the arm tip of the robot moves.

	Sample	Description
Command	@JOG 1+[cr/lf]	
Response	RUN[cr/lf]	Movement start
	END[cr/lf]	Movement end

5.1 Copy operations

5.1.1 Copying a program

Command Format		
@COPY	<program name 1> PGn	TO <program name 2> [cr/lf]

Response Format		
RUN [cr/lf]	At process start
END [cr/lf]	At process end

Notation	Value	Range
Program name 1	Program name in copy source	32 characters or less consisting of alphanumeric characters and underscore
Program name 2	Program name in copy destination	alphanumeric characters and underscore
n	Program number	1 to 100

Meaning Copies the program specified by <program name 1> or program number to <program name 2>.

	Sample	Description
Command	@COPY <TEST1> TO <TEST2> [cr/lf]	
Response	RUN [cr/lf]	Process start
	END [cr/lf]	Process end

5.1.2 Copying point data

Command Format		
@COPY	Pmmmmm-Pnnnnn	TO Pkkkkk [cr/lf]

Response Format		
RUN [cr/lf]	At process start
END [cr/lf]	At process end

Notation	Value	Range
m	Top point number in copy source	
n	Last point number in copy source	0 to 29999
k	Top point number in copy destination	

Meaning Copies the point data between Pmmmmm and Pnnnnn to Pkkkkk.

	Sample	Description
Command	@COPY P101-P200 TO P1101 [cr/lf]	
Response	RUN [cr/lf]	Process start
	END [cr/lf]	Process end

5.1.3 Copying point comments

Command Format

```
@COPY PCmmmmm-PCnnnnn TO PCkkkkk [cr/lf]
```

Response Format

```
RUN [cr/lf] ..... At proess start
END [cr/lf] ..... At proess end
```

Notation	Value	Range
mmmmm	Top point comment number in copy source	
nnnnn	Last point comment number in copy source	0 to 29999
kkkkk	Top point comment number in copy destination	

Meaning Copies the point comments between PCmmmmm and PCnnnnn to PCkkkkk.

	Sample	Description
Command	@COPY PC101-PC200 TO PC1101 [cr/lf]	
Response	RUN [cr/lf] Process start END [cr/lf] Process end	

5.2 Erase

5.2.1 Erasing a program

Command Format

```
@ERA <program name>
PGn [cr/lf]
```

Response Format

```
RUN [cr/lf] ..... At proess start
END [cr/lf] ..... At proess end
```

Notation	Value	Range
<i>Program name</i>	Program name to be erased	32 characters or less consisting of alphanumeric characters and underscore
n	Program number	1 to 100

Meaning Erases the designated program.

	Sample	Description
Command	@ERA <TEST1> [cr/lf]	
Response	RUN [cr/lf] Process start END [cr/lf] Process end	

5.2.2 Erasing point data Command format

Command Format		
@ERA Pmmmmm-Pnnnnn [cr/lf]		
Response Format		
RUN [cr/lf] At process start		
END [cr/lf] At process end		
Notation	Value	Range
m m m m m	Top point number to be erased	0 to 29999
n n n n n	Last point number to be erased	

Meaning Erases the point data between Pmmmmm and Pnnnnn.

	Sample	Description
Command	@ERA P101-P200 [cr/lf]	
Response	RUN [cr/lf]	Process start
	END [cr/lf]	Process end

5.2.3 Erasing point comments

Command Format		
@ERA PCmmmmm-PCnnnnn [cr/lf]		
Response Format		
RUN [cr/lf] At process start		
END [cr/lf] At process end		
Notation	Value	Range
m m m m m	Top point comment number to be erased	0 to 29999
n n n n n	Last point comment number to be erased	

Meaning Erases the point comments between PCmmmmm and PCnnnnn.

	Sample	Description
Command	@ERA PC101-PC200 [cr/lf]	
Response	RUN [cr/lf]	Process start
	END [cr/lf]	Process end

5.2.4 Erasing point name

Command Format

```
@ERA PNmmmm- PNnnnn [cr/lf]
```

Response Format

```
RUN [cr/lf] ..... At proess start
END [cr/lf] ..... At proess end
```

Notation	Value	Range
mmmm	Top point name number to be erased	0 to 29999
nnnn	Last point name number to be erased	

Meaning Erases the point names between PNmmmm and PNnnnn.

	Sample	Description
Command	@ERA PC101-PC200 [cr/lf]	
Response	RUN [cr/lf] Process start END [cr/lf] Process end	

5.2.5 Erasing pallet data

Command Format

```
@ERA PLm [cr/lf]
```

Response Format

```
RUN [cr/lf] ..... At proess start
END [cr/lf] ..... At proess end
```

Notation	Value	Range
m	Pallet number to be erased	0 to 39

Meaning Erases the PLm pallet data.

	Sample	Description
Command	@ERA PL1 [cr/lf]	
Response	RUN [cr/lf] Process start END [cr/lf] Process end	

5.2.6 Erasing general-purpose Ethernet port

Command Format		
@ERA GPm[cr/lf]		
Response Format		
RUN[cr/lf] At prosess start		
END[cr/lf] At prosess end		
Notation	Value	Range
m	General-purpose Ethernet port number to be erased	0 to 15

Meaning Erases the general-purpose Ethernet port of "GPm".

	Sample	Description
Command	@ERA GP5[cr/lf]	
Response	RUN[cr/lf]	Process start
	END[cr/lf]	Process end

5.2.7 Erasing real time output

Command Format		
@ERA RTmmm-RTnnn[cr/lf]		
Response Format		
RUN[cr/lf] At prosess start		
END[cr/lf] At prosess end		
Notation	Value	Range
mmm	Top real time output number to be erased	24 to 127
nnn	Last real time output number to be erased	

Meaning Erases the real time output setteng between RTmmm and RTnnn.

	Sample	Description
Command	@ERA RT24-RT80[cr/lf]	
Response	RUN[cr/lf]	Process start
	END[cr/lf]	Process end

5.3 Rename program

Command Format

@REN	<program name 1> PGn	TO <program name 2> [cr/lf]
------	-------------------------	-----------------------------

Response Format

```
RUN[cr/lf] ..... At process start
END[cr/lf] ..... At process end
```

Notation	Value	Range
<i>Program name 1</i>	Program name before renaming	32 characters or less consisting of alphanumeric characters and underscore
<i>Program name 2</i>	Program name after renaming	
n	Program number	1 to 100

Meaning Changes the name of the specified program.

	Sample	Description
Command	@REN <TEST1> TO <TEST2> [cr/lf]	
Response	RUN[cr/lf] Process start END[cr/lf] Process end	

5.4 Changing the program attribute

Command Format

@ATTR	<program name> PGn	TO s[cr/lf]
-------	-----------------------	-------------

Response Format

```
OK[cr/lf]
```

Notation	Value	Range / Meaning
<i>Program name</i>	Program name to change the attribute	32 characters or less consisting of alphanumeric characters and _ (underscore)
s	Attribute	RW: Readable/writable RO: Not writable (read only) H: Hidden
n	Program number	1 to 100

Meaning Changes the attribute of the program specified by the <program name> or program number.

	Sample	Description
Command	@ATTR <TEST1> TO RO[cr/lf]	
Response	OK[cr/lf]	

5.5 Initialization process

5.5.1 Initializing the memory area

Command Format

```
@INIT memory area[cr/lf]
```

Response Format

```
RUN[cr/lf] ..... At process start
END[cr/lf] ..... At process end
```

Notation	Value	Meaning
<i>Memory area</i>	PGM	Initializes the program area.
	PNT	Initializes the point data area.
	SFT	Initializes the shift data area.
	HND	Initializes the hand data area.
	WRKDEF	Initializes the work data area.
	PLT	Initializes the pallet data area.
	PCM	Initializes the point comment area.
	PNM	Initializes the point name area.
	ION	Initializes the input/output name area.
	ACO	Initializes the area check output setting area.
	RTO	Initializes the real time output setting area.
	GEP	Initializes the general-purpose Ethernet port setting area.
	MEM	Initializes the above areas (PGM ... all data up to GEP).
	PRM	Initializes the parameter area.
	ALL	Initializes all areas (MEM+PRM).

Meaning Initializes the memory area.
To Initialize, specify any memory area among "Value" above.

	Sample	Description
Command	@INIT PGM[cr/lf]	
Response	RUN[cr/lf]	Process start
	END[cr/lf]	Process end

5.5.2 Initializing the communication port

Command Format

```
@INIT communication port [cr/lf]
```

Response Format

```
RUN [cr/lf] ..... At process start
END [cr/lf] ..... At process end
```

Notation	Value	Meaning
<i>Communication port</i>	CMU	Initializes the RS-232C port
	ETH	Initializes the Ethernet port

Meaning Initializes the communication port.
To Initialize, specify any port between "Value" above.

Reference For information about the communication port initial settings, refer to RCX3 user's manual.

	Sample	Description
Command	@INIT CMU [cr/lf]	
Response	RUN [cr/lf] Process start END [cr/lf] Process end	

5.5.3 Initializing the alarm history

Command Format

```
@INIT LOG [cr/lf]
```

Response Format

```
RUN [cr/lf] ..... At process start
END [cr/lf] ..... At process end
```

Meaning Initializes the alarm history.

	Sample	Description
Command	@INIT LOG [cr/lf]	
Response	RUN [cr/lf] Process start END [cr/lf] Process end	

5.6 Data readout processing

Command Format

```
@READ read-out file[cr/lf]
```

Response Format

```
BEGIN[cr/lf] ..... At process start
(Data output: The contents may vary depending on the read-out file.)
END[cr/lf] ..... At process end
```

Meaning Reads out the data from the designated file.

- Online commands that are input through the RS-232C port have the same meaning as the following command.
SEND <read-out file> TO CMU
- Commands via Ethernet have the same meaning as the following command.
SEND <read-out file> TO ETH

Reference Chapter 10 "Data file description"

Type	Read-out file name	Definition format	
		All	Individual file
User memory	All file	ALL	-----
	Program	PGM	<bb...b>>
	Point data	PNT	Pn
	Point comment	PCM	PCn
	Point name	PNM	PNn
	Parameter	PRM	/ccccccc/
	Shift definition	SFT	Sn
	Hand definition	HND	Hn
	Work definition	WRKDEF	Wn
	Pallet definition	PLT	PLn
	General Ethernet port	GEP	GPn
	Input/output name	ION	iNMn(n)
	Area check output	ACO	ACn
	Real time output	RTO	RTn
Variable, constant	Variable	VAR	ab...by
	Array variable	ARY	ab...by(x)
	Constant	-----	"cc...c"
Status	Program directory	DIR	<<bb...b>>
	Parameter directory	DPM	-----
	Machine reference (sensor or stroke-end)	MRF	-----
	Machine reference (mark)	ARP	-----
	Accumulated data	ACD	-----
	System configuration information	CFG	-----
	Controller	CNT	-----
	Robot	RBT	-----
	Driver	DRV	-----
	Option board	OPT	-----
	Self check	SCK	-----
	Alarm history	LOG	-----
	Remaining memory size	MEM	-----
Device	DI port	DI()	DIn()
	DO port	DO()	DOn()
	MO port	MO()	MOn()
	TO port	TO()	TOn()
	LO port	LO()	LOn()
	SI port	SI()	SI n()
	SO port	SO()	SO n()
	SIW port	SIW()	SIWn()
SOW port	SOW()	SOWn()	
Others	File end code	EOF	-----

a: Alphabetic character b: Alphanumeric character or underscore (_) c: Alphanumeric character or symbol
i: I/O type n: Number x: Expression (Array argument) y: variable type

Command	Sample	Description
	@READ PGM[cr/lf].....	Reads out all programs.
	@READ P100[cr/lf].....	Reads out the point 100.
	@READ DIN2(0)[cr/lf].....	Reads out the input/output name of DI2(0).

6.1 Setting the sequence program execution flag

Command Format

```
@SEQUENCE k[cr/lf]
```

Response Format

```
OK[cr/lf]
```

Notation	Value	Range / Meaning
k	Execution flag	0: disable, 1: enable, 3: enable (DO reset)

Meaning Sets the sequence program execution flag.

	Sample	Description
Command	@SEQUENCE 1[cr/lf]	
Response	OK[cr/lf]	

6.2 Setting the date

Command Format

```
@DATE yy/mm/dd[cr/lf]
```

Response Format

```
OK[cr/lf]
```

Notation	Value	Range
yy/mm/dd	Date to be set	year, month, day
yy	Lower 2 digits of the year	00 to 99
mm	Month	01 to 12
dd	Day	01 to 31

Meaning Sets a date in the controller.



NOTE

To change only the year or month, the slash (/) following it can be omitted.

Example:

- To set the year to 2016, enter 16(cr/lf).
- To set the month to June, enter /06(cr/lf).

MEMO

- The currently set values are used for the omitted items.
- If only [cr/lf] is transmitted, then the date remains unchanged.
- If an improbable date is entered, then "5.202: Data error" occurs.

Sample 1 : To change only the day,

Command	//15[cr/lf] Day is set to 15th.
---------	---------------------------------------

Sample 2

Command	@DATE 16/01/14[cr/lf]
---------	-----------------------

Response	OK[cr/lf]
----------	-----------

6.3 Setting the time

Command Format

```
@TIME hh:mm:ss [cr/lf]
```

Response Format

```
OK [cr/lf]
```

Notation	Value	Range
hh:mm:ss	Current time	
hh	Hour	00 to 23
mm	Minute	00 to 59
ss	Second	00 to 59

Meaning Sets the time of the controller.

MEMO

- The currently set values are used for the omitted items.
- If only [cr/lf] is transmitted, then the time remains unchanged.
- If an improbable time is entered, then "5.202: Data error" occurs.

Sample 1: To change only the minute,

Command :20:[cr/lf].....Minute is set to 20.

Sample 2

Command @TIME 10:21:35 [cr/lf]

Response OK [cr/lf]

7.1 Command

Command Format

```
@robot language[cr/lf]
```

Response Format 1

```
OK[cr/lf] or NG=gg.bbb[cr/lf]
```

Response Format 2

```
RUN[cr/lf] or NG=gg.bbb[cr/lf] ..... At process start
END[cr/lf] or NG=gg.bbb[cr/lf] ..... At process end
```

Notation	Value	Range
OK, END	Command ended correctly	
NG	An error occurred	
RUN	Command starts correctly	
gg	Alarm group number	0 to 99
bbb	Alarm classification number	0 to 999

Meaning Robot language commands can be executed.

- Only independently executable commands are executed.
- Command format depends on each command to be executed.

Sample 1

Command	@SET DO(20) [cr/lf]
Response	OK[cr/lf]

Sample 2**Description**

Command	@MOVE P,P100,S=20 [cr/lf]
Response	RUN[cr/lf] Process start END[cr/lf] Process end

7.2 Function

Command Format

@?robot language[cr/lf]

Response Format

X [cr/lf]
OK[cr/lf]

Notation	Value	Range
X	Return value	
OK, END	Command ended correctly	
NG	An error occurred	
gg	Alarm group number	0 to 99
bbb	Alarm classification number	0 to 999

Meaning Robot language Functions can be executed.

- Only independently executable functions are executed.
- Function format depends on each function to be executed.

	Sample	Description
Command	@?REFTSK(1) [cr/lf]	Acquires the status of Task 1.
Response	0 [cr/lf] OK[cr/lf]	Task 1 is in STOP staus.

Command Format

^C (=03H)

Response Format

NG=1.8

Meaning Interrupts execution of the current command.

	Sample	Description
Command	@MOVE P, P100, S=20 [cr/lf] ^C	
Response	NG=1.8 [cr/lf]	

Chapter 13

Appendix

- 1 Reserved word list..... 13-1
- 2 Changes from conventional models..... 13-3

The words shown below are reserved for robot language and cannot be used as identifiers (variables, etc.).

A	D	HOLDALL	MRKSET
ABS	DATE	I	MSG
ABSADJ	DBP	IDIST	MSGCLR
ABSRPOS	DECEL	IF	MSPEED
ACCEL	DEF	IMP	MTRDUTY
ACCESS	DEGRAD	INCH	N
ACD	DELAY	INCHT	NAME
ACO	DI	INCHXY	NEXT
ALL	DIM	INIT	NOT
ALM	DIR	INPUT	O
ALMRST	DIST	INROFST	OFFLINE
AND	DO	INT	ON
ARCHP1	DPM	ION	ONLINE
ARCHP2	DRIVE	J	OPEN
ARM	DRIVEI	JOG	OPT
ARMCND	DRV	JOGT	OR
ARMSEL	E	JOGXY	ORD
ARMTYP	ELSE	JTOXY	ORGORD
ARP	ELSEIF	L	ORGRTN
ARY	EMG	LEFT	ORIGIN
ASPEED	END	LEFTY	OUT
ATN	ENDIF	LEN	OUTPOS
ATN2	EOF	LET	P
ATTR	EQV	LINEMODE	P
AXWGHT	ERA	LO	PATH
B	ERL	LOAD	PCM
BIN	ERR	LOC1	PDEF
BREAK	ERROR	LOC2	PGM
C	ETH	LOC3	PGMTSK
CALL	ETHSTS	LOC4	PGN
CASE	EXIT	LOC5	PLT
CFG	EXITTASK	LOC6	PMOVE
CHANGE	F	LOCF	PNM
CHGPRI	FN	LOG	PNT
CHGWRK	FOR	LSHIFT	PPNT
CHR	G	M	PRINT
CLOSE	GEP	MAINPG	PRM
CMU	GEPSTS	MCHREF	PSHFRC
CNT	GO	MEM	PSHJGSP
CORRECTXY	GOSUB	MID	PSHMTD
CONTPLS	GOTO	MO	PSHRSLT
COPY	H	MOD	PSHSPD
COS	HALT	MODE	PSHTIME
CREWRK	HALTALL	MOTOR	PUSH
CURPNT	HAND	MOVE	R
CURTQST	HEX	MOVEI	RADDEG
CURTRQ	HND	MOVET	RBT
CUT	HOLD	MRF	RBTWRK

READ	SFT	TASKS	WHILE
REF	SGI	TCHXY	WHRXY
REM	SGR	TCOUNTER	WHRXYEX
REN	SHARED	TEACH	WRITE
RESET	SHIFT	THEN	WRKDEF
RESTART	SI	TIME	X
RESUME	SID	TIMER	XOR
RETURN	SIN	TO	XYTOJ
RIGHT	SIW	TOLE	
RIGHTY	SKIP	TORQUE	
RSHIFT	SKIPTO	TSKECD	
RTO	SO	TSKMON	
RUN	SOD	TSKPGM	
RUNTO	SOW	V	
S	SPEED	VAL	
S	SQR	VAR	
SCK	START	VER	
SCRINR	STEP	VMCDEF	
SELECT	STOP	VMCPNO	
SEND	STR	VMCORRECT	
SEQCMPL	SUB	VMCSTS	
SEQCMPSTS	SUSPEND	W	
SEQUENCE	SWI	WAIT	
SERVO	SYNCHK	WEIGHT	
SET	T	WEIGHTG	
SETGEP	TAG	WEND	
SETPW	TAN	WHERE	

Since the following names are used as system variable names, they cannot be used at the beginning of other variable names

ACn	GPn	PNn	SON
DIn	Hn	SGIn	SONMn
DINMn	LOn	SGRn	TON
DOOn	MOOn	SIn	
DONMn	PCn	SINMn	
FN	Pn	Sn	

n: numeric value

Variable name usage examples

- Although keywords which are reserved as robot language words cannot be used as they are, **they can be used as variable names if alphanumeric characters are added to them.**

Example: "ABS" cannot be used, but "ABS1" or "ABSX" can be used.

- Keywords reserved as system variables cannot be used at the beginning of other variable names**, even if alphanumeric characters are added to them.

Example: "FN" cannot be used. "FNA" and "FN123" also cannot be used.

2 Changes from conventional models

1 Program name

For RCX340/RCX320, the following two program names which have been special for conventional models (RCX240, etc.) don't have a special meaning.

- A) FUNCTION
- B) _SELECT

A) FUNCTION

In conventional models (RCX240, etc.), "FUNCTION" has been a special program for registering a user function. RCX340/RCX320 doesn't have a user function, thus it doesn't have a special meaning.

B) _SELECT

In conventional models (RCX240, etc.), the "_SELECT" program has been selected and executed every time robot programs were reset.

In RCX340/RCX320, the program specified at the main program number (or the program executed last if there is no specified program there) is selected and executed when robot programs are reset.

For details regarding the main program, refer to "12. Set main program" in "2.1 Program operations" in Chapter 12.

2 Multiple Robot Control

In conventional models (RCX240, etc.), robot has consisted of a main group (one main robot, main auxiliary axes) and a sub group (one sub robot, sub auxiliary axes).

In RCX340/RCX320, robot consists of robot 1 to 4 (normal axes, auxiliary axes).

Due to this change, commands for each group have changed to ones for each robot.

For details regarding the command for each robot, refer to "2. Command list with a robot setting" in Chapter 5 of this manual for RCX340/RCX320, and regarding the command for each group, refer to "Command list for each group" of the programming manual for conventional models (RCX240, etc.), respectively.

Command to each robot group by conventional controller (RCX240, etc.)

Sample	Description
MOVE P, P1	Axes of a main group move to the position specified at P1.
MOVE2 P, P5	Axes of a sub group move to the position specified at P5.

Command to specified robot by RCX340/RCX320

Sample	Description
MOVE P, P1	Axes of the robot 1 move to the position specified at P1.
MOVE[2] P, P5	Axes of the robot 2 move to the position specified at P5.

MEMO

.....
 Robot number can be omitted in the commands with a robot setting. When omitted, robot 1 is specified.

3 Multi-tasking

The differences between RCX340/RCX320 and conventional models (RCX240, etc.) are shown below.

	Conventional models	RCX340/RCX320
Maximum number of task	8	16
Priority	17 to 47	1 to 63
Task definition	During the program	In another program
Starting tasks	Task is assigned in Task 1 automatically and placed in RUN status	Task is assigned in a specified task number and placed in RUN status
Command execution for Task 1 (restart, etc.)	Not executable	Executable

Reference For details regarding the multi-tasking, refer to Chapter 6 "Multi-tasking" in this manual or in a programming manual for conventional models (RCX240, etc.).

4 Robot Language

The following robot languages are not supported in RCX340/RCX320.

ABSINIT	ABSINIT2	ABSRST	ABSRPOS2
ACCEL2	ARMCND2	ARMTYP2	ASPEED2
AXWGHT2	CHANGE2	CURTRQ2	DECEL2
DECLARE	DRIVE2	DRIVEI2	HAND2
JTOXY2	LEFTY2	MCHREF2	MOVE2
MOVEI2	ORGORD2	OUTPOS2	PMOVE2
RIGHTY2	SERVO2	SHIFT2	SPEED2
TOLE2	TORQUE2	TRQSTS	TRQSTS2
TRQTIME	TRQTIME2	WAIT ARM2	WEIGHT2
WHERE2	WHRXY2	XYTOJ2	_SYSFLG

Reference For details regarding the robot Languages above, refer to the programming manual for conventional models (RCX240, etc.).

5 Online commands

The following online commands are not supported in RCX340/RCX320.

AUTO	EMGRST	EXELV	MANUAL
? ARM	? CONFIG	? EXELVL	? OPSLOT
? SELFCHK	? WHRXYEX		

Reference For details regarding the online commands above, refer to the programming manual for conventional models (RCX240, etc.).

6 Data file

- "Alarm history file" replaced "Error message history file" and "Error message history details file" of conventional models.
- In RCX340/RCX320, the point number ranges from 0 to 29999 (0 to 9999: Conventional models).

Reference Chapter 10 "Data file description"

Revision record

Version	Issue date	Description
Ver. 1.00	Apr. 2014	First edition
Ver. 1.10	Aug. 2014	Clerical error corrections, etc.
Ver. 1.20	Mar. 2016	Chapter 7 "Sequence function" was added. "PATH control" and "Torque control" were added to robot language in Chapter 8. Chapter 9 "PATH Statements" was added. "2.5 Sealing" was added in Chapter 11. "2 Changes from conventional models" was added in Chapter 13.
Ver. 1.21	Feb. 2017	Contact information was changed.
Ver. 1.31	Mar. 2017	Conditions of PUSH statement were changed in Chapter 8. Descriptions on "I/O name" were added in Chapter 10.
Ver. 1.33	Mar. 2018	Descriptions of current value were added to CURTQST/CURTRQ/MTRDUTY statements, descriptions of online/offline modes were added to OFFLINE/ONLINE statements in Chapter 8.
Ver. 1.37	Nov. 2018	Commands for work definition were added.
Ver. 1.38	Aug. 2019	WEIGHTG statement was added.
Ver. 2.00	Oct. 2019	Controller "RCX320" was added.
Ver. 2.03	Apr. 2020	Added the functions (real time output/SLOW area extension) and commands (CONTPLS/CORRECTXY/SCRINR/INROFST).
Ver. 2.06	Feb. 2021	Added the function (Task status acquisition REFTSK) and the online commands (HND/WRKDEF).
Ver. 2.07	Oct. 2021	Added the work data as the usable target of LOCx (Ch. 8).
Ver. 2.09	Apr. 2022	Added ACD (Data file/ Online command) and SEQCMPSTS (Online command). Added the descriptions of sample programs to Ch. 8
Ver. 2.10	Oct. 2022	Added the followings; Descriptions to ACD (Ch. 8/ 10), Formats to SGI/ SGR (Ch. 8), Descriptions when omitting the point No. to PDEF (Ch. 8).
Ver. 2.11	Feb. 2023	Clerical error corrections.

Programming Manual

4-axis/2-axis Robot Controller

RCX 3 Series

February 2023

Ver. 2.11

YAMAHA MOTOR CO., LTD. Robotics Operations

All rights reserved. No part of this publication may be reproduced in any form without the permission of YAMAHA MOTOR CO., LTD. Information furnished by YAMAHA in this manual is believed to be reliable. However, no responsibility is assumed for possible inaccuracies or omissions. If you find any part unclear in this manual, please contact your distributor.

Robotics Operations

127 Toyooka, Kita-ku, Hamamatsu, Shizuoka, 433-8103, Japan

<https://global.yamaha-motor.com/business/robot/>

